


EC-4310-RS

Intelligent Conductivity Transmitter

Operation
Manual



CONTENTS

Precautions for installation

Brief Instruction	1
1. Specifications	4
2. Assembly and installation	
2.1 Transmitter installation.....	5
2.2 Illustration of panel mounting.....	5
2.3 Illustration of Wall mounting and pipe mounting.....	6
3. Overview of conductivity transmitter EC-4310-RS	
3.1 Illustration of rear panel.....	7
3.2 Illustration of terminal function.....	7
3.3 Description of terminal function.....	8
3.4 Wiring of cable.....	9
3.5 Circuit of cable.....	9
3.6 Illustration of electrical connection.....	10
3.7 Online EC/RC pipe system(Optional).....	11
4. Configuration	
4.1 Illustration of front panel.....	12
4.2 Keypad.....	12
4.3 LED indicators.....	12
5. Operation	
5.1 Measurement mode.....	13
5.2 Set-up menu.....	13
5.3 Calibration menu.....	13
5.4 Shortcuts.....	13
5.5 Default value.....	13
6. Measurement display mode	
6.1 Text mode.....	15
6.2 Real-time chart mode.....	16
6.3 Trace mode.....	17
6.4 Warning symbols and text.....	18
7. Settings	
Block diagram of Setting.....	19
7.1 Entry of set-up menu.....	21
7.2 Security code of settings.....	22
7.3 Language.....	23

7.4 Mode.....	24
7.4.1 Cond. measurement mode.....	24
7.4.2 Res. measurement mode.....	25
7.4.3 Salinity & TDS measurement mode.....	26
7.5 Product adjustment.....	27
7.6 Temperature.....	28
7.7 Temperature compensation coefficient.....	29
7.8 Relay 1.....	30
7.9 Relay 2.....	31
7.10 Clean.....	32
7.11 Analog output 1.....	33
7.12 Date/Time (Clock).....	34
7.13 RS-485 communication.....	35
7.14 Sample average of measurements (Digital filter).....	36
7.15 Backlight settings.....	37
7.16 Contrast settings.....	38
7.17 Logbook.....	39
7.18 Power frequency (Frequency).....	40
7.19 Return.....	41
8. Calibration	
Block diagram of calibration.....	42
8.1 Enter calibration setup menu.....	43
8.2 Security password of calibration (Code).....	44
8.3 Cell constant calibration.....	45
8.3.1 Resistivity (Res.).....	45
8.3.2 Conductivity (Cond.).....	46
8.4 Standard solution calibration (Std. solution).....	47
8.5 Return.....	48
9. MODBUS protocol and instructions	
9.1 Communication connection.....	49
9.2 MODBUS address and command table.....	51
9.3 MODBUS example description.....	55
10. Error messages (Error code)	56
11. Installation of cells	
11.1 Appearance of cells.....	57
11.2 Correct installation.....	58
11.3 Incorrect installation.....	58
Appendix	59

Thank you for purchasing Suntex products. In order to continually improve and enhance the transmitter's function, Suntex reserves the right to modify the content and icon display of the product. The actual situation is subject to the instrument without notice. The operation manual is only provided for function and installation description, Suntex Instruments Co., Ltd. is not liable for any person or entity for any direct or indirect loss or damage due to improper usage of this product. If you have any questions or find omission, negligence or mistakes of the operation manual, please contact with our staff, thank you.

Precautions for installation

Wrong wiring will lead to breakdown or electrical shock of the instrument, please read this operation manual clearly before installation.

- Make sure to remove AC power from the transmitter before wiring input, output connections, and remove it before opening the transmitter's housing.
- The installation site of the transmitter should be good in ventilation and avoid direct sunshine.
- The material of signal cable should be special coaxial cable. Strongly recommend using our coaxial cable. Do not use normal wires instead.
- Avoid electrical surge when using power. Especially when using three-phase power, use ground wire correctly. If the power surges interference occurs, separate the power supply of transmitter from the control device, such as: dosing machines, mixers, etc. to make individual power supply for the transmitter; or set surge absorber to reduce the power surges at all electromagnetic switches and power control device coils.
- The internal relay contact of the instruments is for alarm or control function. Due to safety, **please must connect to external relays which can stand enough ampere to make sure the safety operation of the instrument.** (Please refer to chapter 3.6 "Illustration of electrical connection")
- There a manufacturer logo usually shows in the display of transmitter, and the illustration of each function in the manual is no longer expressed.

Brief Instruction


Description of set-up settings (see chapter 7 for details)


Press  and  simultaneously to see the overview of the set-up settings now. Then press  if you would like to modify set-up settings. Press keypad according to index of keypad on the screen.

Index of keypad

keypad	Accordingly item	Description
		Back to upper layer
		Choose leftward of change to left page
		Increase digit
		Choose rightward of change to right page
		Decrease digit
		Confirm settings after modifications and then go through next step

Selection of set-up items


keypad	Accordingly item	Description
Mode		Measurement mode, to select Conductivity (Cond.), Resistivity (Res.), Total Dissolved Solids (TDS) or Salinity measurement
Product Adj.		Sample reading adjustment
Temperature		Temperature measurement and compensation, including MTC, PTC100Ω, PTC1KΩ, NTC (4 types total). MTC---Manual temperature compensation, PTC100Ω/PTC1KΩ/NTC--- auto temperature compensation
Compensation		Temperature compensation setting, selection from linear(Lin.), non-linear(Non-Lin.), off-compensation, 3 types
Relay 1		First relay setting, to choose action off or Hi/Lo alarm
Relay 2		Second relay setting, to choose action off or Hi/Lo alarm

Clean		Automatic wash time setting, to choose electrode clean equipment's ON and OFF duration
Analog 1		Current output according to Res, Cond., TDS or Sal. setting range
Clock		Clock setting (When out of power and reboot it, the instrument's time setting will return to the factory pre-setting)
RS-485		RS485 serial interface (Modbus protocol)
Digital Filter		Take every serial 1~60 measurements, average them continuously, and make it as the readings
Black-light		Backlight setting, to set Auto/ON/OFF backlight, brightness, and sensitivity
Contrast		Contrast of screen setting
Logbook		Event recorder logbook (50 data)
Frequency		Power frequency setting
Return		Setting of returning to the measurement mode
Code		Security code of set-up mode. The set-up code is precedential to calibration code, thus it can pass a different security code of calibration.
Language		Available for English, Traditional Chinese, Simplified Chinese

Description of calibration settings (see chapter 8 for details)

Press  and  simultaneously to see the last calibration information. Then press  if you would like to make a new calibration or modify setting of calibration. Press keypad according to index of keypad on the screen.

Index of keypad:

keypad	Accordingly item	Description
		Back to upper layer
		Choose leftward of change to left page
		Increase digit
		Choose rightward of change to right page
		Decrease digit
		Confirm settings after modifications and then go through next step

Selection of calibration items

keypad	Accordingly item	Description
Cell Constant		To adjust the instrument cell constant setting until the value the same with the given cell constant of the sensor
Std. Solution		Use the appropriate standard solution to calibrate the system
Return		Time interval setting of returning to the measurement mode
Code		Security code of calibration mode.

Note

Due to the need for continuous improvement of the transmitter function, we reserve the right to modify the content and the icon of the function. The actual icons and contents are subject to the instrument without notice.

1. Specifications

Model		EC-4310-RS
Measuring modes		Resistivity/Conductivity/TDS/Salinity/Temp.
Ranges	Resistivity	0.00 MΩ·cm~20.00 MΩ·cm
	Conductivity	0.000 μS/cm~2000 mS/cm (depends on selected sensor)in 7 ranges; Auto or Fixed
	Salinity	0.0ppt~70.0ppt (according to IOT)
	TDS	0ppm~19999ppm ; 0.00~199.99 ppt
	Temp.	PT-1000/PT-100: -30.0~200.0° C; NTC-30K: -30.0~130.0° C
Resolutions	Resistivity	0.01 MΩ·cm
	Conductivity	0.001 / 0.01 / 0.1 / 1 μS/cm, 0.01 / 0.1 / 1 mS/cm
	Temp.	0.1° C
Accuracy	Resistivity	±1% (± 1 Digit)
	Conductivity	±1% (± 1 Digit)
	Temp.	± 0.2° C (± 1 Digit), (excluding two-wiring PT100) Equipped with temperature error correction function
Temperature Compensation		Automatic with NTC 30K Ω / PT-1000 /PT-100
		Manual adjustment
Calibration mode		(1) Manual cell-constant adjustment (2) Conductivity standard solution calibration
Ambient Temp.		0~50 °C
Storage Temp.		-20~70 °C
Cell constant		0.01, 0.05, 0.1, 0.5, 10.00 cm ⁻¹ fixed, freely selectable 0.0080~19.99 cm ⁻¹
Temperature coefficient		Linear temperature compensation at 0.00%~40.00%, Non-linear compensation for pure water, and Off-compensation
Display		Large LCM with auto-sense backlight and contrast function
		Text mode: Numerical display
		Chart mode: 3 mins real-time dynamic graph(Res. & Cond. only)
		Trace mode: Set up from 3 mins to four weeks duration of the measured value trend graph(Res. & Cond. only)
Language		Available for English, Traditional Chinese, Simplified Chinese
Analog output 1		Isolated DC 0/4~20mA corresponding to main measurement, max. load 500Ω
Logbook		50 event records
Serial interface		RS-485(MODBUS RTU or ASCII)
Settings	Contact	240VAC, 0.5A max. (recommend)
	Activate	Hi/Lo. Hi/Hi. Lo/Lo selectable two limited programmable, ON/OFF
Wash	Contact	240VAC, 0.5A max. (recommend)
	Time	ON: 0~99min.59sec. / OFF:0~999 hours59min
Power Supply		100~240VAC±10%, 7W Max., 50/60 Hz
Installation		Wall or Pipe or Panel Mounting
Dimensions		144m × 144mm × 115mm (H×W×D)
Cut off Dimensions		138 mm × 138 mm (H×W)
Weight		0.8Kg
Protection		IP 65 (NEMA 4X)

Note: The specifications and appearance of the instrument are subject to change without notice.

2. Assembly and installation


2.1 Transmitter installation:

This Transmitter can be installed through panel mounting, wall mounting and 2" pipe mounting.


Installation of panel mounting:

First, prepare a square hole of 138 x 138mm on the panel box, and then insert the transmitter directly into the panel box. Insert the accessorial mounting bracket from the rear, and make it be fixed into pickup groove.


2.2 Illustration of panel mounting



2.3 Illustration of wall mounting and pipe mounting




Installation of pipe mounting
Fixed with U-shaped pipe clamp.
(Optional, Order Number: 8-34)




Installation of wall mounting
Fixed with 4 x M5 screws


Penetrate the two prepared holes in the rear cover and fix the U-shaped pipe clip, and then install two waterproof squeezed caps (the transmitter's standard accessory kit) into the holes from inner rear cover to prevent from the water vapor.



Sun Shield (Pipe mounting, Optional)
(Order No.: 8-35 + 8-35-1)




Sun Shield (Wall mounting, Optional)
(Order No.: 8-35 + 8-35-2)




Insert the single hole rubber plug into the unused cable gland, and tighten up the cable gland to prevent from the penetration of water vapor.

3. Overview of Conductivity transmitter EC-4310-RS


3.1 Illustration of rear panel



3.2 Illustration of terminal function




3.3 Description of terminal function



- 1 **100~240 AC** : Power supply terminal
- 2
- 3 **WASH** : Wash relay contact for an external relay
- 4
- 5 **REL2** : Second alarm control, the contact for an external relay
- 6
- 7 **REL1** : First alarm control, the contact for an external relay
- 8
- 9 **NC / D-(A)** : None contact
- 10 **4~20mA -terminal / G** : RS-485 output GND
- 11 **4~20mA +terminal / D+(B)** : RS-485 output D+(B)
- 12 **4~20mA -terminal** : Master measure current output terminal -, for an external recorder or PLC control
- 13 **4~20mA +terminal** : Master measure current output terminal +, for an external recorder or PLC control
- 14 **NC** : None contact
- 15 **T/P** : Connect the cell wire of temperature probe
- 16 **CELL4** : The black cell wire or Current electrode 2 °
- 17 **CELL3** : The orange cell wire or Voltage electrode 2
- 18 **CELL2** : The red cell wire or Voltage electrode 1 °
- 19 **CELL1** : The brown cell wire or Current electrode 1 °
- 20 **SHIELD** : The transparent cell wire

3.4 Wiring of cable




3.5 Circuit of cable

	SUNTEX Conductivity Cell			Others
Terminal sign	2-Electrode Cell 8-221/8-222/8-223 4-Electrode Cell 8-241/8-241-01/8-242/8-244	Fixed Cable Resistivity Cell 8-11-3	Fixed Cable Conductivity Cell 8-12-6	Please read the instruction of the cells
SHIELD	Transparent line	Shield line	Shield line	SHIELD
CELL 1	Brown line	Short with transparent line	Short with transparent line	Current electrode 1
CELL 2	Red line			Voltage electrode 1
CELL 3	Orange line	Short with white line	Short with green line	Voltage electrode 2
CELL 4	Black line			Current electrode 2
T/P	Yellow line	Yellow line	Red line	T/P(the other side for CELL 4)


Note: If use other brand's 2-Electrode cell, the circuit of cable is the same with that for 8-11-3 or 8-12-6 cell.

3.6 Illustration of electrical connection



Note: The transmitter built-in miniature relay is necessary to be repaired and replaced by professional technicians. It is recommended to use an external relay (Power Relay) to activate the external equipments.


3.7 Online EC/RC pipe system (Optional)



- Water flow direction
 A : Immersion system in open basin
 B : 1/2" & 3/4" flow-through system
 C : 1/2" pipe mounted system
 D : 3/4" horizontal pipe mounted system
 E : 3/4" side-entry system in vessel
 F : Top-entry system in closed vessel

4. Configuration

4.1 Illustration of front panel



4.2 Keypad

In order to prevent inappropriate operation by others, before the parameter setting and calibration, the operation applies multi-keys, and coding protection if necessary. Description of the key functions is in the following:



: In the parameter set-up mode, pressing this key allows you exit parameter set-up mode and back to Measurement mode.



: In the Calibration mode, pressing this key allows you exit Calibration mode and back to Measurement mode.



: 1. In the parameter set-up mode and Calibration mode, pressing this key to select leftward or change to another page.
2. When adjusting value, press this key to increase the value.



: 1. In the parameter set-up mode and Calibration mode, pressing this key to select rightward or change to another page.
2. When adjusting value, press this key to decrease the value.



: Key for confirmation; pressing this key is essential when modifying data value or selecting the parameter setting items in the window.

4.3 LED indicators:

- WASH** : Washing device operation indicator
- RELAY1** : Controlling of dose feeding operation indicator (Relay 1)
- RELAY2** : Controlling of dose feeding operation indicator (Relay 2)
- B.L.** : Light sensor, the lamp will light or go out as the change of environmental brightness in the automatic display backlit mode.

5. Operation

5.1 Measurement mode:

After all electrical connections are finished and tested, connect the instrument to the power supply and turn it on. The transmitter will automatically enter measurement mode with the factory default settings or the last settings from user.

5.2 Set-up menu:

Please refer to the set-up instructions in Chapter 7. Press  and  simultaneously to enter into set-up menu, and press  to go back to measurement mode.

5.3 Calibration menu:

Please refer to the calibration instructions in Chapter 8. Press  and  simultaneously to enter into calibration menu, and press  to go back to measurement mode.

5.4 Shortcuts:

1. In the measurement mode, if selecting MTC for temperature compensation mode, you may press  and  to adjust MTC temperature value.
2. Under measurement mode, press  continuously for 2 seconds to see the Logbook function directly. Press  key to back to measurement mode.
3. Under measurement mode, press  continuously for 2 seconds to switch the display mode from text mode, trace mode, and real-time chart display mode.

5.5 Default value:

5.5.1 Setting default value:

Measurement mode: Conductivity, Auto-Range

Temperature compensation: NTC 25°C

Temperature Coefficient: Lin, 2.00%

Relay 1: High point alarm: AUTO, SP1= 100.0mS, Hys.=10.0mS

Relay 2: Low point alarm: AUTO, SP2 =10.0 mS, Hys.= 1.00 mS

Wash time: OFF

Analog 1 current output (Cond/Res): 4~20 mA, 0.00~199.9mS

Date & Time: 2014/1/1 00:00:00

RS-485: RTU, 19200, Even, 1, ID:001

Digital filter: 0

Backlight setting: Off

Contrast: 0

Logbook: None

Auto back: Auto, 3 minutes

Code set-up: Off

5.5.2 Calibration default value:

Cal Type: No Cal

Cal Temp: None

Cell Constant: 0.5000

Auto back: Auto, 3 minutes


Code set-up: Off

Note: The factory default of calibration presetting is “No Cal”, and the cell constant setting is “0.5000”. It means that the user has not calibrated the sensor with the transmitter yet. When selecting standard solution to finish calibration, the display shows cell constant of the cell and the value of the standard solution.

6. Measurement display mode


6.1 Text mode

The normal mode is for digit display, the content is as the following illustration. It mainly includes main measurement value and unit, temperature measurement value and unit, temperature compensation mode, and clock display.



6.2 Real-Time chart mode

Real-time chart mode is for dynamic display of real-time graphics. The duration is about three minutes of the recent changes in measured values of the curve. Users can set the mode to its corresponding Cond/Res measuring range (see section 7.4). The smaller the range is set, the higher resolution of the display is. When entering setup or calibration mode and returning to measurement mode, the real-time graphic will be re-updated. When the measured value exceeds a set range of the upper and lower limit, the graphics will be presented in the upper and lower limits dotted line. Real-time chart mode display is shown as below. There are also real-time measurement value, & unit, and temperature value & unit which are displayed in the bottom of the screen. The timeline in real-time graphic is divided into 12 depict, which is describe the range of representatives of each of 1 / 4 minutes (15 seconds).




6.3 Trace mode

The feature of the trace mode is the record duration which can be set by the user (range from three minutes, up to four weeks). The trend graphic records the measurements in the past T time. The trend is recorded by the 60 group structure. Hence, each group of units is recorded in T/60 time interval. The trend line is constructed by all value data which is calculated to the average (Mean Value), maximum (Max Value) and minimum (Min Value) form. When the latest T/60 record shows in the rightmost of the trend graphic, all the previous record will be moved to the left side of the graphic. For example, T is set to 60 hours, then each set of records will be calculated to the average, the maximum, the minimum values after one hour(T/60 = 1), each time interval. Timeline of trends which is divided into 12 depictions showed on the horizontal axis of the display is on behalf of each characterization interval T/12. So, every depiction has 5 (T/60) sets of records. Users can set the corresponding Cond./Res. measuring range in its set-up menu(see section 7.4). The smaller the range is set, the higher resolution of the display is. The trace mode is shown as below. There are also real-time measurement value, & unit, and temperature value & unit which are displayed in the bottom of the screen.


Attention: When the time interval has been reset, the trend in the data will not be retained, it will start a new trace record.

Note: The time display format (XX: XX) (hr: min), for example, appear as four weeks (672:00).



6.4 Warning symbols and text

1. When the clean function is activated, the display shows and twinkles the description, “Clean Running”. At the same time, the ACT indicator LED lights up, and the transmitter automatically turns off Relay 1 and Relay 2 function. After finishing cleaning, the Relay 1 and Relay 2 will automatically back to normal status.
2. When Relay 1/Relay 2 which is set in high setting point is in action, the display shows and twinkles the description, “REL 1-HI/REL 2-HI”, and ACT indicator LED lights up. When Relay 1/Relay 2 which is set in low setting point is in action, the display shows and twinkles the description, “REL 1-Lo/ REL 2-Lo”, and ACT indicator LED lights up.
3. When the Analog 1 current output exceeds the upper/lower limitation, the display twinkles ” S-mA ▲ / S-mA ▼ ” or ” Ω-mA ▲ /Ω-mA ▼ “.




Note: The “HOLD” warning text appears when clean function is activated, or when entering setup menu, or when entering calibration menu. Under HOLD status, the corresponding display and output as follows:


1. Both Relay 1 and Relay 2 cease from action. If enter setting menu or calibration menu under clean status, the instrument will stop clean status automatically.
2. The current output which is corresponding to measurement value remains at the last output value before HOLD status.
3. The last signal output value of RS-485 interface is kept at the last output value before HOLD status.

7. Settings

Block diagram of setting-part 1




Block diagram of setting-part 2



7.1 Entry of set-up menu


In the measurement mode, pressing the two keys  and  simultaneously allows you enter the overview of current setting, and press  to enter the set-up mode to modify the setting if necessary.



7.2 Security code of settings


After entering set-up mode, select “code” item, press  to enter into code procedure. **The code pre-setting is 1111.**

Note: The code of setting mode is prior to the code for calibration. That means that the code of setting mode can be used for the code of calibration mode.



7.3 Language


Enter Language setup menu, select the system language from English, Traditional Chinese and Simplified Chinese



7.4 Mode


7.4.1 Cond. Measurement Mode

Enter setup of “Mode”. Select for “Conductivity (Cond.)”, and select display mode, Auto Range, or Manual selection for 2.000 μ S, 20.00 μ S, 200.0 μ S, 2000 μ S, 20.00mS, 200.0mS or 2000mS.



7.4.2 Resistivity(Res.) measurement mode


Enter setup of Mode, select Resistivity(Res.) measurement mode and select the display mode.



7.4.3 Salinity & TDS Measurement Mode


Enter into Mode setup, select Salinity or TDS for measurement.

TDS : Select the range from 0~19999ppm or 0~199.99ppt and set up the conductivity conversion factor.



7.5 Product Adjustment


Enter setup of product adjustment to make the fine adjustment of the measurement reading. For ultra-pure water application, the function can increase the resolution of cell constant, and it makes users adjust the cell constant through a cell factor in the field. It also allows two decimal of the temperature display which increases the sensitivity of cell constant and temperature change and achieves the fine adjustment of reading up to 0.01Meg ohm. It helps the users to see the small change of reading or trend in ultra-pure water application.



7.6 Temperature

Enter setup of “Temperature” to select temperature compensation mode. Select from NTC(NT30K), PTC1KΩ(PT-1000), PTC100Ω(PT-100) for Auto Temperature Compensation or MTC(Manual adjustment).

Note: Due to two-wiring set-up of temperature circuit, length or thickness of wiring may cause the temperature error between actual temperature & measured temperature when selecting PTC1KΩ or PTC100Ω for temperature compensation. After that, the temperature error can be modified by the next step “Adjust”.



7.7 Temperature Compensation Coefficient

The instrument's reference temperature of temperature compensation presets 25°C, and the temperature compensation coefficient presets 2.00%.


Enter setup of Temperature Compensation Coefficient mode, and select linear (Lin.), non-linear (Non-Lin.), or non-compensated (OFF) according to your measurement need for temperature coefficient. Normally, select linear compensation for conductivity measurement (Cond.), and select non-linear compensation for resistivity measurement.

Temperature Compensation Coefficient (hereinafter referred to as TC): Conductivity of solution increases with rising temperature. The relationship is as follows:

Ct _{ref}	Conductivity at 25°C	Formula 1 : $C_t = C_{tref} \{ 1 + \alpha(T - t_{ref}) \}$
Ct	Conductivity at T°C	
T	Measured solution temperature	Formula 2 : $\alpha = (C_t - C_{tref}) / \{ C_{tref} (T - t_{ref}) \}$
α	Temperature compensation coefficient	


How to get TC of solution:

According to the formulas above, take an example for 0.01MKCl. Set the TC of the instrument to non-compensated (OFF), and control the temperature at 25°C and at 20°C. Ct_{ref} means the measured value at 25°C (Such as C_{t,25} = 1413μS). Ct means the measured value at 20°C (Such as C₂₀ = 1278μS). According to both formulas above, α = 1.91%.




7.8 Relay 1

Enter setup of Relay 1. Select the item to turn on or turn off the relay 1 function. If you select to turn on the relay 1, then select for using relay 1 as “High set-point” alarm or “Low set-point” alarm. Set the value of set-point (SP) and Hysteresis (Hys.). The relationship between parameters can refer to an explanatory diagram of the box (as a high point alarm).




7.9 Relay 2

Enter setup of Relay 2. Select the item to turn on or turn of the relay 2 function. If you select to turn on the relay 2, then select for using relay 2 as “High set-point” alarm or “Low set-point” alarm. Set the value of set-point (SP) and Hysteresis (Hys.). The relationship between parameters can refer to an explanatory diagram of the box (as a low point alarm).




Press to confirm it.




Press or to select for activating REL2 or not. If select OFF, the guide menu goes to setup of clean.

Press to confirm it.





Press or to select Hi point or Lo point alarm of REL2.

Press to confirm it.




Press or to adjust set-point (SP) value. If the measuring range of conductivity measurement is set as AUTO, then it needs to be set unit(μ S/cm or mS/cm), value, and decimal point by order.

Press to confirm it.



Press or to adjust Hysteresis (Hys.) value

Press to confirm it.



Press or to select for activating a test of REL2 or not. If “ON”, the relay 2 is in action, and the “RELAY2” indication light will light up.


Press to confirm it.

Enter “Clean” Setup


7.10 Clean

Enter setup of “Clean” function. Select the icon to turn on or turn off the clean function. If you select “Auto” turning on, then set the timer of the clean function including automatically turning on time and turning off time, and set the Hysteresis value(Hys.).

Note: When the clean function is turned on, if any value is set to be 0, the instrument will automatically turn off this function. When the clean function is activated under measurement mode, there is a “Clean Running” message showing on top of the display. The measured value will be remained at the last measured value before cleaning. If enter setting menu or calibration menu under clean status, the instrument will stop clean status automatically.



Press to confirm it.




Press or to select for activating Clean or not. If not, the guide menu goes to setup of Analog 1.

Press to confirm it.





Press or to adjust the action time. Press to confirm the minute part, and move to adjust the second part. to confirm it.

Press to confirm it.




Press to confirm it.



Press or to adjust Hysteresis (Hys.) value

Press to confirm it.




Press or to select for activating a test of Clean or not. If “ON”, the Clean function is in action, and the “WASH” indication light will light up.

Press to confirm it.

Enter “Analog 1” Setup

7.11 Analog output 1


Enter setup of Analog 1. Select 0~20mA or 4~20mA current output and set the related value to the range of measurement. If the range of measurement is to be set smaller, the resolution of current output is higher. When the measured value exceeds the higher range limit, the current will remain approximately 22mA output. When the measured value exceeds the lower range limit, under 0~20mA mode the current output will remain 0mA output; while under 4~20mA mode the current output will remain approximately 2mA output. The exceptional output value can be used as a basis for failure determination. Under HOLD(measurement) status, the current output maintains the last output value before HOLD status. However, in order to keep convenience of insuring the current setting of an external recorder or of a PLC controller, the current output will be 0/4mA or 20mA under the analog output setup menu.



7.12 Date/Time(Clock)


Enter setup of Date/Time(Clock). Set the “Year”, “Month”, “Date”, “Hour”, and “Minute” time. If you select to turn off the clock function, there will not display clock under measurement mode. The calibration time of calibration record will also show ”OFF” under calibration overview display.

Note: The clock of the EC-4310-RS can be able to function still as out of power supply. If the clock is not working, the cell may be out of power, and then please replace it with 3V CR2025 Li cell.




7.13 RS485 communication

Enter setup of RS485 communications. According to the Modbus protocol, set the transmitting mode, parity, baud rate, stop bit, and ID number. About the detail of Modbus protocol, please refer to Ch9. If under hold status, the measurement signal output maintains the last output value before hold status.




Press to confirm it.




Press or to select RTU or ASCII mode.

Press to confirm it.




Press or to select 9600, or 19200, or 2400 for baud rate.

Press to confirm it.




Press or to select Even, or Odd, or None for parity check.

Press to confirm it.



Press or to select stop bit as 1 bit or 2 bit.

Press to confirm it.



Press or to set the ID number of the transmitter. The valid value is from 1 to 247.


Press to confirm it.

Enter " Sample average of measurements (Digital Filter) " Setup

7.14 Sample average of measurements (Digital Filter)

Enter the setup of Digital filter. You may select the number of sample to be averaged each time to become a reading which is gradually counted in order to increase the stability of measurement.

Note: “0” represents auto setting according to the conductivity measurement.




7.15 Backlight settings

Enter setup of backlight display. According to your need, you can set the brightness of display(-2~2, dark~bright) and sensitivity of the sensitization sensor(-2~2, insensitive~sensitive). Where there is a keystroke, then activate the touch-on backlight function. Regardless of what kind of backlight mode, the touch-on function will activate the backlight. If there is no keystroke for 5 seconds, the display will back to the original backlight setting status.

ON setting: The backlight is always on.


OFF setting: The backlight is off. When there is a keystroke, it enters to the touch-on status.

Auto setting: According to the ambient light, activate or deactivate the backlight. When there is a keystroke, it enters to the touch-on status.




7.16 Contrast settings

Enter setup of display contrast. You can set the contrast of display according to your need. (-2, -1, 0, 1, 2, light to dark)



7.17 Logbook

Enter setup of Logbook. Users may look up the recently important 50 events and error diagnosis records of the transmitter. Definitions please see as following table, before users may read records of logbook through Modbus, they may need to input logic address, 0028H, and read corresponding data, 0029H~002FH. The latest data record is assigned to #1, and the last data record is assigned to #2 and so on.




Events	definitions	Modbus code
Mea mode	Measurement mode	00
Set mode	Setting mode	01
Cal mode	Calibration mode	02
Power On	With power supply	03
Power Off	Out of power supply	04
Cond_mA Over	Current exceeds the upper/lower range	05
Error 1	The readings are unstable under calibration mode	06
Error 2	1.Cell constant value exceeds the upper/lower range 2.The temperature exceeds the limited range	07
Error 3	Error input code	08
Res_mA Over	Current exceeds the limited range	09
Error 5	Malfunction of instrument	10
TDS_mA Over	Current exceeds the limited range	11
Salt_mA Over	The current exceeds the limited range	12
Modbus Write	Modbus demand input	13

7.18 Power frequency (Frequency)


Enter setup of power frequency. You may select power frequency setting of the instrument 50Hz or 60Hz according to the local power frequency.

Note: This setting significantly affects the normal measurement of instrument, thus, be sure to make the setting correctly.




7.19 Return

Enter setup of auto return mode (Return) to set the function that the instrument automatically exit the setup menu after a period of time without pressing any key. The “Manual Exit” means that it needs to exit setup menu manually, while “Auto” means that the display automatically exit the setup menu and back to measurement mode after a period of time without pressing any key.




8. Calibration

Block diagram of Calibration




8.1 Enter calibration setup menu

In the measurement mode, pressing the two keys  and  simultaneously allows you enter the Calibration Information. If you do not need to re-calibrate the measurement system, press  to go back to measurement mode. If you need to re-calibrate the system, press  to enter into the calibration setup menu. (If the calibration time shows “OFF”, it represents that the clock function has been turned off.)



8.2 Security password of calibration (Code)


Select the Code (password) icon after entering calibration setup mode. Select to activate code function or not. **The default Calibration setting code is “1100”.**




8.3 Cell constant calibration

8.3.1 Resistivity (Res.)

Enter setup of cell constant to directly set cell constant. Press  or  to select the preset value to near an appropriate one. There are three sets of preset value (0.01, 0.05, 0.10). Select the most appropriate cell constant value and press  to confirm it and enter to the next screen. At the time, the cell constant starts to twinkle. Press  or  to adjust the cell constant value. Correct the measurement value to known standard solution value by adjusting cell constant, or setting the known cell constant directly. Press  to confirm it.




Press  to confirm it.




According to the cell constant of the resistivity sensor, press  or  to select the nearest preset value.

Press  to confirm it.




Under MTC temperature mode, press  or  to adjust temperature value. If under ATC temperature mode (PTC or NTC), the temperature value is read automatically, and the instrument directly goes to next screen.

Press  to confirm it.




According to labeled cell constant of the resistivity sensor, press  or  to adjust to the corresponding value. Press  to confirm it.

Press  to confirm it.




8.3.2 Conductivity (Cond.)

Enter setup of cell constant to directly set cell constant. Press  or  to select the preset value to near an appropriate one. There are four sets of preset value (0.01, 0.10, 0.50, 10.00). Select the most appropriate cell constant value and press  to confirm it and enter to the next screen. At the time, the cell constant starts to twinkle. Press  or  to adjust the cell constant value. Correct the measurement value to known standard solution value by adjusting cell constant, or setting the known cell constant directly. Press  to confirm it.




Press  to confirm it.




According to the cell constant of the resistivity sensor, press  or  to select the nearest preset value.

Press  to confirm it.




Under MTC temperature mode, press  or  to adjust temperature value. If under ATC temperature mode (PTC or NTC), the temperature value is read automatically, and the instrument directly goes to next screen.

Press  to confirm it.




According to labeled cell constant of the conductivity sensor, press  or  to adjust to the corresponding value. Press  to confirm it.



Enter "Standard solution calibration" mode

8.4 Standard solution calibration (Std. Solution)


Applying known standard solution for calibration is only suitable for conductivity measurement mode. Press or to select from preset standard solution value. There are three preset values from 84.0 μ S/cm, 1413 μ S/cm, to 12.88mS/cm. After selecting proper preset value, put the cleaned conductivity sensor into standard solution, and press to enter the calibration screen. At the time, the conductivity value can be adjusted according to standard solution value. Press to initiate the calibration. The display shows the sign , and it starts the auto calibration procedure. After finishing calibration, the display automatically shows the cell constant after calibration. Press to exit. *Note:* there is a temperature range limit within 0 $^{\circ}$ C ~31 $^{\circ}$ C for “Std. Solution Calibration” . If exceeding the range, please refer to “8.3.2 Cond. Cell Constant Mode” for calibration.



8.5 Return

Enter setup of auto return mode (Return) to set the function that the instrument automatically exits the setup menu after a period of time without pressing any key. The “Manual Exit” means that it needs to exit calibration setup menu manually, while “Auto” means that the display automatically exits the calibration setup menu and returns back to measurement mode after a period of time without pressing any key.


Note: The return function of setup menu and calibration setup menu are independent settings.



9. MODBUS protocol and instructions

9.1 Communication connection

The RS-485 communication port of the transmitter features electronic isolation protection and lightning protection, and it provides isolated ground solution. It is allowed to use normal twisted-pair (segregation double-stranded twisted pair cable) cable for connection. All devices are in contact with a positive connecting point D+(B) of the double-stranded twisted-pair cable all together, and another line will be connected with all the negative contacts D-(A), and the isolated shield wire must be connected to ground(GND). When we talk about communication in the laboratory, the stand-alone master-slave communication is relatively simple. Hence, it is allowed to consider using the normal cable instead. However, there should be strictly in accordance with the requirements of industrial engineering construction. Wiring diagram is as follows:



Note:

1. The RS-485 interface of the transmitter has a protective earth terminal. When communicate with the RS-485, there should use with solution ground to eliminate risk of safety.
2. It is allowed to use an 120 ohm impedance matching resistors at terminal equipment in the transmission lines (D +(B), D-(A)) ends across to effectively reduce or eliminate signal reflection.

Note: there are three possible situations resulting to failure connection:

- a. Open circuits: the signal cable has open circuits.
- b. Short circuits: the insulation that is insufficient between signal cables causes short circuits.
- c. Idle-bus: there is no data transmission in the Controlbus.

Based on the previous three situations resulting in unknown state of Controlbus's voltage, the receiver accepts the unexpected signals. Therefore, in some harsh environment like multi-transmitter connection, the Controlbus needs the terminator to avoid reflection of baud rate, and it needs pull-high resistor, pull-low resistor, and biasing circuits made up of V_{Bus} as the block diagrams showing above. Besides, it makes sure that the free voltage between transmission line D+(B) and D-(A) is available for maintaining the completeness of the signals. Due to not each environment being suitable to fixed resistor and V_{Bus} , therefore, users must pay attention to the settings. Some parts of connecting instruments (as parts of RS-485 or modules) provide the terminator, pull-high resistor, pull-low resistor, and settings of V_{Bus} . Please refer to the operation manuals of the connecting instruments.

3. Without repeaters, the RS-485 network cannot exceed a maximum of 32 nodes. The maximum communication transmission distance of RS-485 is up to 1200 meters. For long distance transmission, it is recommended to apply cables which are dedicatedly design for RS-485.
4. When communication, all the equipments of the network should be maintained in the same transfer mode, baud rate, parity consistent. And each of the device address cannot be the same, so as not to conflict resulted in the normal network communications.
5. The Modbus command of the transmitter can only access 50 registers. If it exceeds the length, then it returns abnormal message.
6. The waiting time which a slave instrument response to a master machine is different according to each model. Generally, it shall be longer than 0.5 second. (Some models may require a longer waiting-responding time, please note whether the operation manual specified.)

9.2 Modbus address and command table

The following information is the Modbus address and command table. Users who apply a PLC or HMI systems to communicate with this instrument need to pay particular attention to whether if the actual delivery address decrease 1 to deliver. If the above situation happens, it is necessary to add 1 to correspond to this table. For example, the temperature of the table address is 0037H (hexadecimal) or 55 (decimal), if the PLC or HMI system delivers the address which has been decreased 1 and then transmit, then the user must enter the 0038H (hexadecimal) or 56 (decimal) in order to correspond to the correct temperature address code which affected by the PLC or HMI system.

Function Code : 03H, 06H, 10H Modbus response (setup parameter)

Logic address (Hex)	R/W	Item	Number of Byte	Information type	Description of data transmission	Default value	Note
0000H		None					
0001H	R	Equipment's ID	2	USHORT	1-247	1	
0002H	R	Transmitter model	6	USHORT	ASCII Code	EC4310	
0005H	R	Communication protocol	2	USHORT	0: RTU	0	
					1: ASCII		
0006H	R	Serial transmission speed (Baud rate)	2	USHORT	0: 2400	3	
					1: 4800		
					2: 9600		
					3: 19200		
0007H	R	Parity	2	USHORT	0: None	1	
					1: Even		
					2: Odd		
0008H	R/W	Real-time clock*	12	USHORT	Second	2014-01-01, 00:00:00	
0009H	R/W			USHORT	Minute		
000AH	R/W			USHORT	Hour		
000BH	R/W			USHORT	Day		
000CH	R/W			USHORT	Month		
000DH	R/W			USHORT	Year		
000EH	R/W	Code setting*	2	USHORT	Code setting	1111	
000FH	R/W	Temperature mode*	2	USHORT	0: MTC	2	
					1: PTC-1K Ω		
					2: NTC		
					3:PT100 Ω		

0010H	R/W	Clean relay*	2	USHORT	0: OFF	0		
				USHORT	1: AUTO			
0011H	R/W		2	USHORT	ON.S: 0-5999	0	Second	
0012H	R/W		2	USHORT	OFF.H: 0-999	0	Hour	
0013H	R/W		2	USHORT	OFF.M: 0-59	0	Minute	
0014H	R/W		2	USHORT	Hys.S: 0-5999	0	Second	
0015H	R/W		Relay 1 *	2	USHORT	0: OFF	1	
						1: AUTO		
0016H	R/W			2	USHORT	0: Hi	0	
						1: Lo		
0017H	R/W	4		FLOAT	SP1	100.0mS	Data affected by parameter unit	
0019H	R/W	4		FLOAT	Hys1	10.0mS		
001BH	R/W	Relay 2 *		2	USHORT	0: OFF	1	
						1: AUTO		
001CH	R/W			2	USHORT	0: Hi	1	
						1: Lo		
001DH	R/W		4	FLOAT	SP2	10.0mS	Data affected by parameter unit	
001FH	R/W		4	FLOAT	Hys2	1.0mS		
0021H	R/W		Backlight Brightness*	2	USHORT	0: AUTO	2	
						1: ON		
						2: OFF		
0022H	R/W			2	SHORT	2: Highest brightness	0	
		SHORT			1: high brightness			
		SHORT		0: Standard				
		SHORT		-1: Low brightness				
		SHORT		-2: Lowest brightness				
0023H	R/W	Backlight Sensitivity*		2	SHORT	2: Highest Sensitivity	0	
					SHORT	1: High Sensitivity		
			SHORT		0: Standard			
			SHORT		-1: Low Sensitivity			
			SHORT		-2: Lowest Sensitivity			

0024H	R/W	Sample average of measurements (Digital Filter)*	2	USHORT	0-60	5	
0025H	R/W	Product adjustment*	2	USHORT	0: OFF	0	
0026H			4	FLOAT	0.7000~1.3000		
0028H	R/W	Event Number	2	USHORT	1~50	1	
0029H	R	Event time	12	USHORT	Second	2014-01-01 00:00:00	
002AH	R			USHORT	Minute		
002BH	R			USHORT	Hour		
002CH	R			USHORT	Day		
002DH	R			USHORT	Month		
002EH	R			USHORT	Year		
002FH	R	Event code	2	USHORT	0~13	0	
0030H	Factory reserved						

Note 1 : The actions without * sign only support for function code 03H. The actions with * sign support function code 03H, 06H, 10H.

Note 2 : FLOAT is a 32-bit IEEE 754 format. The above table, for an example, is divided into two 16-bit register data transmission. The back 16-bit register(CC CD) will be transferred first, and then the first 16-bit register (41 C8) will be transferred later. Every 16-bit format is high-bit in the front and low-bit in the post. For example, the temperature now is 25.1°C. The 16-bit of FLOAT data(Hexadecimal) will show 41 C8 CC CD. The transmission order is CC CD 41 C8. For detail description, please refer to Ch 9.3 Modbus example description.

Note3 : USHORT means unsigned short integer.

Function code: 03H Modbus response (measurement parameter)

Logic address (Hex)	R/W	Item	Number of Byte	Information type	Description of data transmission	Default value	Note
0031H	R	Measurement status	2	USHORT	0: Hold Status 1: Measurement	1	
0032H	R	Parameter unit	6	CHAR	μ S/cm mS/cm M Ω -cm ppm ppt	Conductivity Auto	ASCII code

0035H	R	Cond. measurement	4	FLOAT	Cond. measurement		
0037H	R	Temperature measurement	4	FLOAT	Temperature measurement		
0039H-003FH	Factory reserved						
0040H	R	Cell constant	4	FLOAT	Cell constant	0.5000	
0042H	R	Calibration Time	2	USHORT	Minute	2014-01-01 00:00	
0043H	R		2	USHORT	Hour		
0044H	R		2	USHORT	Day		
0045H	R		2	USHORT	Month		
0046H	R		2	USHORT	Year		
0047H-0050H	Factory reserved						

Function code: 01H · 05H Modbus response (dispersion parameter)

Logic address (Hex)	R/W	Item	BIT	Description	Default value	Note
0070H	R	LO Alarm	1	Contact on	0 (Contact off)	
0071H	R	HI Alarm	1	Contact on	0 (Contact off)	
0072H	R	mA too high	1	Contact on	0 (Contact off)	
0073H	R	mA too low	1	Contact on	0 (Contact off)	
0074H	R	Exceed temp. range	1	Contact on	0 (Contact off)	
0075H	R	Exceed Cond. range	1	Contact on	0 (Contact off)	
0076H	R	RLY1 Action	1	Contact on	0 (Contact off)	
0077H	R	RLY2 Action	1	Contact on	0 (Contact off)	
0078H	R	Clean Action	1	Contact on	0 (Contact off)	
0079H-008FH	Factory reserved					

9.3 Modbus example description(ex: function code 03H)

The following description takes the temperature reading(0037H) as an example. Set the temperature at the transmitter at MTC 25.1°C, and confirm that host and sub-machine communication format settings are correct. The host according to the following left table to send commands, and then to get the response from sub-machine according to following right table. This example shows the message transmission function code 03H data format. If under other function code, the logic mode is the same.

ASCII Mode:

Request		Response	
Message Framing	Hex	Message Framing	Hex
ID, Address	01	ID, Address	01
Function code	03	Function code	03
Starting Address Hi	00	Byte Count	04
Starting Address Lo	37	Register value Hi	CC
No. of Registers Hi	00	Register value Lo	CD
No. of Registers Lo	02	Register value Hi	41
LRC	C3	Register value Lo	C8
		LRC	56

RTU Mode:

Request		Response	
Message Framing	Hex	Message Framing	Hex
ID, Address	01	ID, Address	01
Function code	03	Function code	03
Starting Address Hi	00	Byte Count	04
Starting Address Lo	37	Register value Hi	CC
No. of Registers Hi	00	Register value Lo	CD
No. of Registers Lo	02	Register value Hi	41
CRC Check Lo	75	Register value Lo	C8
CRC Check Hi	C5	CRC Check Lo	65
		CRC Check Hi	5A


Note: FLOAT is a 32-bit IEEE 754 format. The above table, for an example, is divided into two 16-bit register data transmission. The back 16-bit register(CC CD) will be transferred first, and then the first 16-bit register (41 C8) will be transferred later. Every 16-bit format is high-bit in the front and low-bit in the post. For example, the temperature now is 25.1°C. The 16-bit of FLOAT data(Hexadecimal) will show 41 C8 CC CD. The transmission order is CC CD 41 C8.

10. Error messages (Error code)


Messages	Reason	Dispositions
Error1	The reading is unstable when calibration	<ol style="list-style-type: none"> 1. Replace with new standard solution 2. Maintain the electrode or replace a new electrode, and make another calibration
Error2	<ol style="list-style-type: none"> 1. Cell constant of the electrode exceeds the upper or lower limit 2. Exceed temperature range 	<ol style="list-style-type: none"> 1. Replace with new standard solution 2. Maintain the electrode or replace a new electrode, and make another calibration
Error3	Wrong password ERROR CODE	Re-enter a password
Error5	Serious error that does not permit any further measuring	Please call service engineer.

11. Installation of cells


11.1 Appearance of cells




8-221/ 8-222 cell dimensions



8-223 cell dimensions




8-241 / 8-241-01 / 8-242 cell dimensions




8-244 cell dimensions

11.2 Correct installation




11.3 Incorrect installation


11.3.1 Insufficient immersion: The installation is easy to result in stagnant water inside the cell and thus lead to measurement error.



11.3.2 Insufficient water flow: The installation is prone to error measurement due to insufficient water flow.



11.3.3 Insufficient immersion: The installation is easy to result in stagnant water inside the cell and thus lead to measurement error.



Appendix: Calibration Solution

°C	Conductivity	84 μ s@25°C	1413 μ S@25°C	12.88mS@25°C
0			776	7.15
5	65		896	8.22
10	67		1020	9.33
15	68		1147	10.48
16	70		1173	10.72
17	71		1199	10.95
18	73		1225	11.19
19	74		1251	11.43
20	76		1278	11.67
21	78		1305	11.91
22	79		1332	12.15
23	81		1359	12.39
24	82		1386	12.64
25	84		1413	12.88
26	86		1440	13.13
27	87		1467	13.37
28	89		1494	13.62
29	90		1521	13.87
30	92		1548	14.12
31	94		1575	14.37



SUNTEX INSTRUMENTS CO., LTD.

13F, No. 31, Lane 169, Kangning St.,
Xizhi Dist., New Taipei City, Taiwan (R.O.C.)
Tel: 886-2-2695-9688
Fax: 886-2-2695-9693
e-mail: suntex@ms1.hinet.net

www.suntex.com.tw/en