



Description of the Interface for S and SI Balances (Summit)

Operating Instructions

Contents

- Intended Use 3**
- Configuring the Interface 3**
- Data Output Functions 4**
 - Data Output Format 4
 - Data Input Format 4
 - Pin Assignment Chart 9

Intended Use

Your balance is equipped with an interface port for connection to a computer or other peripheral device. You can connect a computer to change, start and/or monitor the functions of the balance and the application programs.

Features

Type of interface: Serial interface

Operating mode: Full duplex

Standard: RS-232

Transmission rates:

600, 1200, 2400, 4800, 9600

and 19,200 baud

Parity: odd, even, none

Number of data bits: 7 or 8 bits

Character format:

1 start bit, 7-bit ASCII, parity, 1 or 2 stop bits

Handshake:

For 2-wire interface: software (XON/XOFF)

For 4-wire interface: hardware (CTS/DTR)

Data output format of the balance:

16 or 22 characters

Factory Settings

Transmission rate:

1200 baud (menu code 1. 5. 1. 4)

Parity: *ODD* (1. 5. 2. 3)

Stop bits: *1 STOP* bit (1. 5. 3. 1)

Handshake:

HANDSHK. Hardware Handshake (1. 5. 4. 2)

Operating mode: *PRINTER* (1. 5. 6. 2)

Printing: *MAN.WITH.* Manual after stability (1. 6. 1. 2)

Preparation

See »Pin Assignments« and »Pin Assignment Chart«

Configuring the Interface

Parameter Settings (Menu)

Please refer to the installation and operating instructions supplied with your balance.

Data Output Functions

Data Output Format with 16 Characters

Display segments that are not activated are output as spaces.

The type of character that can be output depends on the character's position:

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
or	+			D	D	D	D	D	D	D	*	U	U	U	CR	LF
or	—				*	*	*		
or	*		*	*	*	*	*	*	*	*						

*,	Space	CR:	Carriage return
D:	Digit or letter	LF:	Line feed
U:	Unit symbol	.,	Decimal point

Special Codes

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	*	*	*	*	*	*	*	*	*	*	*	*	*	*	CR	LF
or							H	i	g	h						
or							L	o	w							
or				C	a	l	.	E	x	t	.					

*,	Space	High:	Overload
Cal. Ext.:	Calibration, external	Low:	Underload

Error Codes

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
				E	r	r	*	#	#	#	*	*	*	*	CR	LF
				A	P	P	.	E	R	R ¹⁾	*	*	*	*	CR	LF
				D	I	S	.	E	R	R ¹⁾	*	*	*	*	CR	LF
				P	R	T	.	E	R	R ¹⁾	*	*	*	*	CR	LF

*,	Space	## #:	Error number
----	-------	-------	--------------

¹⁾ See "Troubleshooting Guide" in the installation and operating instructions supplied with your balance

Example: Output of the weight value +123.56 g

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	+	*	*	*	1	2	3	.	5	6	*	g	*	*	CR	LF
	+	*	*	1	2	3	.	5	[6] ¹⁾	g	*	*	CR	LF

Position 1: Plus or minus sign or space

Position 2: Space

Position 3–10: Weight with a decimal point; leading zeros = space

Position 11: Space

Position 12–14: Unit symbol or space

Position 15: Carriage return

Position 16: Line feed

Data Output Format with 22 Characters

When data is output with an ID code, the 6-character code precedes the 16-character string described above. The code identifies the subsequent value.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
I	I	I	I	I	I	+	*	D	D	D	D	D	D	D	D	*	U	U	U	CR	LF
	*	*	*	*	*	—			*	*	*		
						*		*	*	*	*	*	*	*	*						

I: ID code character

U: Unit symbol¹⁾

*: Space

CR: Carriage return

D: Digit or letter

LF: Line feed

Example:

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
N						+				1	2	3	.	5	6	*	g	*	*	CR	LF
N						+			1	2	3	.	5	[6] ¹⁾	g	*	*	CR	LF

¹⁾ Identification of Non-Verified Digits

To have non-verified digits (when “e # d”) automatically identified on the printout,

set the following parameters: Communication: *PRINTER* (menu code 1. 5. 6. 2)

Non-verified digits are marked by square brackets [].

SBI mode:

When the SBI mode is active (menu code 1. 5. 6. 1), non-verified digits are not marked.

To mark non-verified digits, configure the auxiliary device as needed.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
S	t	a	t	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	CR	LF
											H i g h										
											L o w										
									C a l . E x t .												

Error Codes

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
S	t	a	t	*	*	*	*	*	E	R	R	*	#	#	#	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	A	P	P	.	E	R	R ¹⁾	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	D	I	S	.	E	R	R ¹⁾	*	*	*	*	CR	LF
S	t	a	t	*	*	*	*	*	P	R	T	.	E	R	R ¹⁾	*	*	*	*	CR	LF

1) See "Troubleshooting Guide" in the installation and operating instructions supplied with your balance



Commands (Data Input Format)





You can connect a computer to your balance to send commands via the balance interface port for controlling balance functions and applications. The commands sent are control commands and may have different formats. Control commands consist of up to 13 characters. Each character must be transmitted according to the settings configured in the operating menu for data transmission.

Format for Control Commands

Format 1:	Esc	!	CR	LF		
Format 2:	Esc	!	#	_	CR	LF

Esc: Escape (optional) CR: Carriage return
 !: Command character LF: Line feed (optional)
 _: Underline

Command character	Format 1: Meaning
!	
K	Ambient conditions: very stable
L	Ambient conditions: stable
M	Ambient conditions: unstable
N	Ambient conditions: very unstable
O	Block keys
P	 key (print, auto print; activate or block)
R	Unblock keys
S	Restart/self-test
T	 key
W	Calibration/adjustment (depending on the menu setting) ¹⁾
Z	Internal calibration/adjustment*

Command character	Format 2: Meaning
!#	
f0_	Function key 
f1_	Function key 
f2_	Function key 
s3_	 key
x1_	Print balance/scale model
x2_	Print weighing cell serial number
x3_	Print software version

* = only on models with built-in motorized calibration weight

¹⁾ May be inaccessible on verified balances

Synchronization

During data communication between the balance and a connected device (computer), messages consisting of ASCII characters are transmitted via the interface. For error-free data communication, the parameters for baud rate, parity, handshake mode and character format must be the same for both units.

You can set these parameters in the Setup menu so that they match those of the connected device. You can also define parameters in the balance to make data output dependent on various conditions. The conditions that can be configured are listed in the descriptions of the application programs.

If you do not connect a peripheral device to the interface port, this will not generate an error message.

Handshake

The balance interface has transmit and receive buffers. You can define the handshake parameter in the Setup menu:

- Hardware handshake (CTS/DTR)
- Software handshake (XON, XOFF)

Hardware Handshake

With a 4-wire interface, 1 more character can be transmitted after CTS (Clear to Send).

Software Handshake

The software handshake is controlled via XON and XOFF. When a device is switched on, XON must be transmitted to enable any connected device to communicate.

Data Output by Print Command

The print command can be transmitted by pressing **PRINT** or by a software command (Esc P).

Automatic Data Output

Activate the “auto print” operating mode to have data output to the interface port without a print command. You can have data output automatically at defined display update intervals, with or without the stability parameter. The length of a print interval depends on the operating menu settings for *AMBIENT* (ambient conditions)

(menu code 1. 1. 1. x) and *AUT.EYCL.* (time-dependent autom. printing; menu code 1. 6. 3. x).

If you activate the auto print setting, data will be transmitted immediately the moment you turn on the balance. In the operating menu, you can define whether automatic printing can be stopped by pressing **PRINT**.

Pin Assignment Chart

Hardware Handshake

With a 4-conductor interface, 1 or 2 characters can be transmitted after CTS.

These connections must be made when the balance is connected through the RS-232C port.

Pin Assignment Chart for Data Interface

Summit Series	Standard RS-232
Balance 9-pin port	9-pin connector
RxD 2	3 TxD
TxD 3	2 RxD
DTR 4	4 DTR
Signal ground 5	5 Signal ground
CTS 8	8 CTS

Summit Series	Standard RS-232
Balance 9-pin port	25-pin connector
RxD 2	2 TxD
TxD 3	3 RxD
DTR 4	20 DTR
Signal ground 5	7 Signal ground
CTS 8	5 CTS

Copyright by Denver Instrument GmbH, Goettingen, Germany.
All rights reserved. No part of this publication may be reprinted
or translated in any form or by any means without the prior
written permission of Denver Instrument GmbH.

The status of the information, specifications and illustrations in
this manual is indicated by the date given below. Denver Instrument
GmbH reserves the right to make changes to the technology, fea-
tures, specifications, and design of the equipment without notice.
Status: July 2006, Denver Instrument GmbH, Goettingen, Germany.

Europe, Asia and Australia:

**Denver Instrument GmbH
Robert-Bosch-Breite 10
37079 Goettingen, Germany
Tel: +49-551-20977-30
Fax: +49-551-20977-39**

Internet:

www.denverinstrument.com

U.K. and Ireland:

**Denver Instrument Company
Denver House, Sovereign Way
Trafalgar Business Park
Downham Market
Norfolk PE38 9SW England
Tel: +44-136-63862-42
Fax: +44-136-63862-04**

North and South America:

**Denver Instrument Company
1401 17th Street, Suite 750
Denver, Colorado 80202
1-800-321-1135
Tel: +1-303-431-7255
Fax: +1-303-423-4831**