



MS103
0303
0002

MACNAUGHT®

The experts in fluid technology

Positive Displacement Flowmeters

———— M40 series instruction manual ————



M40 Mechanical meter • From serial No. CXXXX

To the owner

Please take a few minutes to read through this manual before installing and operating your meter. If you have any problems with the meter, refer to the maintenance and trouble shooting sections of this manual.

This manual contains connection and operating instructions for meters with mechanical displays. If you need further assistance, contact your local representative or distributor.

This Flow Meter has incorporated the Oval rotor principal into its design. This has proven to be a reliable and highly accurate method of measuring flow. Exceptional repeatability and high accuracy over a wide range of fluid viscosities and flow rates are features of the Oval rotor design. The low pressure drop and high pressure rating means Oval rotor flow meters are suitable for both gravity and pump (in line) applications.

Flow meters are available in either aluminium or 316 stainless steel. Standard rotors are made from PPS (Polyphenylene Sulfide Resins) with optional 316 stainless steel rotors available for both stainless steel and aluminium models.

Mechanical displays have a resettable batch totaliser and non-resettable accumulative totaliser.

Important Information



PLEASE READ THIS INFORMATION CAREFULLY BEFORE USE!

Before use, confirm the fluid to be used is compatible with the meter. Refer to the industry compatibility charts, or consult your local representative for

advice.

To prevent damage from dirt or foreign matter it is recommended that a Y or Basket type 60 mesh strainer be installed as close as possible to the inlet side of the meter.

Note: When a strainer is installed it should be regularly inspected and cleaned. Failure to keep the strainer clean will dramatically effect flow


meter performance.

Note: To prevent damage caused by air purge slowly fill the system with fluid.

To prevent pressure build up turn off the pump at the end of each day.

Operation

When fluid passes through the meter, rotors turn. The gear located on top of one of the rotors drives the mechanical registers gear train which provides an accurate readout.





Installation

- 1] It is recommended that when setting up pipework for meter installations a bypass line be included in the design. This provides the facility for a meter to be removed for maintenance without interrupting production. (See Fig.1)
- 2] Use thread sealant on all pipe threads. For flanged versions appropriate companion flanges and gaskets are required.
- 3] For pump applications ensure pipe work has the appropriate working pressure rating to match the pressure output of the pump.
- 4] Install a wire mesh strainer (Y or basket type) as close as possible to the inlet side of the meter.
- 5] Ensure that the meter is installed so that the flow of the liquid is in the direction of the arrows embossed on the meter body.
- 6] The meter can be installed in any

orientation as long as the meter shafts are in a horizontal plane. (Refer to Fig.2 for correct installation) The register assembly may be orientated to suit the individual installation.

Note: Incorrect installation can cause premature wear of meter components.

- 7] Do not over tighten meter connections.
- 8] **It is important that after initial installation you fill the line slowly, high speed air purge could cause damage to the rotors.**
- 9] Test the system for leaks.
- 10] Check the strainer for swarf or foreign material, after the first 200 litres check periodically, particularly if the flow rate decreases.



Service Instructions

Disassembly

Ensure that the fluid supply to the meter is disconnected, and the line pressure is released before disassembly. Refer to the exploded parts diagram on pages 13 and 15 for item numbers.

- 1] Remove the four screws (Item 17) located on the face of the register. Then remove the face plate cover including register assembly.
- 2] Remove the four register mounting screws (Item 15). Then remove the lower half of the register housing.
- 3] Remove the six cover plate screws (Item 12) and remove the cover plate (Item 11).
- 4] Remove the eight meter cap screws (Item 5) and remove the meter cap (Item 4).
- 5] Remove rotors (Item 3).

Reassembly

- 1] Clean all components before reassembly.
- 2] Before reassembly check the condition of the rotors (Item 3). Replace if necessary.
- 3] Replace the rotor (with the gear) on the short shaft in the housing then place the 2nd rotor onto the shaft so as the rotors are at 90° to each other. (Refer Fig 3). Check rotor operation by turning either of the rotors. If the rotors are not in mesh correctly or do not move freely remove one of the rotors and

replace it correctly at 90° to the other rotor. Recheck the operation of the rotors.


- 4] Inspect the gears (Item 6) in the meter cap (Item 4) for wear. (Replace if required, refer to spare parts on page 10).
- 5] Replace the o-ring (Item 2) into the groove in the meter cap, if the o-ring has been distorted or is damaged in any way replace it with a new part.
- 6] Replace the meter cap, making sure the locating pins line up with the holes in the meter cap and the gear on the rotor meshes correctly with the gear in the meter cap (Item 4). Insert the allen screws (Item 5) and tighten in the sequence 1, 4, 2, 5, 3, 6.
- 7] Inspect the bevel gear (Item 13), o-ring (Item 10), and output gear (Item 7) for wear or damage. (Replace faulty components if necessary).
- 8] Replacement of output shaft, bush and seal.

Disassembly

- a. Remove the bevel gear.
- b. Remove the circlip and push out the output shaft assembly, including washer.
- c. Remove the seal.
- d. Carefully press out the output shaft bush (If required).

Assembly

- a. Carefully press the new output shaft bush into place (Use Loctite Primer 747, as per instructions,



Rotors must be at 90° to each other.

5

followed by sealant Loctite 262).

b. Insert a new seal into the groove of the output shaft bush.

c. Replace the output gear and washer and replace the circlip to lock the output gear shaft into place.


d. Replace the bevel gear (Item 13) and tighten the grub screw onto flat face of shaft.

- 9] Place the o-ring (Item 10) into the groove in the cover plate (Replace the o-ring seal if required).
- 10] Place the cover plate onto the meter. Replace the cover plate screws and tighten the six cap head screws (Item 12) firmly.
- 11] Place the lower cover plate of the register into position. Replace the four screws (Item 15) and tighten.
- 12] Position the register correctly on top of the lower register cover. Replace the four screws (Item 17) and tighten.
- 13] Test the meter by turning the rotors with a finger or by applying low air pressure (No more than a good breath) to one end of the meter, before returning meter to the line.

Meter Trouble Shooting

TROUBLE SHOOTING GUIDE		
TROUBLE	CAUSE	REMEDY
Fluid will not flow through meter	a] Foreign matter blocking rotors b] Line strainer blocked c] Damaged rotors d] Meter connections over tightened e] Fluid is too viscous	a] Dismantle meter, clean rotors (Strainer must be fitted in line) b] Clean strainer c] Replace rotors (Strainer must be fitted in line) d] Re-adjust connections e] See specifications for maximum viscosity
Reduced flow through the meter	a] Strainer is partially blocked b] Fluid is too viscous	a] Clean strainer b] See specifications for maximum viscosity
Meter reading inaccurate	a] Fluid flow rate is too high or too low b] Fluid is too viscous c] Excess wear caused by incorrect installation	a] See "specifications" for minimum and maximum flow rates b] Bleed air from system c] Check meter body and rotors. Replace as required. Refer to installation instructions
Fluid flows but no reading on meter	a] Bevel gear is loose on shaft b] Rotor drive gear is damaged c] Transmission gears damaged d] Register gears damaged	a] Tighten grub screws b] Replace rotor c] Replace gears d] Replace register assembly
Fluid leaks into register	a] Seal won or damaged on the cover plate	a] Replace seal (Check seal compatibility with fluid)

Heating Jackets




Complete Assembly: HJ400-1 - Aluminium BSP
HJ400-2 - Aluminium NPT

Spare Parts Listing:

HJ100-1:	MS320 MS135B OR812	SHCS Screws Jacket Body - Aluminium/BSP "O" Ring
HJ100-2:	MS320 MS135N OR812	SHCS Screws Jacket Body - Aluminium/NPT "O" Ring

Meter Parts Listing



KEY:

u Indicates recommended Spare Parts to stock
Bold text indicates Stainless Steel Model parts.


Item No.	No. Off.	Rec. Parts	Part or Set (Order from this column only)	Part Description
1	1		MS192B	Meter Body 1 1/2" BSP (Aluminium)
1	1		MS192N	Meter Body 1 1/2" NPT (Aluminium)
1	1		MS190B	Meter Body 1 1/2" BSP (Stainless Steel)
1	1		MS190N	Meter Body 1 1/2" NPT (Stainless Steel)
1	1		MS192F	Meter Body 1 1/2" ANSI 150lb Flange (Aluminium)
1	1		MS192D	Meter Body 1 1/2" DIN16 Flange (Aluminium)
1	1		MS190F	Meter Body 1 1/2" ANSI 150lb Flange (S/Steel)
1	1		MS190D	Meter Body 1 1/2" DIN16 Flange (S/Steel)
2	1	u	BS243S	"O" Ring (NBR)
2	1	u	BS243ES	"O" Ring (EPDM)
2	1	u	BS243TES	"O" Ring (Teflon)
2	1	u	BS243VS	"O" Ring (Viton)
3	2	u	MS92S	Rotors PPS (Polyphenylene Sulfide Resins) brass hub
3	2	u	MS92-1S	Rotors (316 Stainless Steel)
3	2	u	MS92-2S	Rotors PPS with Stainless Steel hub
3	2	u	MS92TS	High Temperature Rotors (PPS)
3	2	u	MS92HS	High Viscosity Rotors (PPS)
3	2	u	MS92HS-2S	High Viscosity Rotors (PPS) S/Steel hub
3	2	u	MS92TS-2S	High Temperature Rotors (PPS) with Stainless Steel hub
3	2	u	MS92HTS	High Viscosity/High Temperature Rotors (PPS)
3	2	u	MS92HTS-2S	High Viscosity/High Temperature Rotors (PPS) S/Steel hub
4	1		MS222S	Meter Cap Liters (Aluminium)
4	1		MS222US	Meter Cap US Gallons (Aluminium)
4	1		MS223S	Meter Cap Liters (Stainless Steel)
4	1		MS223US	Meter Cap US Gallons (Stainless Steel)
5	6	u	MS116S	Meter Cap Screws (Standard)
5	6	u	MS180S	Meter Cap Screws (Stainless Steel)
6	1	u	MS295S	Complete Gear Set - Liters
6	1	u	MS317S	Complete Gear Set - US Gallons
7	1	u	MS77S	Output Gear & Shaft Assembly
8	1	u	MS78S	Coverplate Seal/Bush Set Standard
8A	1	u	OR42CS	Solvent o-ring (Chemraz)
9	1	u	MS78C	Coverplate Seal/Bush Set Solvent
9A	1	u	N7-007S	Standard o-ring (NBR)
10	1	u	BS145S	O-ring (NBR)

Meter Parts Listing

Item No.	No. Off.	Rec. Parts	Part or Set (Order from this column only)	Part Description
10	2	u	BS145ES	O-ring (EPDM)
10	2	u	BS145TES	O-ring (Teflon)
10	2	u	BS145VS	O-ring (Viton)
11	1		MS99S	Coverplate (Aluminium) includes bush
11	1		MS99-1S	Coverplate (Stainless Steel) includes bush
12	6	u	MS312S	Coverplate Screws - Litre Model
12	6	u	MS313S	Coverplate Screws (Stainless Steel)- Litre Model
13	1	u	MS83S	Bevel Gear Set
14	1		MS140RS	Bottom Register Coverplate
15	4	u	MS111S	Mounting Screws
16	1	u	MS141RS incl 15 & 17	Register Assembly complete - Litres
16	1	u	MS141RUS incl 15 & 17	Register Assembly with complete - US Gallons
17	4	u	MS129S	Register Body Screws
18	1		Customer to specify model	Legend Plate (Not Pictured) includes Hammer Screws
19	1		MS37	Warning Label (Not Pictured)

Meter Dimensions

MEC40 Mechanical Meter Dimensions



Meter Specifications

Flow Ranges

(Liter per minute/US Gallons per minute)

Above 5 Centipoise 10 to 250/ 2.6 to 66

Below 5 Centipoise 15 to 235/ 4 to 62

Accuracy of Reading +/- 1%

Maximum Viscosity* 1000 Centipoise

Maximum Operating Pressure 1800kPa / 260 PSI / 18 BAR

Maximum Operating Temperature* 80°C / 176°F (Stainless Steel Models 120°C / 248°F)

Meter conforms to PED 97/23/EC Cat1.

* Unless High Viscosity or High Temperature Rotors are fitted

Warranty

Macnaught Industries ('Macnaught') warrants that the Products will be free from any defects caused by faulty material or workmanship for a period of twelve (12) months from the date of sale of the Products to the enduser (the 'Warranty Period') PROVIDED THAT, during the Warranty Period:

1. Macnaught receives notice setting out full details of any defect in any product and details of the time and place of purchase of the Product: and
2. the enduser, at its own cost returns the Product to the nearest authorised Macnaught Service Centre.

Macnaught shall, as its option repair or replace and Product found defective by its inspection or refund the price paid by the enduser for that Product.

Macnaught's liability and the enduser's rights under this warranty shall be limited to such repair, replacement or refund and, in particular, shall not extend to any direct, special, indirect or consequential damage or losses of any nature.

Note:

This warranty does not form part of, nor does it constitute, a contract

between Macnaught and the enduser. It is additional to any warranty given by the seller of the Products and does not exclude, limit, restrict or modify the rights and remedies conferred upon the enduser, or the liabilities imposed on the seller, by any statute or other laws in respect of the sale of the Product.



MACNAUGHT PTY. LTD
ACN 000 460 551
41-49 Henderson Street, Turella Sydney NSW Australia 2205
PO Box 90 Arncliffe, Sydney NSW Australia 2205
Telephone +61 2 9567 0401 Facsimile +61 2 9597 7773
Email sales@macnaught.com.au - Web Site www.macnaught.com.au

