



MS85FA
0502
0002

# MACNAUGHT®

## The experts in fluid technology

---

### Positive Displacement Flowmeters — MIO Encoder series instruction manual —



MIO Encoder series meter • From serial No. CXXXX

---

---

# To the owner

---

Thank you for purchasing a Macnaught M Series Flow Meter. Please take a few minutes to read through this manual before installing and operating your meter. If you have any problems with the meter, refer to the maintenance and trouble shooting sections of this manual.

This manual contains connection and operating instructions for the M10 Encoder Series meter. If you need further assistance, contact your local

Macnaught representative or contact Macnaught by telephone or fax for advice.

The Macnaught M Series Flow Meter has incorporated the oval rotor principal into its design. This has proven to be a reliable and highly accurate method of measuring flow. Exceptional repeatability and high accuracy over a wide range of fluid viscosities and flow rates are features of the M Series flow meter design. The

low pressure drop and high pressure rating means the M Series flow meter is suitable for both gravity and pump (in line) applications.

The Macnaught M Series flow meters are available in either aluminium or 316 stainless steel. Standard rotors are made from PPS (Polyphenylene Sulfide Resins) with optional 316 stainless steel rotors available for both stainless steel and aluminium models.

---

## Important Information

---



### **PLEASE READ THIS INFORMATION CAREFULLY BEFORE USE!**

Before use, confirm the fluid to be used is compatible with the meter (refer to the Macnaught fluid compatibility chart), or consult your local Macnaught representative for advice.

To prevent damage from dirt or foreign matter, Macnaught recommends a Y or Basket type 60 mesh strainer be installed as close as possible to the inlet side of the meter (if required contact Macnaught for further information).

Note: When a strainer is installed it should be regularly inspected and cleaned. Failure to keep the strainer clean will dramatically effect flow meter performance.

To prevent damage to the meter slowly fill the system with fluid (this will prevent damage caused by air purge).

Note: Failure to do this could damage the meter.

For pump applications, turn off the pump at the end of each day.

# Installation

1] Macnaught recommends that when setting up pipework for meter installations a bypass line be included in the design. This provides the facility for a meter to be removed for maintenance without interrupting production. (See Fig.1)

2] Use thread sealant on all pipe threads. For flanged versions 1" ANSI 150lb or DIN16, appropriate companion flanges and gaskets are required.

3] For pump applications ensure pipe work has the appropriate working pressure rating to match the pressure output of the pump. The flow meter maximum working pressures are;

1" aluminium or stainless steel Mechanical meter series 3450kPa/34.5Bar/500PSI.

1" flanged stainless steel or aluminium Mechanical meter series. See appropriate ANSI/DIN flange rules

4] Install a wire mesh strainer (Y or basket type) 60 mesh as close as possible to the inlet side of the meter.

5] Ensure that the meter is installed so that the flow of the liquid is in the direction of the arrows embossed on the meter body.

6] The meter can be installed in any orientation as long as the meter shafts are in a horizontal plane. (Refer to Fig.2 for correct installation)

**Note: Incorrect installation can cause premature wear of meter components.**

7] Do not over tighten meter connections.

8] **It is important that after initial installation you fill the line slowly, high speed air purge could cause damage to the rotors.**

9] Test the system for leaks.

10] Check the strainer for swarf or foreign material, after the first 200 litres check periodically, particularly if the flow rate decreases.




Fig. 1





Fig. 2

# Operation

When fluid passes through the meter, the encoder giving a pulse output. rotors turn. The gear located on top of one of the rotors drives the mechanical registers gear train which then drives



# Service Instructions

## Meter Disassembly

Ensure that the fluid supply to the meter is disconnected, and the line pressure is released before disassembly. Refer to the exploded parts diagram, Figure 5, and page 5 and 6 for item numbers.

- 1] Remove the four screws (Item 16) located on the face of the Encoder adaptor. Then remove the Encoder adaptor.
- 2] Remove the six cover plate screws (Item 12) and remove the cover plate (Item 11).
- 3] Remove the six meter cap screws (Item 5) and remove the meter cap (Item 4).
- 4] Remove rotors (Item 3).

## Meter Reassembly

- 1] Clean all components before reassembly.
- 2] Before reassembly check the condition of the rotors (Item 3). Replace if necessary.
- 3] Replace the rotor (with the gear) on the short shaft in the housing then place the 2nd rotor onto the shaft so as the rotors are at 90° to each other. (Refer Fig 3). Check rotor operation by turning either of the rotors. If the rotors are not in mesh correctly or do not move freely remove one of the rotors and replace it correctly at 90° to the other rotor. Recheck the operation of the rotors.

- 4] Inspect the gears (Item 6) in the meter cap (Item 4) for wear. (Replace if required, refer to spare parts on page 5).
- 5] Replace the o-ring (Item 2) into the groove in the meter cap, if the o-ring has been distorted or is damaged in any way replace it with a new part.
- 6] Replace the meter cap, making sure the locating pins line up with the holes in the meter cap and the gear on the rotor meshes correctly with the gear in the meter cap (Item 4). Insert the meter cap screws (Item 5) and tighten in the sequence 1, 4, 2, 5, 3, 6.
- 7] Inspect the drive dog (Item 13), o-ring (Item 10), and output gear (Item 7) for wear or damage. (Replace faulty components if necessary).


## Output shaft Seal Replacement

### Disassembly

- a. Remove the drive dog (Item 13).
- b. Remove the circlip and push out the output shaft assembly, including washer.
- c. Remove the seal.
- d. Carefully press out the output shaft bush (If required).

### Assembly

- a. Carefully press the new output shaft bush into place (Use Loctite Primer 7471, as per instructions, followed by sealant Loctite 680).
- b. Insert a new seal into the groove of the output shaft bush.
- c. Replace the output gear and washer and replace the circlip to




lock the output gear shaft into place.  
d. Replace the drive dog (Item 13) and tighten the grub screw onto flat face of shaft.

- 9] Place the o-ring (Item 10) into the groove in the meter cap (Item 4) (Replace the o-ring seal if required).
- 10] Place the cover plate onto the meter. Replace the meter cap screws and tighten the six cap head screws (Item 12) firmly.
- 11] Place the Encoder adaptor into position. Making sure the drive dogs engage correctly with each other. Replace the four screws (Item 16) and tighten.
- 12] Test the meter by turning the rotors with a finger or by applying low air pressure (No more than a good breath) to one end of the meter, before returning meter to the line.

# Meter Trouble Shooting

TROUBLE SHOOTING GUIDE		
TROUBLE	CAUSE	REMEDY
Fluid will not flow through meter	<b>a]</b> Foreign matter blocking rotors <b>b]</b> Line strainer blocked <b>c]</b> Damaged rotors <b>d]</b> Meter connections over tightened <b>e]</b> Fluid is too viscous	<b>a]</b> Dismantle meter, clean rotors (Strainer must be fitted in line) <b>b]</b> Clean strainer <b>c]</b> Replace rotors (Strainer must be fitted in line) <b>d]</b> Re-adjust connections <b>e]</b> See specifications for maximum viscosity
Reduced flow through the meter	<b>a]</b> Strainer is partially blocked <b>b]</b> Fluid is too viscous	<b>a]</b> Clean strainer <b>b]</b> See specifications for maximum viscosity
Meter reading inaccurate	<b>a]</b> Fluid flow rate is too high or too low <b>b]</b> Fluid is too viscous <b>c]</b> Excess wear caused by incorrect installation	<b>a]</b> See "specifications" for minimum and maximum flow rates <b>b]</b> Bleed air from system <b>c]</b> Check meter body and rotors. Replace as required. Refer to installation instructions
Fluid flows but no reading on meter	<b>a]</b> Drive Dog is loose on shaft <b>b]</b> Rotor drive gear is damaged <b>c]</b> Transmission gears damaged <b>d]</b> Encoder is damaged	<b>a]</b> Tighten grub screws <b>b]</b> Replace rotor <b>c]</b> Replace gears <b>d]</b> Replace Encoder assembly
Fluid leaks from Encoder adaptor	<b>a]</b> Seal worn or damaged on the cover plate	<b>a]</b> Replace seal (Check seal compatibility with fluid)

# Heating Jackets



**Complete Assembly:** HJ100-1 - Aluminium BSP  
HJ100-2 - Aluminium NPT

## Spare Parts Listing:

<b>HJ100-1:</b>	MS320 MS134B OR692	SHCS Screws Jacket Body - Aluminium/BSP "O" Ring
<b>HJ100-2:</b>	MS320 MS134N OR692	SHCS Screws Jacket Body - Aluminium/NPT "O" Ring

# Meter Parts Listing





Fig. 5

Item No.	No. Off.	Rec. Parts	Part or Set (Order from this column only)	Part Description
1	1		MS188B	Meter Body 1" BSP (Aluminium)
1	1		MS188N	Meter Body 1" NPT (Aluminium)
<b>1</b>	<b>1</b>		<b>MS186B</b>	<b>Meter Body 1" BSP (Stainless Steel)</b>
<b>1</b>	<b>1</b>		<b>MS186N</b>	<b>Meter Body 1" NPT (Stainless Steel)</b>
1	1		MS188F	Meter Body 1" ANSI 150lb Flange (Aluminium)
1	1		MS188D	Meter Body 1" DIN16 Flange (Aluminium)
<b>1</b>	<b>1</b>		<b>MS186F</b>	<b>Meter Body 1" ANSI 150lb Flange (S/Steel)</b>
<b>1</b>	<b>1</b>		<b>MS186D</b>	<b>Meter Body 1" DIN16 Flange (S/Steel)</b>
2	1	u	BS235s	"O" Ring (NBR)
2	1	u	BS235Es	"O" Ring (EPDM)
2	1	u	BS235TEs	"O" Ring (Teflon)
2	1	u	BS235Vs	"O" Ring (Viton)
3	2	u	MS72S	Rotors PPS (Polyphenylene Sulfide Resins) Brass hub
<b>3</b>	<b>2</b>	<b>u</b>	<b>MS72-1S</b>	<b>Rotors (316 Stainless Steel) with SS Hub</b>
<b>3</b>	<b>2</b>	<b>u</b>	<b>MS72-2S</b>	<b>Rotors PPS with Stainless Steel hub</b>
3	2	u	MS72TS	High Temperature Rotors (PPS) Brass Hub
3	2		MS72TS-2S	High Temperature Rotors (PPS) with SS Hub
3	2	u	MS72HS	High Viscosity Rotors (PPS) with Brass Hub
3	2	u	MS72HS-2S	High Viscosity Rotors (PPS) S/Steel Hub
<b>3</b>	<b>2</b>	<b>u</b>	<b>MS72-1S</b>	<b>High Viscosity Rotors (SS) with Stainless Steel hub</b>
3	2	u	MS72HTS	High Viscosity/High Temp. Rotors (PPS) Brass Hub
3	2	u	MS72HTS-2S	High Viscosity/High Temperature Rotors (PPS) S/Steel hub
4	1		MS75S	Meter Cap Liters (Aluminium)
4	1		MS75US	Meter Cap US Gallons (Aluminium)
<b>4</b>	<b>1</b>		<b>MS251S</b>	<b>Meter Cap Liters (Stainless Steel)</b>
<b>4</b>	<b>1</b>		<b>MS251US</b>	<b>Meter Cap US Gallons (Stainless Steel)</b>
5	6	u	MS114S	Meter Cap Screws (Standard)
<b>5</b>	<b>6</b>	<b>u</b>	<b>MS200S</b>	<b>Meter Cap Screws (Stainless Steel)</b>
6	1	u	MS294S	Complete Gear Set - Liters
6	1	u	MS316S	Complete Gear Set - US Gallons
7	1	u	MS77S	Output Gear & Shaft Assembly
8	1	u	MS78S	Coverplate Seal/Bush Set Standard
8A	1	u	OR42Cs	Solvent o-ring (Chemraz)
9	1	u	MS78C	Coverplate Seal/Bush Set Solvent
9A	1	u	N7-007s	Standard O-ring (NBR)
9A	1	u	E7-007s	O-ring (EPDM)
9A	1	u	V7-007s	O-ring (Viton)



# Meter Parts Listing

Item No.	No. Off.	Rec. Parts	Part or Set (Order from this column only)	Part Description
10	1	u	BS145s	O-ring (NBR)
10	1	u	BS145Es	O-ring (EPDM)
10	1	u	BS145TEs	O-ring (Teflon)
10	1	u	BS145Vs	O-ring (Viton)
11	1		MS99S	Coverplate (Aluminium) includes bush
11	1		<b>MS99-1S</b>	<b>Coverplate (Stainless Steel) includes bush</b>
12	6	u	MS312S	Coverplate Screws
12	6	u	<b>MS313S</b>	<b>Coverplate Screws (Stainless Steel)</b>
13	1	u	MS246s	Drive Dog
14	1		MS408	Encoder Aadaptor
15	1		MS407s	Encoder
16	4		MS411s	Adaptor screw set
17	1		MS146	Grub Screw

## Encoder details



**PLEASE READ THIS INFORMATION  
CAREFULLY BEFORE USE!**

The encoder (Item 15, refer Figure 5) is an Optical Incremental shaft Encoder. It has a 1000 pulses per revolution resolution output. The output is an open collector with 3 phases (A, B and Z) that can function on a 5 to 12 Volts DC power supply.

Optical encoders are delicate instruments and should be treated with care. Shock loads and incorrect electrical connection will lead to Encoder damage.

To avoid electrical interference use quality shielded cable to connect the encoder to the recording instrument,

ensure the cable shield is grounded, as shown in wiring diagram below. The maximum allowable transfer distance for open collector encoders is 50 metres.

To avoid damage to the encoder please observe the manufactures electrical specifications, wiring table & wiring diagram shown below.


### Electrical Specifications

Resolution	1000 pulses per rev.
Power Supply	DC5V -5% ~ DC12V +5%
Current Consumption	50mA Maximum
Output Form (Open Collector)	
Maximum Allowable Output Voltage	40V
Maximum Sink Current	30 mA
Maximum Response Frequency	200 kHz
Operating Temperature range	-10°C ~ +70°C
Encoder Protection	IP50
Maximum signal transfer distance	50 metres


### Wiring Table

Lead Colour	Function
Red	DC + 5 ~ 12V
Black	GND
Yellow	Z channel output
White	GND
Blue	A channel output
Green	B channel output
Brown	-
Orange	-

### Wiring Diagram



### Wiring Diagram



Note: The above voltage waveform can be obtained by loading RL as shown in the figure on the left.

# Meter Specifications

<b>Flow Ranges</b>	(Liter per minute/US Gallons per minute)
<b>Above 5 Centipoise</b>	6 to 120/ 1.6 to 32
<b>Below 5 Centipoise</b>	10 to 100/ 2.6 to 26
<b>Accuracy of Reading</b>	+/- 1%
<b>Maximum Viscosity</b>	1000 Centipoise
<b>Maximum Operating Pressure</b>	3450 kPa / 500 PSI / 34.5 BAR
<b>Maximum Operating Temperature</b>	70°C / 158°F (For Stainless Steel & Aluminium meters)
<b>Pulses rate</b>	1000 Pulses/Litre, 1000 Pulses/US Gallon

## Warranty

Macnaught Industries ('Macnaught') warrants that the Products will be free from any defects caused by faulty material or workmanship for a period of twelve (12) months from the date of sale of the Products to the enduser (the 'Warranty Period') PROVIDED THAT, during the Warranty Period:

1. Macnaught receives notice setting out full details of any defect in any product and details of the time and place of purchase of the Product: and

2. the enduser, at its own cost returns the Product to the nearest authorised Macnaught Service Centre.

Macnaught shall, as its option repair or replace any Product found defective by its inspection or refund the price paid by the enduser for that Product.

Macnaught's liability and the enduser's rights under this warranty shall be limited to such repair, replacement or refund and, in particular, shall not extend to any direct, special, indirect

or consequential damage or losses of any nature.

Note:

This warranty does not form part of, nor does it constitute, a contract between Macnaught and the enduser. It is additional to any warranty given by the seller of the Products and does not exclude, limit, restrict or modify the rights and remedies conferred upon the enduser, or the liabilities imposed on the seller, by any statute or other laws in respect of the sale of the Product.



MACNAUGHT PTY. LTD  
ACN 000 075 785  
41-49 Henderson Street, Turella Sydney NSW Australia 2205  
PO Box 90 Arncliffe, Sydney NSW Australia 2205  
Telephone +61 2 9567 0401 Facsimile +61 2 9597 7773  
Email sales@macnaught.com.au - Web Site www.macnaught.com.au



Quality  
Endorsed  
Company

ISO 9001 Lic 8602  
Standards Australia