

DCT7088



PORTABLE DIGITAL CORRELATION TRANSIT TIME ULTRASONIC FLOWMETER

USER MANUAL

Formerly

Thermo Polysonics

P/N 1-0561-007 Rev B (02/03)



USER MANUAL

DCT7088 Portable Transit Time Ultrasonic Flowmeter FIRMWARE VERSIONS 6.00 ONWARD FEBRUARY 2003 REV. B

NOTICE

Read this manual before working with the product. For personal and system safety and for optimum performance, make sure you thoroughly understand the contents before installing, using, or maintaining your transit time instrument.

For equipment service needs outside the United States contact your nearest Thermo representative. Within the United States, the Thermo Service Department is your single-point contact for all Thermo equipment service needs. If at any time you are not sure what to do, you have a question about using the product, or you have a service or support request, call the center at (713) 272-0404. This contact is your fastest link to quick and complete answers about any Thermo product or service.

Thermo Electron Corporation Process Instruments Division 9303 W. Sam Houston Pkwy S. Houston, TX 77099 Phone: (713) 272-0404 Fax: (713) 272-5388 Web: www.thermo.com

Acknowledgements for product names used in this manual belong to the following companies:

Dow Corning[®] is a registered trademark of Dow Corning Corporation.

Excel® for Windows® is either a registered trademark or trademark of Microsoft Corporation.

IBM® is either a registered trademark or a trademark of International Business Machines, Inc.

Krautkramer® is a registered trademark of Agfa-Gevaert Group.

Sil-Glyde® is either a registered trademark or a trademark of American Grease Stick Company.

TABLE OF CONTENTS

1.	Product Overview	[,]	1
	1.1 Introduction	'	1
	1.2 Theory of Operation	'	1
	1.3 Transit Time Accuracy	:	2
	1.4 Ordering	:	3
	1.5 Technical Specifications	:	3
	1.5.1 Performance	(3
	1.5.2 Functional	:	3
	1.5.3 Physical	4	4
	1.6 External Features	,	4
	1.7 Breakout Box Components	!	5
	·		
2.	Wiring the Current Loop	(6
3.	Configuring & Operating the Flowmeter	•	7
	3.1 The Keypad & Display		7
	3.1.1 Components		7
	3.1.2 Display Contrast & Backlight		7
	3.2 Direct Menu Access		7
	3.3 Using the Arrow Keys to Access Menus	9	9
	3.4 Flowmeter Configuration Using Setup Menus	9	9
	3.5 Quick Setup Configuration	1(0
	3.6 Primary Displays	12	2
	3.6.1 Flow/Net Totalizer (00)	12	2
	3.6.2 Flow/Velocity (01)	12	2
	3.6.3 Flow/Positive Totalizer (02)	12	2
	3.6.4 Flow/Negative Totalizer (03)	1:	3
	3.6.5 Signal Strength/Low Signal Cutoff (04)	1:	3
	3.7 Additional Setup Menus Within the PIPE Submenu*	1;	3
	3.8 Additional Setup Menus Within the LINER Submenu*	14	4
	3.9 Additional Setup Menus Within the FLUID Submenu*	14	4
	3.10 Additional Setup Menus Within the FLOW Submenu*	1	5
	3.11 Additional Setup Menus Within the TOTAL Submenu*	16	6
	3.12 Additional Setup Menus Within the OPTIONS Submenu*	1	7
	3.13 Additional Setup Menus Within the CALIBR Submenu*	19	9
	3.13.1 Zero Set Calibration	20	0
	3.13.1.a Zero Flow Set Method	20	0
	3.13.1.b Manual Zero Set	2	1
	3.13.2 Scale Factor Calibration	2	1
	3.13.3 Other CALIBR Submenu Options	2	2
	3.14 Additional Setup Menus Within the 4-20mA Submenu*	2	2
	3.15 Additional Setup Menus Within the ALARMS Submenu*	2	3
	3.15.1 Programming the Alarm	24	4
	3.15.2 Viewing Alarms	2	5
	3.16 Additional Setup Menus Within the DATA LOG Submenu*	2	5
	3.17 Additional Setup Menus Within DIAGNOSTICS Submenu*	2	7
	3.18 Additional Setup Menus Within PRINT Submenu*	2	7

4. Wiring & Installing the Transducers	29
4.1 Wiring	29
4.2 Site Selection & Preparation	29
4.3 Spacing & Mounting the Transducers	31
4.4 Transducer Mounting Methods	33
4.4.1 V Method	33
4.4.2 W Method	34
4.4.3 Z Method	34
4.4.4 WV and WW Methods	37
4.5 Small Pipe Applications	38
5. Emergency Overrides & Master Erase	40
5.1 Emergency Overrides	40
5.2 Performing a Master Erase	40
6. Flowmeter Maintenance & Troubleshooting	41
6.1 Replacing the Fuse	41
6.1.1 Flowmeter Fuse	41
6.1.2 Breakout Box Fuse	41
6.2 Charging the Printer Battery	41
6.3 Charging the Flowmeter	42
6.4 Replacing Sonic Coupling Compound	42
6.5 Troubleshooting & Support	43
6.5.1 General	43
6.5.2 Local Representative Support	43
6.5.3 Service & Returns	43
6.5.4 Upgrades	44
6.6 Warranty Statement	44
Appendix A: Pipe Schedules	45
Appendix B: Fluid Properties	49
B.1 Fluid Sound Velocities & Kinematic Viscosities	49
B.2 Clean Water Sound Speed Versus Temperature	62
B.3 Relationship Between Specific Gravity, Viscosity, & Sound Velocity for Petroleum Products 6	63
Appendix C: Monitoring & Downloading Datalogs Using D-Link	64
C.1 Installing D-Link	64
C.2 Establishing Communications with a Flowmeter	64
C.3 Monitoring Datalogs	65
C.4 Saving & Loading Datalogs	66

1. PRODUCT OVERVIEW

1.1 Introduction

The DCT7088 Digital Correlation Transit Time Flowmeter is manufactured by Thermo Electron Corporation. This microprocessor-based instrument measures the flow of clean, homogeneous liquids (liquids without large concentrations of suspended particles or gasses such as air bubbles). The flowmeter is noninvasive, which means that it measures flow from outside the pipe. Its transducers can be mounted to a pipe within a matter of minutes, and flow measurements may be made without interrupting the flow or modifying pipework.

The DCT7088 can be configured using an integral keypad for entering variables such as pipe size, pipe material, wall thickness, and fluid type (refer to Section 3, page 7). The flowmeter can also be remotely configured and monitored via the RS232 interface mode using the D-Link data link utility (refer to Appendix D, page 64). Another alternative to flowmeter configuration is to use the UltraScan utility which also graphically analyzes the signal in a Microsoft[®] Windows[®] environment (UltraScan manual provided on PolyCD).

1.2 Theory of Operation

Sound waves travel in fluids at a specific velocity depending on the type of fluid. If the fluid is moving, the sound wave travels at a velocity equal to the sum of the speed of sound in the fluid and the velocity of the fluid itself relative to the transducer. A sound wave traveling in the same direction as the fluid flow (down-stream) will arrive sooner than a sound wave traveling against the flow (upstream). A transit time flowme-ter operates by measuring both the absolute travel time of each sound wave and the difference in time required for the waves to travel between an externally mounted downstream and upstream transducer (Figure 1.2-A, below). Based on the transit time of the 2 sound waves, the flowmeter calculates the average fluid velocity.



FIGURE 1.2-A: TYPICAL TRANSIT TIME SYSTEM

Once the differential transit time is calculated, several additional variables must be taken into consideration. The overall velocity of the fluid is actually made up of many individual local velocities that vary according to their distance from the pipe wall. The velocities in the center of the pipe are higher than the velocities near the pipe wall. The combination of these individual velocities for a specific type of fluid within a specific pipe yield a velocity distribution known as the flow profile (Figure 1.2-B, page 2), which is a function of the Reynolds number. By properly configuring the flowmeter, the effects of the flow profile are taken into consideration when calculating the mean fluid velocity. The flowmeter then multiplies this velocity by the pipe's cross-sectional area to obtain volumetric flow.



1.3 Transit Time Accuracy

Noninvasive ultrasonic measurements are subject to a variety of effects that can influence measurement accuracy. All ultrasonic instruments are velocity measuring devices and only infer volumetric flow from the operator-entered parameter of pipe inside diameter (ID). When this value is squared to get cross-sectional area, a 1% error yields a 2% error in volumetric flow. In practice, commercially fabricated pipe seldom has ID consistency much tighter than 1%, and unless the pipe to be measured has been accurately measured, this uncertainty is not reducible through instrument calibration.

The more sophisticated transit time flowmeters incorporate flow profile corrections to compensate for the pipe's cross-sectional velocity profile with a changing Reynolds number. However, this requires that the operator knows the inside roughness of the pipe to be measured. The instrument may infer a roughness if none is entered by the operator, but that is only an estimate based on the characteristics of new pipe. Pipes can, of course, accumulate deposits which may not only reduce the ID, but affect the roughness as well. Errors on the order of 2% as a result of this phenomenon are not uncommon.

While other factors may influence instrument accuracy to a lesser extent, the issues described above are the major elements of pipe dependency upon absolute instrument accuracy. While calibration on a reference flow loop under known conditions is a useful exercise to determine the accuracy potential of an instrument, it is not a guarantee of absolute accuracy on different pipes under field conditions.

1.4 Ordering

The table below describes ordering information for a standard DCT7088 flowmeter as well as available options.

MODEL NUMBER				
Series: Digital Correlation Transit Time Flowmeters				
DCT7088 = DCT7088, RS232 digital interface with UltraScan signal analysis and configuration program				
Battery Duration				
$1 = 8 \text{ hours}^1$ $2 = 16 \text{ hours}^3$				
Transducer Cable Length				
16A = 16 ft $(5 \text{ m})^1$ XXXXA = increments of 10 ft (3 m) up to 1000 ft (305 m)				
Additional Options				
0704/0188 = Ultrasonic Thickness Gauge (UTG), English units 0704/0187 = UTG, metric units 22334-0001 = Thermal printer kit				
Typical Model Number: DCT7088-1-B-16A				
¹ standard				

TABLE 1: ORDERING INFORMATION

1.5 Technical Specifications

1.5.1 Performance

Flow range:	0 to 40 ft/s (0 to 12 m/s)
Accuracy:	+/-1% of velocity or +/-0.05 ft/s (+/-0.0152 m/s), typical, digital output
Sensitivity:	0.001 ft/s (0.3 mm/s) at any flow rate, including zero
Linearity:	+/-0.1% of scale, digital output
Pipe size:	1 to 200 in (25 mm to 5 m)
Fluid:	homogeneous liquids without gas bubbles

1.5.2 Functional

Outputs:	4-20 mA (into 1000 ohms), 12-bit, isolated, loop- or self- powered RS232 serial interface				
Power supply:	built-in lead acid gel battery providing 8 hours continuous operation (standard) OR 16 hours continuous operation (optional)				
Keypad:	19-key with tactile action				
Display:	40-character, 2-line, alphanumeric, backlit LCD				
Datalogger:	40,0000 points, time stamped; programmable in 1-second intervals				
Programming:	via UltraScan utility (supplied with flowmeter) OR integral keypad				
Temperature Range:	Transducers: -40° to +212° F (-40° to +100° C) optional high temperature transducers available				
	<i>Transmitter:</i> -5° to +140° F (-20° to +60° C)				

...1.5 Technical Specifications continued

1.5.3 Physical

Transmitter:	NEMA 6 (IP67), waterproof against accidental immersion; splashproof with lid
	open
Transducers:	encapsulated design with standard 16 ft (5 m) cable length
Weight:	approximately 11 lbs (4.9 kg) with 8-hour battery;
-	approximately 15 lbs (6.8 kg) with 16-hour battery

1.6 External Features



Components

Description

- Printer port: provides output for optional external thermal printer; connects to special cable which has 3-pin round connector on flowmeter end and DB9 connector on printer end
- ON/OFF keys
- Battery Low light: activates approximately 7 or 14 hours of operation (depending on battery type); automatic shutdown after approximately 1 additional hour
- 4 Charging light
 - Instrument on light
- 6 Fuse: 3-A, 250 V; protects flowmeter from battery overcurrent or short circuits
- 7 Liquid crystal display (LCD): displays configuration selections, flow rate, totalized flow, etc.
- 8 Keypad: use to enter configuration parameters and control flowmeter functions
- 9 Downstream transducer connector
- 10 Upstream transducer connector
- 11 Breakout box interface connector: connects flowmeter to breakout box

1.7 Breakout Box Components



Components

Description

#

1 2

3

4

5

6 7

- AC power cable
- DC power output cable
- DC power input connector: connects DC power output cable to flowmeter
- 4-20 mA output terminals
- Printer charger cable
- RS232 serial port
- Breakout box interface connector: provides connections for DC power input from battery charger/AC adapter, for DC output cable for charging batter, for RS232 serial port, and for 4-20 mA current loop output terminals
- 8 7-pin circular connector: connects breakout box to flowmeter

2. WIRING THE CURRENT LOOP

The 4-20 mA current loop module has an input terminal and an output terminal, which are indicated on a label on the inside of the flowmeter door. The current loop output is rated for a loop resistance of up to 1 k ohms and is isolated for up to 5 kV when loop-powered.

The 4-20 mA module is shipped with the current loop self-powered. Switch the module to loop power by moving a jumper on the module. Current loop modules which are loop-powered must be driven from an external power supply. In this case the flowmeter acts as a passive 2-wire transmitter.



Prevent possible electrical shock and/or damage to the meter-disconnect power PRIOR to removing back cover of the breakout box and disconnect the breakout box from the flowmeter and battery charger/AC adapter.

To connect the current loop:

- 1. Ensure the loop powering option is correct.
- 2. Locate the jumpers on the upper right corner of the module. Refer to Figure 2.1-A (below) to change the jumper settings.
- 3. Refer to Figure 2.1-B (below) for the self-powered option or Figure 2.1-C (below) for the loop-powered option.



FIGURES 2.1-A (LEFT), 2.1-B (RIGHT, TOP), 2.1-C (RIGHT, BOTTOM)

3. CONFIGURING & OPERATING THE FLOWMETER

3.1 The Keypad & Display

The keypad provides access to the microprocessor for flowmeter configuration. During operation, the instrument's 40-character LCD indicates flow rate and totalizer values.

3.1.1 Components



Components

1 LCD

Description

2 Numeric keys: **0** through **9** and decimal (.)

- 3 Arrow keys: for scrolling up, down, left, right
- 4 **ENTER** key: operates like the Return (Enter) key on a computer
- 5 **ERASE** key: deletes last value entered; in most setup and diagnostic menus, accesses Main Menu; accesses Menu 00 (flow rate and net totalizer display) if pressed twice
- 6 **MENU** key: provides access to setup and diagnostic menus

FIGURE 3: KEYPAD & DISPLAY FEATURES

3.1.2 Display Contrast & Backlight

The display is backlit for ease of viewing in low-light conditions. In order to save battery life, the backlight shuts off automatically after several minutes have passed without a keypad entry. The display has a variable contrast setting, and you may need to adjust the contrast on the display as ambient temperature changes:

- 1. Press **MENU** followed by the ± (plus/minus) key.
- 2. LCD CONTRAST appears on the display with a bar indicating current contrast setting.
- 3. Press **LEFT** or **RIGHT ARROW** keys to adjust the contrast.
- 4. Press ENTER when complete.

3.2 Direct Menu Access

The unique 2-digit address (reference Table 2, page 8) for each setup and diagnostic menu allows the user to directly access the desired menu:

- 1. Press **MENU**, and the letter **M** appears in the lower right corner of the display.
- 2. Enter the desired menu's 2-digit address.

The address must be entered while the **M** is displayed (within approximately 4 seconds). If the **M** is no longer displayed, press **MENU** again followed by the 2-digit address.

Table 2: Menu Addresses					
Menu Type	Display	Menu	Menu Type	Display	Menu
Primary	Flow/Net Totalizer Flow/Velocity Flow/Positive Totalizer Flow/Negative Totalizer Signal Strength/Low Signal Cutoff	00 01 02 03 04	Options	Measurement Units Site Parameters RS232 Configuration Change System Password Change Scale Factor Password Unit ID	42 43 46 47 48 49
Pipe	Pipe OD Pipe Wall Thickness Pipe ID Pipe Material Pipe Sound Speed Pipe Inside Roughness	10 11 12 13 14 15	Calibration	Zero Set Scale Factor Sound Speed Compensation Date and Time	50 51 52 53 54
Liner	Liner Material Liner Thickness Liner Sound Speed Liner Inside Roughness	16 17 18 19	Current Loop	Current Loop Span Current Loop Calibration Current Loop Test	56 57 58 59
Fluid	Fluid Type Fluid Sound Speed Fluid Viscosity	20 21 22	Alarms	Program Alarms View Alarms	70 71 72
Transducer	Transducer Type Transducer Mounting Transducer Spacing	23 24 25	Datalog	Datalog Setup Datalog Interval	80 81
Flow	Flow Units Max Flow Range Min Flow Range Damping Low Flow Cutoff Low Signal Cutoff	30 31 32 33 34 35	Diagnostics	Signal Strength/Margin Delta Time/Fluid Sound Speed Reynolds #/Profile Factor Current Loop Output Software/Firmware Rev. Level	90 91 92 93 94
Totalizer	Totalizer Units Totalizer Multiplier Net Totalizer Positive Totalizer Negative Totalizer Totalizer Reset	36 37 38 39 40 41	Print	Print Log Setup Print Settings Print Diagnostic Print Current Screen	96 97 98 99

3.3 Using the Arrow Keys to Access Menus

Another method of accessing the flowmeter's menus is to use the **LEFT** or **RIGHT ARROW** keys to scroll through the menu structure. Menus are organized into 3 basic levels: 1) Main menu, 2) submenus, and 3) primary displays, setup menus, diagnostic menus. The **Main** menu displays various **submenus**, which contain individual **setup** and **diagnostic** menus.

To access the Main menu from any screen:

- 1. Press **MENU** twice. The Main menu is displayed with the **Pipe** and **Liner** submenu options as shown in Figure 3.3-A.
- 2. To view the remaining submenus (Figure 3.3-B), press the **DOWN ARROW** key.

Main Menu				
■Pipe ■Liner				
Figure 3.3-A				
■Pipe	∎Liner			
■Fluid	∎Xducer			
■ Flow	∎Total.			
■Options	■Calibr.			
■4-20mA	∎Alarms			
■DataLog.	■Diagn			

FIGURE 3.3-B

3. When the desired submenu is highlighted, press **ENTER** to display the first menu of the selected submenu. Figure 3.3-C is an example of when the **Flow** submenu is selected.

Flow Units

*Gallons

FIGURE 3.3-C

Use the **UP** or **DOWN ARROW** keys to view a Primary Display, setup menu, or diagnostic menu within the current submenu.

3.4 Flowmeter Configuration Using Setup Menus

Flowmeter configuration is accomplished using the setup menus. Some setup menus allow a numeric value to be entered, and others offer non-numeric selections. In non-numeric setup menus, an asterisk is displayed to the left of the selected currently entered in the flowmeter (Figure 3.4, below).



FIGURE 3.4

...3.4 Flowmeter Configuration Using Setup Menus continued

To configure the flowmeter:

- 1. Access the setup menus individually by pressing **MENU** and entering the 2-digit address OR by scrolling through the submenus and selecting the desired setup menu.
- 2. a. If the setup menu requires a numeric entry, use the numeric keys to enter the value and press **ENTER** to accept the value. If the numeric value is entered incorrectly, press **ERASE** to delete the entry.

OR

b. If the setup menu offers a non-numeric selection, press **ENTER**, and the asterisk changes to a flashing cursor. Use the arrow keys to scroll through the available selections. When the cursor is to the left of the desired selection, press **ENTER**.

NOTE

3. Complete the configuration process by accessing a Primary Display (menus 00 through 04).

The flowmeter will not use the new parameters until accessing a Primary Display.

3.5 Quick Setup Configuration

The Quick Setup procedure contains the minimal steps required for flowmeter configuration. These steps enable the flowmeter to calculate transducer spacing, acquire ultrasonic signal, and measure flow. The number in parentheses after the required menu is the 2-digit address to directly access that menu.

- 1. Select a proper transducer site according to Section 4 (page 29).
- 2. Access the **Pipe** submenu. This submenu contains setup menus related to the pipe parameters such as pipe inside diameter (ID) and pipe outside diameter (OD).



Pipe Wall Thickness is an additional setup menu within the Pipe submenu. If parameters for any 2 of the following 3 setup menus are entered, the flowmeter calculates the remaining parameter automatically: Pipe OD (10), Pipe Wall Thickness (11), Pipe ID (12).



Accuracy is directly affected by the square of an error in pipe dimensions; actual measurements (not nominal) must be entered.

a. Select the **PIPE OD** menu (10). Figure 3.5-A is displayed. Enter the value for the pipe OD and press **ENTER**. Press the **DOWN ARROW**, and select **Actual**.

Pipe OD 13.87 inches

FIGURE 3.5-A

NOTE: If you know the pipe circumference but not the OD, enter the circumference value instead and press **ENTER**. Press the **DOWN ARROW**, and Figure 3.5-B is displayed. Select **Circum**. The flowmeter calculates the pipe OD automatically.



FIGURE 3.5-B

...3.5 Quick Setup Configuration continued

Step 2, PIPE setup menu continued:

- b. Select the **Pipe ID** setup menu (12). Enter the pipe ID value, and press **ENTER.** (Figure 3.5-C)
- Select the **Pipe Material** setup menu (13). Press the **UP** and **DOWN ARROWS** to scroll through the available options. (Figure 3.5-D)

NOTE: Select **OTHER** if the material is not listed. You must then enter then pipe sound speed (14) and pipe inside roughness (15).

- 3. If there is a liner:
 - Access the Liner Material setupmenu (16), and Figure 3.5-E is displayed. Press the UP and DOWN ARROWS to scroll through the available options.

NOTE: Select **OTHER** if the material is not listed. You must then enter the liner sound speed (18) and liner inside roughness (19).

- b. Access the Liner Thickness setup menu (17), and enter the thickness. (Figure 3.5-F)
- 4. Access the **Fluid Type** setup menu (20), and scroll through the available options using the **UP** and **DOWN ARROWS.** (Figure 3.5-G)

NOTE: Select **OTHER** if the fluid type is not listed. You must then enter the fluid sound speed (21) and fluid viscosity (22).

- 5. Within the **Transducer** submenu:
 - Access the Transducer Type setup menu (23). Currently, the only selection available is STANDARD, which MUST be selected for all applications using clamp-on transducers, including high temperature transducers. (Figure 3.5-H)
 - Access the Transducer Mounting setup menu (24), and select the desired mounting method. (Figure 3.5-I)
- Access the Transducer Spacing view-only menu (25). Note the required spacing between transducers. (Figure 3.5-J)

PIPE ID

4.02 INCHES

FIGURE 3.5-C

Pipe Material

*CARBON STEEL

FIGURE 3.5-D

Liner Material

*POLYETHYLENE

FIGURE 3.5-E

Liner Thickness

0.00 Inches

FIGURE 3.5-F

Fluid Type

*GASOLINE

FIGURE 3.5-G

Transducer Type

*Standard

FIGURE 3.5-H

Transducer		Mount		
*v	z	W	WV	ww

FIGURE 3.5-1

Transducer Spacing

5.93 Inches

FIGURE 3.5-J

...3.5 Quick Setup Configuration continued

- 7. Access the **Flow Units** setup menu (30) within the **FLOW** submenu. Use this setup menu to select the flow rate units. Volumetric units are displayed first, followed by the associated time per units.
 - a. Select one of the available volumetric units. (Figure 3.5-K)
 - Press the **DOWN ARROW** and the time per unit options are displayed. Select the desired option. (Figure 3.5-L)
- 8. Install the transducers on the pipe using the spacing provided by the flowmeter, and connect the transducer cables to the flowmeter.



Flow	Units	Per	
Sec	*Min	Hour	



9. Access a Primary Display (00 through 04) to complete the configuration process.

If the flowmeter and transducers are properly installed and a steady flow is present, the flow and signal strength readings should be relatively stable.



If any of the above setup parameters are changed, the flowmeter stops measuring flow until the new value is entered and a Primary Display is accessed to accept the new value.

3.6 Primary Displays

The **Primary Displays** are for viewing only and cannot be configured. **Primary Displays** include displayed values for flow rate, totalizers, velocity, signal strength, or low signal cutoff (menus 00 through 04).

3.6.1 Flow/Net Totalizer (00)

The **Flow/Net Totalizer** is the standard display used under normal operating conditions. It displays the flow rate and net totalizer value. If the net totalizer is not currently enabled, the last net totalized value is displayed. (Figure 3.6-A)

Flow=	0.00 GPM
Net	0 x0.1Gal

FIGURE 3.6-A

3.6.2 Flow/Velocity (01)

The **Flow/Velocity** display indicates the flow rate and fluid velocity. Velocity is displayed in feet per second (*FPS*) if ENGLISH is selected as the measurement unit in Menu 42 and in meters per second (*MPS*) if METRIC is selected. (Figure 3.6-B)

3.6.3 Flow/Positive Totalizer (02)

This display indicates the flow rate and the totalized flow in the positive flow direction. If the positive totalizer is not currently enabled, the last *net* totalized value is displayed. (Figure 3.6-C)

Flow=	0.00	GPM
Vel =	0.00	FPS

FIGURE 3.6-B

Flow=	0.	00 GPM
Pos	0	x0.1Gal

FIGURE 3.6-C

3.6.4 Flow/Negative Totalizer (03)

This display indicates the flow rate and the totalized flow in the negative flow direction. If the negative totalizer is not currently enabled, the last *net* totalized value is displayed. (Figure 3.6-D)

3.6.5 Signal Strength/Low Signal Cutoff (04)

This display indicates the values for signal strength and low signal cutoff. (Figure 3.6-E)

Flow=	0.00 GPM	
Neg	0 x0.1Gal	

FIGURE 3.6-D

SigStr	=	0
Cutoff	=	2

FIGURE 3.6-E

3.7 Additional Setup Menus Within the PIPE Submenu*

*Not included in the Quick Setup Configuration

Following are **setup** menus not included in the Quick Setup Configuration detailed in Section 3.5 (page 10). **Setup** menus are used primarily to enter configuration data or to view the flowmeter's current configuration settings. The following setup menus are located within the **PIPE** submenu and are not required entries in the Quick Setup Configuration:

- **Pipe Wall Thickness** setup menu (11) (Figure 3.7-A)
- **Pipe Sound Speed** setup menu (14): This menu can only be configured if **OTHER** was selected as the pipe material in Menu 13. Enter the pipe sound speed. If **OTHER** was NOT selected as the pipe material, this menu is available by the direct access method only and functions as a view-only display to indicate the pipe sound speed as programmed in the flowmeter's database. (Figure 3.7-B)
- Pipe Inside Roughness setup menu (15): This menu can only be configured if OTHER was selected as the pipe material in Menu 13. Data on this parameter are available from the *Cameron Hydraulic Data Book* published by Ingersoll-Rand. Enter the inside roughness of the pipe. If OTHER was NOT selected as the pipe material, this menu is available by the direct access method only and functions as a viewonly display to indicate the pipe inside roughness as programmed in the flowmeter's database. (Figure 3.7-C)

Pipe Wall Thickness

0.38 inches

FIGURE 3.7-A

Pipe Sound Speed

10440

FPS

FIGURE 3.7-B

Pipe Roughness 0.000150 Ft

FIGURE 3.7-C

3.8 Additional Setup Menus Within the LINER Submenu*

*Not included in the Quick Setup Configuration

- Liner Sound Speed setup menu (18): This menu can only be configured if OTHER was selected as the liner material in Menu 16. Enter the liner sound speed. If OTHER was NOT selected as the liner material, this menu is available by the direct access method only and functions as a view-only display to indicate the liner's sound speed as programmed in the flowmeter's database. (Figure 3.8-A)
- Liner Inside Roughness setup menu (19): This menu can only be configured if OTHER was selected as the liner material in Menu 16. Enter the liner inside roughness. If OTHER was NOT selected as the liner material, this menu is available by the direct access method only and functions as a view-only display to indicate the inside roughness of the liner as programmed in the flowmeter's database. (Figure 3.8-B)

Liner Sound Speed

8203.00 FPS

FIGURE 3.8-A

Liner Roughness

0.001000

FIGURE 3.8-B

3.9 Additional Setup Menus Within the FLUID Submenu*

*Not included in the Quick Setup Configuration

- Fluid Sound Speed setup menu (21): This menu can only be configured if OTHER was selected as the fluid type in Menu 20. Enter the fluid sound speed. If OTHER was NOT selected as the fluid type, this menu is available by the direct access method only and functions as a view-only display to indicate the fluid sound speed as programmed in the flowmeter's database. (Figure 3.9-A)
- Fluid Viscosity setup menu (22): This menu can only be configured if OTHER was selected as the fluid type in Menu 20. Enter the fluid viscosity. If OTHER was NOT selected as the fluid type, this menu is available by the direct access method only and functions as a view-only display to indicate the fluid viscosity as programmed in the flowmeter's database. (Figure 3.9-B)

Fluid Sound Speed 4863.33 FPS

FIGURE 3.9-A

Fluid Viscosity 1.130 cSt

FIGURE 3.9-B

3.10 Additional Setup Menus Within the FLOW Submenu*

*Not included in the Quick Setup Configuration

• Max Flow Range setup menu (31) and Min Flow Range setup menu (32): Use these menus to enter the minimum and maximum flow values for setting the volumetric flow range. Setting the optimum flow range generally improves the flowmeter's response time. (Figures 3.10-A and 3.10-B)

NOTE: Whenever the pipe ID is changed, the flowmeter returns the volumetric flow range to its default settings. The default settings are the minimum and maximum flows for the new pipe ID that occur at +32 and -32 ft/s (+9.76 and -9.76 m/s).

- **Damping** setup menu (33): Use this menu to enter the value for the damping coefficient, which suppresses short-term fluctuations in the indicated flow rate. The displayed flow rate and the 4-20 mA current loop output is a moving average of the last *n* seconds where *n* is the damping value. Increasing the coefficient increases the response time to changes. The coefficient is adjustable from 1 to 99 seconds in 1-second increments. Damping should be kept at a minimum unless the flow rate fluctuates wildly. If this is the case, increase the damping coefficient just enough to reduce the fluctuation to an acceptable degree. (Figure 3.10-C)
- Low Flow Cutoff setup menu (34): When a zero flow condition occurs (for example, as the result of a pump being shut off), internal sloshing, check valve leakage, and other fluid movement can prevent the flowmeter from reading total zero. This phenomenon can result in totalizer errors. Minimize these errors by entering a low flow cutoff, which drives the flowmeter to zero for flow rates at or below the specified value. If the flow rate falls below the low flow cutoff value, the indicated flow rate is driven to zero and the totalizers stop incrementing; this is the case regardless of flow direction. (Figure 3.10-D)

For example, if you enter a low flow cutoff of 0.1 ft/s (.03 m/s), the flowmeter is driven to zero for flow rates less than 0.1 ft/s in the positive direction and greater than -0.1 ft/s in the negative direction. (Figure 3.10-E)

Max Flow

2000.00 GPM

FIGURE 3.10-A

Min Flow

-2000.00 GPM

FIGURE 3.10-B

Damping

5 secs

FIGURE 3.10-C



...3.10 Additional Setup Menus Within the FLOW Submenu* continued

*Not included in the Quick Setup Configuration

• Low Signal Cutoff setup menu (35): Empty pipes or solids, bubbles, or voids in the flow stream may cause temporary drops in signal strength and erroneous readings. Minimize the effect of these dropouts by setting a low signal cutoff, which drives the flowmeter to the loss-of-signal (LOS) condition. The low signal cutoff should be set at the minimum acceptable signal amplitude.

To set the low signal cutoff:

- a. Access the **Low Signal Cutoff** setup menu (35). (Figure 3.10-F)
- b. Enter the low signal cutoff and press ENTER.

NOTE: The value for the low signal cutoff should usually be set at approximately one-half of the value of the signal strength present under flow conditions. Typically, signal strength is not significantly affected by flow rate.

c. Select one of the following:

Low Signal Cutoff 0%

FIGURE 3.10-F

Low	Signal	Action
*Zei	0	Hold

FIGURE 3.10-G

- ZERO: the flowmeter drops the reading to zero during LOS condition;
- **HOLD**: the flowmeter holds the last valid reading during LOS condition for about 3 seconds. (Figure 3.10-G)

3.11 Additional Setup Menus Within the TOTAL Submenu*

*Not included in the Quick Setup Configuration

- **Totalizer Units** setup menu (36): The flow unit selected for the totalizer display may be different from the flow unit selected for the flow rate display. (Figure 3.11-A)
- **Totalizer Multiplier** setup menu (37): The totalizer value can be displayed with one of several multiplier values. For example, 700 liters can be displayed as *700* if the selected multiplier value is *X1*, or it can be displayed as *7* if selected multiplier value is *X100*. (Figure 3.11-B)
- Net Totalizer setup menu (38): Use this menu to enable or disable the net totalizer. The net totalizer provides the difference between the positive and negative flow values. For example, if there are 1000 gallons of flow in the negative direction and 3000 gallons of flow in the positive direction, the net totalizer indicates 2000 gallons of net flow. (Figure 3.11-C)

Tota	lizer	Units	
	*Gallo	ns	
Figure 3.11-A			
Tot	alizer	Mult.	
*x0.	01	x0.1	
	FIGURE 3.11-B		
Net	Total	izer	
Off		*On	

FIGURE 3.11-C

...3.11 Additional Setup Menus Within the TOTAL Submenu* continued

*Not included in the Quick Setup Configuration

- **Positive Totalizer** setup menu (39): Use this menu to enable or disable the positive totalizer. The positive totalizer tracks the flow that moves in the positive direction, from upstream transducer to downstream transducer. It is NOT affected by flow in the opposite direction. (Figure 3.11-D)
- **Negative Totalizer** setup menu (40): Use this menu to enable or disable the negative totalizer. The negative totalizer tracks the flow that moves in the negative direction, from downstream transducer to upstream transducer. It is NOT affected by flow in the opposite direction. (Figure 3.11-E)
- **Totalizer Reset** setup menu (41): Use this menu to reset one or all of the totalizers. (Figure 3.11-F)

Pos.	Totalizer
Off	*On

FIGURE 3.11-D

Neg. Totalizer Off *On

FIGURE 3.11-E

Neg.	Totalizer
Off	*On

FIGURE 3.11-F

3.12 Additional Setup Menus Within the OPTIONS Submenu*

*Not included in the Quick Setup Configuration

The **OPTIONS** submenu contains setup menus for several miscellaneous functions.

- Measurement Units setup menu (42): Use this menu to select ENGLISH (feet per second, *FPS*) or METRIC (meters per second, *MPS*) measurement units. (Figure 3.12-A)
- Site Parameters setup menu (43): This menu saves the parameters for the pipe, liner, fluid, transducer, and flow setup menus, allowing them to be recalled later for a specific measurement site. Several sites are available and are numbered. The site number is displayed in Menu 43 in the lower left corner of the screen and is followed by a colon. See Figure 3.12-B for an example of a site numbered 1.

Measurement Units			
*English Metric			
FIGURE 3.12-A			
Site Parameters			
1:3.507 In, PVC			

FIGURE 3.12-B

As the setup parameters are entered in their respective menus during normal configuration, the same parameters are saved simultaneously in the **Site Parameters** setup menu, in whichever site has the asterisk displayed.

Access a different site to automatically enter that site's stored parameters into the flowmeter for measuring flow. To access a different site, press ENTER, scroll to the desired site, and press ENTER again. To avoid overwriting stored parameters and losing old data, ensure that the desired site is active prior to entering the new set of parameters.

...3.12 Additional Setup Menus Within the OPTIONS Submenu* continued

*Not included in the Quick Setup Configuration

- RS232 Configuration setup menu (46): Use this menu to configure the RS232 port which allows the flowmeter to connect to an IBM[®]-compatible PC using the UltraScan (refer to the UltraScan manual) or D-Link (refer to Appendix C, page 64) utilities. (Figure 3.12-C)
 - Access the **RS232 Configuration** setup menu (46).
 - b. Select ULTRASCAN or D-LINK.

RS232 Mode *ULTRASCAN D-Link

FIGURE 3.12-C

RS232 Config * 19200,N,8,1

FIGURE 3.12-D

- c. Press the **DOWN ARROW** to display the baud rate selections. The baud rate is the only RS232 parameter that can be selected. The remaining parameters are preset. (Figure 3.12-D)
- d. Access Menu 00.
- **Change System Password** setup menu (47): The flowmeter is shipped from the factory with the system password *disabled*. If a password is enabled, the flowmeter requests the password when a user attempts to enter any configuration data. Entering the correct password temporarily unlocks the system, allowing the user to make configuration changes.

To change or disable the system password:

- a. Access Menu 47. (Figure 3.12-E)
- b. Enter the new system password and press **ENTER.** (Figure 3.12-F)

NOTE: Disable the system password function by entering **0** (zero) as the system password. Enable the function by changing the password back to a non-zero number.

c. Enter the old system password (Figure 3.12-G) and press ENTER. If the old system password is correctly entered, Figure 3.12-H is displayed. If the password is incorrectly entered, Figure 3.12-I is displayed.

NOTE: After the system password is accepted or rejected, Menu 48 is displayed, enabling the scale factor password to be changed.

 Access Menu 00 to lock the system with the new password. Password?

FIGURE 3.12-E

New Sys Password? ?

FIGURE 3.12-F

Old Syst. Password?

FIGURE 3.12-G

Password

Accepted

FIGURE 3.12-H

Password

*** Rejected ***

FIGURE 3.12-I

?

...3.12 Additional Setup Menus Within the OPTIONS Submenu* continued

?

?

*Not included in the Quick Setup Configuration

• Change Scale Factor Password setup menu (48): Use this menu to change the scale factor password which is designed to protect the scale factor from unauthorized or accidental changes. The flowmeter ships from the factor with the scale factor password *disabled.* If the scale factor password is *enabled,* the flowmeter requests the password whenever a user attempts to change the scale factor.

To change or disable the scale factor password:

- a. Access Menu 48. (Figure 3.12-J)
- b. Enter the new scale factor password and press **ENTER.** (Figure 3.12-K)

NOTE: The system password function must be *disabled* to allow the scale factor to be changed without entering a password.

- c. Enter the old scale factor password and press **ENTER.** If entered correctly, Figure 3.12-L is displayed. If entered incorrectly, Figure 3.12-M is displayed.
- d. Access Menu 00.
- Unit ID (identification) Number setup menu (49): This number is determined by the operator to identify the specific instrument or site. Any whole number between 1 and 60,000 may be entered. (Figure 3.12-N)

New Sc Fact Passwrd?

FIGURE 3.12-J

Old Scale Password?

FIGURE 3.12-K

Scale Password

Accepted

FIGURE 3.12-L

Scale Password

*** Rejected ***

FIGURE 3.12-M

Unit ID

0

FIGURE 3.12-N

3.13 Additional Setup Menus Within the CALIBR Submenu*

*Not included in the Quick Setup Configuration

Within the **CALIBR** submenu is the **Calibration Group** menu (50) (Figure 3.13-A), which contains 4 setup menus: **Zero Set**, **Scale**, **SS Comp**, **Date** (Menus 51 through 54).



FIGURE 3.13-A

3.13.1 Zero Set Calibration

An important step in assuring accurate flow measurement is the proper calibration of the instrument and proper installation. The calibration methods must be performed for the particular pipe that is to be metered. Table 3 (below) provides guidelines for selecting a calibration method.

Calibration Method	Function	Application
Zero set calibration		
Zero flow set	Zeroes the instrument for an actual no flow condition	Installations where flow can be stopped
Manual zero set	Applies a manually entered offset to all flow readings	Where an offset is required
Scale factor	Compensates for manufacturing variations in the transducers	Set by the factory to the value imprinted on the transducers

TABLE 3

After installing the meter, you may find that a small adjustment to the zero point (zero set calibration) is required. Zero set calibration allows the meter to read very close to zero under zero flow conditions. There are 2 zero set calibration methods in Menu 51: the zero flow set method and the manual zero set method. View the zero point used by the flowmeter in either of these methods by selecting **Manual** in Menu 51.

After the instrument is properly zeroed, it should display a stable reading well below 0.05 ft/s (0.015 m/s) under zero flow conditions with the low flow cutoff disabled.

Prior to performing a zero set calibration, verify the following:

- transducers are connected to the pipe;
- instrument is reading flow;
- low flow cutoff is disabled to allow verification of calibration.

3.13.1.a Zero Flow Set Method

The best method of zeroing the instrument is to stop the flow and perform a zero flow set on the pipe. The purpose of the zero flow set is to zero the instrument for the individual application. This method is used *only* when flow in the pipe can be stopped. The flow rate displayed in Menu 01 must be between -0.25 and +0.25 ft/s (-0.076 and +0.076 m/s).

- 1. Ensure there is no flow in the pipe.
- 2. Access Menu 51. (Figure 3.13-B)
- 3. Select **No Flow.** If the zero flow set calibration is successful, Figure 3.13-C is displayed.

Set Zero			
■No Flow ■Manual			
FIGURE 3.13-B			
Zero Cal Ok			
Flow = 0.00 GPM			

FIGURE 3.13-C

3.13.1.b Manual Zero Set

Use this method infrequently. Manual zero set applies a constant offset entered by the user to all readings. For example, if the flow reads 250 GPM and a 10 GPM offset is applied, the new reading becomes 240 GPM.

To zero the instrument using the manual zero set method:

- 1. Minimize flow occurring in the pipe.
- Access Menu 51 and select Manual. Figure 3.13-D is displayed.
- Enter the value of the required offset and press ENTER. If necessary, you can apply a negative offset by pressing ± (plus/minus key).
- The flowmeter is now calibrated with the manual zero set method, and the zero point offset is displayed. (Figure 3.13-E)

Zero Point	
0.00 GPM	
FIGURE 3.13-D	
Zero Point	
10.00 GPM	

FIGURE 3.13-E

3.13.2 Scale Factor Calibration

After setting and verifying the instrument's zero point, you can set a scale factor to adjust the measured flow; the measured flow is multiplied by this scale factor. For example, if the displayed flow is twice the actual flow, you can enter a scale factor of 0.5 to divide the displayed flow by 2. The primary reason for setting the scale factor is to compensate for manufacturing variations in the transducers. The scale factor printed on the transducer set should be entered in Menu 52.

Observe the following precautions when setting the scale factor:

- Always determine the scale factor at the highest possible flow rate achievable in order to maximize accuracy of the scale factor.
- Use only the factory preset scale factor as marked on the transducers in the following situations: the flow cannot be stopped to verify or set the zero point; a reasonably high flow rate cannot be achieved; an accurate secondary flow standard is not available.

If an additional scale factor is required, the additional scale factor should be multiplied by the factory scale factor and the result should be entered. To enter a new scale factor:

- 1. Access Menu 52. (Figure 3.13-F)
- 2. Enter the new scale factor and press **ENTER.** Figure 3.13-G is displayed.
- 3. Enter the valid password and press ENTER.

The new scale factor is displayed in Menu 52. To maximize security, enter a new scale factor password immediately.

Scale Factor

0.9850

FIGURE 3.13-F

Scale Fac Password? 2

FIGURE 3.13-G

3.13.3 Other CALIBR Submenu Options

- Sound Speed Compensation setup menu (53): Enable or disable the flowmeter's sound speed compensation. Temperature variations in the fluid and other factors may cause variations in the fluid's sound speed. Typically, the flowmeter can determine sound speed more accurately when this feature is enabled. (Figure 3.13-H)
- Date and Time setup menu (54): Use this menu to set the date and time in the flowmeter's internal clock. The time is expressed in military time (24-hour format), and the date is in the month-day-year format (Figure 3.13-I). If you are NOT using UltraScan, set the time and date as follows:
 - a. Perform a Master Erase on the flowmeter according to Section 5.2 (page 40).
 - b. Reconfigure the flowmeter, and access Menu 54.

Sound Speed Comp. *Enabled Disabled

FIGURE 3.13-H

Date and Time 12-01-96 14:07:17 Figure 3.13-1

Date and Time? Month? 12

FIGURE 3.13-J

NOTE: Performing a Master Erase and reconfiguring the flowmeter prior to changing date or time prevents possible data corruption.

- c. Press **ENTER**, and prompts are displayed, requesting entries for month, day, year and hour, minute, second (Figure 3.13-J). Press **ENTER** after EACH entry.
- d. To keep the current values displayed in any screen, scroll to the next screen with the **DOWN ARROW** instead of pressing **ENTER**.
- e. Once all parameters are entered, the new programmed date and time is displayed.

3.14 Additional Setup Menus Within the 4-20mA Submenu*

*Not included in the Quick Setup Configuration

Within the **4-20mA** submenu is the **Current Loop Group** menu (56), which contains 3 setup menus: **Span, Cal., Test** (menus 57 through 59). (Figure 3.14-A)

The 4-20 mA current loop is factory calibrated and should not require field calibration prior to use. If calibration and testing should become necessary, complete the following steps:

- 1. Connect a milliammeter to the input (IN) and output (OUT) terminals of the current loop module.
- 2. Access Menu 58. (Figure 3.14-B)

Current Loop			
∎Span ∎Cal. ∎Test			
FIGURE 3.14-A			
4 mA Calibrate			
<>			



...3.14 Additional Setup Menus Within the 4-20mA Submenu* continued

*Not included in the Quick Setup Configuration

- 3. Press the **RIGHT** or **LEFT ARROWS** to adjust the 4 mA set point until the value reads exactly 4.00 mA on the milliammeter. Every 2 presses of the arrow key adjusts the calibration approximately .01 mA.
- 4. Press ENTER.
- 5. Access Menu 58 again.
- 6. Press the **DOWN ARROW** to scroll to the **20 mA Calibrate** screen. (Figure 3.14-C)
- 7. Repeat step 3 for entering the 20 mA set point.
- 8. Access Menu 00.
- 9. *Test* the current loop calibration by accessing Menu 59. (Figure 3.14-D)
- Change the current loop output in 1 mA increments using the **RIGHT** or **LEFT ARROWS**. The output indicated on the screen should be the same as the output on the milliammeter. If the values do not match, repeat steps 2 through 10.
- Set the current loop *span* by accessing Menu 57 (Figure 3.14-E). The current loop span is the span of flow versus current.
- 12. Enter a flow rate which equals the 4 mA (minimum anticipated) reading, and press **ENTER.**
- 13. Press the **DOWN ARROW**, and Figure 3.14-F is displayed.
- 14. Enter a flow rate which equals the 20 mA (maximum anticipated) reading, and press ENTER.
- 15. Access Menu 00 to complete the current loop calibration process.

3.15 Additional Setup Menus Within the ALARMS Submenu*

*Not included in the Quick Setup Configuration

The **ALARMS** submenu (70) contains the setup menus for programming and viewing the flowmeter's alarm parameters. Up to 4 alarms may be independently programmed ON or OFF based on flow rate or signal strength values. If the measured value of the selected condition falls outside the specified parameters, the alarm activates and causes the printer (if purchased with flowmeter) to print the flow data and/or alarm status. (Figure 3.15-A) Alarms ■Program ■View

FIGURE 3.15-A

20	mA	Calibrate
	<	>

FIGURE 3.14-C

Current	Loop	Test
---------	------	------

4 mA -->

FIGURE 3.14-D

Span? 4 mA

0.00 Gal/S

FIGURE 3.14-E

- Span? 20 mA
- 0.00 Gal/S

FIGURE 3.14-F

3.15.1 Programming the Alarm

- 1. Access Menu 71, and select and alarm to program. (Figure 3.15-B)
- 2. Figure 3.15-C is displayed. Select an alarm ON condition:
 - NOT PROGRAMMED (alarm OFF);
 - **FLOW** > : alarm activates when flow rate is greater than ON condition value;
 - **FLOW <** : alarm activates when flow rate is less than ON condition value;
 - **SIGNAL >** : alarm activates when signal strength value is greater than ON condition value;
 - **SIGNAL <** : alarm activates when signal strength value is less than ON condition value.
- 3. Press the **DOWN ARROW**, and Figure 3.15-D is displayed.
- 4. Enter the value for the alarm ON condition, and press **ENTER.**

NOTE: Flow units used for alarms are the same as flow units selected for measuring flow in Menu 30.

- 5. Press the **DOWN ARROW**, and Figure 3.15-E is displayed.
- 6. Select an alarm OFF condition: Selections available are the same as those for the ON condition. The OFF condition value should be entered in conjunction with the ON condition value to establish as "dead band" which prevents the alarm from continuously cycling on and off when flow is close to the ON or OFF value.

For example, if the ON condition is **FLOW > 250 GPM**, the OFF condition may be set as **FLOW < 240 GPM**. With these settings, the alarm turns on when flow exceeds 250 GPM and does not turn off until flow falls below 240 GPM.

- 7. Press the **DOWN ARROW**, and Figure 3.15-F is displayed.
- 8. Enter a value for the alarm OFF condition, and press ENTER.
- 9. Repeat steps 1-8 for each alarm you want to program.



FIGURE 3.15-B

Alarm 1 On Condition *Flow <

FIGURE 3.15-C

On Cond. Value

16.00 Gal/S

FIGURE 3.15-D

Alarm 1 Off Cond.

*Flow >

FIGURE 3.15-E

Off Cond. Value 24.00 Gal/S

FIGURE 3.15-F

3.15.2 Viewing Alarms

To view the ON/OFF status of the alarms:

- 1. Access Menu 72. (Figure 3.15-G)
- Select an alarm to view, and the ON and OFF conditions are displayed for the selected alarm. (Figure 3.15-H)



3.16 Additional Setup Menus Within the DATA LOG Submenu*

*Not included in the Quick Setup Configuration

The **DATA LOG** submenu contains the **Log Menu** (80) and the **Log Interval** menu (81). The datalogger provides the ability of continuously recording flow data at a preset interval. The flowmeter has a single datalog file with approximately 40,000 data points available. This allows considerable data to be collected. The datalogger is always recording data. When all points are recorded, the datalogger records over the previous data points one at a time in a continuous loop, starting with the oldest data points first. The logger can be started and stopped manually or can be programmed to run automatically at a future start and stop time.

The flowmeter stores completed datalog files and assigns a unique file number to each log. This allows datalogs to be recorded and retrieved. Additionally, files can be viewed, deleted, or transferred in ASCII format to an IBM[®]-compatible PC for record keeping or analysis. Log files are transferred using the D-Link flowmeter data link utility (Appendix D, page 64).

- Log menu (80): There are 4 selections available (Figure 3.16-A):
 - a. Start (or stop) log–This option provides control for manually starting/stopping the datalogger. The appropriate option (start or stop) is displayed depending on whether the logger is currently recording.

To stop the log:

- 1. Access Menu 80, and select Stop.
- 2. Figure 3.16-B is displayed; press 5.





- b. **Auto**–This option allows the user to program the logger for a future start and stop time. To use this function:
 - 1. Access Menu 80, and select Auto.
 - 2. The current programmed start/stop times are displayed. (Figure 3.16-C, page 26)
 - Press ENTER. Prompts are displayed requesting day, hour, minute, and second information for the start/stop times (Figure 3.16-D, page 26). Press ENTER after EACH entry.

3.16 Additional Setup Menus Within the DATA LOG Submenu* continued

*Not included in the Quick Setup Configuration

Once the start/stop times are entered, the new times are displayed. (Figure 3.16-E).

The datalogger will now start and stop automatically at the preset times. If the logger is running, the user can manually stop the logging by selecting **Stop** in Menu 80.

Start:	5	7:08:30	
Stop:	6	23:15:00	

FIGURE 3.16-C



Ensure that flow measurement units, time, and date are correct on the flowmeter PRIOR to beginning the log. Do not change any of these parameters while the logger is actively or before transferring the data.

Start	Log?
-------	------

Day?

Start:

Stop:

FIGURE 3.16-D

5

8 8:09:00 9 11:45:30

FIGURE 3.16-E

Log Interval 60 secs

FIGURE 3.16-F

Erase Log File?

Are you sure?(5=Yes)

FIGURE 3.16-G

Erase Log File?

Really sure?(.=Yes)

FIGURE 3.16-H

Data log

Erased

FIGURE 3.16-I

- Interval menu (81): Datalog intervals must be entered in whole seconds, with a minimum interval of 1 second. (Figure 3.16-F)
- View menu: Use this menu to view which log files are stored in memory, the file sizes, and amount of log memory still available. Additionally, use this menu to delete log files:
 - 1. Access Menu 80, and select View.

2. Scroll through the log file with the **UP/DOWN ARROWS** to locate the file you want to delete.

- 3. Press **ENTER**, and Figure 3.16-G is displayed.
- 4. Press **5**, and Figure 3.16-H is displayed.
- 5. Press . (decimal point), and Figure 3.16-I is displayed informing you the log is deleted.

3.17 Additional Setup Menus Within DIAGNOSTICS Submenu*

*Not included in the Quick Setup Configuration

The **DIAGNOSTICS** submenu contains various view-only menus which display important diagnostic parameters that are currently used or calculated by the flowmeter. These parameters are helpful when configuring or troubleshooting the flowmeter.

- Signal Strength/Margin display (90): Displays the signal strength in percentage and the margin. The signal strength value displayed is the average of the signal strengths for the upstream and downstream transducers. Margin is an indicator of signal quality and is generally greater than 5%. Signal strength is generally greater than 3% under good measurement conditions. (Figure 3.17-A)
- Delta Time/Fluid Sound Speed display (91): Displays the value for DeltaT and the fluid sound speed as measured by the flowmeter. DeltaT is the difference between the upstream and downstream travel times, expressed in nanoseconds (ns). (Figure 3.17-B)
- **Reynolds Number/Profile Factor** display (92): Displays the Reynolds number and flow profile factor currently being used by the flowmeter. The flow profile factor is calculated by the flowmeter and used to determine the effect of the flow profile on mean measured fluid velocity. (Figure 3.17-C)
- **Current Loop Output** display (93): Displays values of the current in mA that the flowmeter is presently providing to the current loop output. (Figure 3.17-D)
- Software/Firmware Revision Level display (94): Displays the software (*SOFT VERS*.) and firmware (*FPGA VERS*.) versions installed in the flowmeter. (Figure 3.17-E)

82%



DeltaT	=	0.00	ns
SSpeed	=	4863.33	FPS

FIGURE 3.17-B

Reynolds=		
Factor	= 0.750000	

FIGURE 3.17-C



FPGA Vers. = A0 FIGURE 3.17-E

3.18 Additional Setup Menus Within PRINT Submenu*

*Not included in the Quick Setup Configuration

Following are instructions on how to configure the optional external thermal printer. To begin, ensure the printer cable is connected to the printer port on the upper left of the flowmeter's control panel.

• **Print Log Setup** menu (96): Use this menu to configure the printer to print out flow data at a preset interval and/or whenever an alarm activates. Printed flow data include data from all enabled totalizers. Flow data are printed in minimum, maximum, and average flow rates. Minimum and maximum flow rates automatically reset at the end of each print period. The average flow rate is the average over the print interval.

3.18 Additional Setup Menus Within PRINT Submenu* continued

*Not included in the Quick Setup Configuration

- **Print Log Setup** menu continued: To configure the printer:
 - 1. Access Menu 96. (Figure 3.18-A)
 - 2. Select an option from the following:
 - a. NONE: disable printer;
 - b. FLOW: print flow data at a preset log interval,
 - c. **ALARM**: print flow data when an alarm activates,
 - d. **BOTH**: print flow data at a preset log interval *and* when an alarm activates.
 - If you select FLOW or BOTH, press the DOWN ARROW to set the print interval. (Figure 3.18-B)

- Print Select
- *None Flow Alarm

FIGURE 3.18-A

Print Interval

30 sec.

FIGURE 3.18-B

4. Enter the print interval in whole seconds, and press ENTER.



Operation errors may occur if the log interval is too short to allow the selected data to be printed. If the print interval is interrupted by a power loss, the printer resumes at the specified interval after power is restored.

- **Print Settings** menu (97): Print all parameters associated with the pipe, liner, fluid, transducer, and flow menus (10-35) by pressing **MENU** followed by **97**.
- **Print Diagnostics** menu (98): Print all parameters associated with the **DIAGNOSTICS** submenu (90-94) by pressing **MENU** followed by **98**.
- Print Current Screen menu (99): Print the current display by pressing MENU followed by 99.

4. WIRING & INSTALLING THE TRANSDUCERS

4.1 Wiring

The transducer terminals and cables are arranged in pairs and are labeled *DN STREAM* and *UP STREAM*. The downstream transducer cable has blue-banded ends; the upstream transducer has red-banded ends.



4.2 Site Selection & Preparation

Prior to installing the transducers, a proper site must be selected to ensure accurate measurement. Examples of site recommendations are illustrated in Figures 4.2-A (below) and 4.2-B (page 30).



FIGURE 4.2-A



FIGURE 4.2-B

Use the following guidelines when selecting the transducer site:

- Choose a section of pipe which is always full of liquid, such as a vertical pipe with up flow or a full horizontal pipe.
- The site should have a straight run equivalent to at least 10 pipe diameters upstream and 5 pipe • diameters downstream from any elbows, tees, throttling valves, orifices, reduced sections, or other flow disturbances.
- Up to 30 diameters of straight run may be required upstream from the flowmeter after a pump, control valve, or double piping bend for greater accuracy. A distance of 5 diameters downstream is usually sufficient under all circumstances.
- Always mount the transducers on the sides of the pipe in the 3 o'clock or 9 o'clock positions on horizontal pipes. Positioning the transducers in this manner prevents signal loss which can be caused by sediment along the bottom of the pipe or gas bubbles and air pockets along the top of the pipe.
- Ensure that the pipe skin temperature is within the transducer temperature rating. The transducers are • rated for -40° to +212° F (-40° to +100° C). Temperature ratings up to 392° F (200° C) are available with optional high temperature transducers.
- Pipes with excessive corrosion or scaling create conditions which can make accurate measurement • difficult or impossible; if possible, avoid selecting these sections of pipe as mounting locations.
- Remove any dirt, grease, rust, loose paint, or scale from the pipe surface prior to mounting the transducers. To obtain best results on aging and rough pipes, a file or grinder may be required to clean the pipe down to bare metal.

If your application cannot follow these guidelines completely, meaningful flow measurements (with some loss in accuracy and stability) may still be obtained, depending on signal quality.

4.3 Spacing & Mounting the Transducers

Once you have selected a proper transducer site, you must ensure proper transducer spacing and mounting in order to maximize signal strength and accuracy:

- 1. Determine which mounting method is appropriate for your application: V, W, Z, VV, WV.
- 2. Refer to Section 3 (page 7) to configure the flowmeter via the keypad or to the UltraScan manual to configure with UltraScan, and note the value required for the transducer spacing (value calculated by and displayed on flowmeter LCD or in UltraScan).
- 3. Clean the area of the pipe designated as the mounting location. Remove any rust, scale, or loose paint; well-bonded paint does not need to be removed.



On horizontal pipes, the transducers should be mounted in the 3 o'clock and 9 o'clock positions in order to avoid situations which can cause signal loss, i.e., sediment along the bottom of the pipe, gas bubbles or air pockets along the top of the pipe.

- 4. Refer to one of the following sections to mount the transducers according to the selected mounting method:
 - the V method: Section 4.4.1 (page 33),
 - the W method: Section 4.4.2 (page 34),
 - the Z method: Section 4.4.3 (page 34),
 - the VV and VW methods: Section 4.4.4 (page 37).
- 5. Install the portable slide rack:
 - a. Extend the chain hooks by unscrewing the chain adjustment knobs to their fullest extent. The knobs will stop at the end of the adjustment and should not be removed.
 - b. Place the rack against the pipe and wrap the chains around the pipe.
 - c. With excess slack removed from the chain, connect the chains to the chain hooks.
 - d. Tighten the chain hooks by screwing down both chain adjustment knobs.
- 6. Install the portable transducers:
 - a. Position the slides according to the calculated spacing. The top rail of the rack is marked in inches and the bottom rail is marked in millimeters.
 - b. Apply sonic coupling compound to a transducer face, and with the cable connector end of the transducer towards the outside of the rack, install the transducer beneath one of the slides. The inside face of the transducer should align with the inside edge of the slide.
 - d. Tighten the knobs on the slide evenly to hold the transducer in place.
 - e. Repeat this procedure with remaining transducer.
...4.3 Spacing & Mounting the Transducers continued

7. Ensure the transducer face is aligned normal to the pipe (Figure 4.3-A, below). The transducer face alignment is particularly critical on small pipes due to pipe curvature. Notice that the properly installed transducer contacts the pipe at the pipe's centerline and that the gaps on either side of the centerline are equal. The notches on both ends of the portable transducer rack allow the assembly to self-align to the curvature of the pipe. Check the contacts of the notches to the pipe, and adjust as necessary.



FIGURE 4.3-A

8. Connect the transducer cables to the flowmeter.



The transducers should be mounted on the pipe in relation to the direction of flow, as shown in Figure 4.3-B (below). Reversing the position of the upstream and downstream transducers or reversing the transducer cable connections to the instrument results in negative flow readings.



- Refer to Figure 1.6 (page 4) to locate the upstream and downstream connectors on the side of the meter.
- The upstream transducer cable has red-banded ends, and the downstream transducer cable has blue-banded ends (Figure 4.3-B, above).
- 9. If maximum accuracy at low flow rates is important, calibrate the flowmeter according to Section 3.13 (page 19).

The flowmeter is now capable of accurately measuring velocity and flow.



FIGURE 4.3-C: PORTABLE TRANSDUCER RACK INSTALLATION

4.4 Transducer Mounting Methods

There are several methods of mounting the transducers. The best method is determined by the specific application. Complete steps 1-5 in Section 4.3 (page 31), and refer to the following sections for instructions on how to properly mount the transducers with one of the available mounting methods.

4.4.1 V Method

The V method (Figure 4.4-A, below) is considered the standard method for pipes with 4- to 16-in (101.6 to 406.4 mm) diameters. This method typically yields a more accurate reading than the Z method since it utilizes a longer measurement path.

Ensure V is the selected mounting method.



FIGURE 4.4-A: V MOUNT

4.4.2 W Method

In many instances, flowmeter performance on small metallic pipes with outer diameters of 4 inches (100 millimeters) or less can be improved by using the W mounting method (Figure 4.4-B, below). With the W method, the sound wave traverses the fluid 4 times and bounces off the pipe walls 3 times. Like the V method, both transducers are mounted on the same side of the pipe.



Ensure W is the selected mounting method.



The signal transmitted in a Z method installation has less attenuation than a signal transmitted with the V method. This is because the Z method utilizes a directly transmitted (rather than reflected) signal which transverses the liquid only once. The Z method (Figure 4.4-C, below) is used primarily in applications where the V method cannot work due to signal attenuation from excessive air or solids in the liquid, thick scale, poorly bonded linings, or very large pipes. In addition, the Z method generally works better on larger diameter pipes where less pipe length is required for mounting.





...4.4.3 Z Method continued

- 1. Establish a reference at both the 3 o'clock and 9 o'clock positions on the pipe. (Figure 4.4-D)
- 2. Place a transducer at the 3 o'clock position.
- Trace the shape of the 3 o'clock transducer along its inside edge (opposite the cable connection). Draw a horizontal line at its center. Remove the transducer.

(Figure 4.4-E)

- 4. Obtain a continuous sheet of paper longer than the circumference of the pipe. Calculator paper tape or thermal printer paper works well for this.
- 5. Fold one end of the paper across the pipe's width to produce a clean, straight edge.
- 6. Line the fold of the paper up with the horizontal centerline of the 3 o'clock transducer.

(Figure 4.4-F)

- Wrap the paper firmly around the pipe, and mark the intersection point where the fold comes in contact with the rest of the paper. (Figure 4.4-G)
- 8. Remove the paper from the pipe. Place the fold and intersection mark together again, and fold the paper exactly in half. (Figure 4.4-H)





SHAPE TRACING

FIGURE 4.4-E: Z MOUNT, STEPS 2-3



FIGURE 4.4-F: Z MOUNT, STEPS 4-6





...4.4.3 Z Method continued

9. Mark along the new fold. (Figure 4.4-I)

10. Draw a horizontal line along the pipe from the centerline of the 3 o'clock transducer position. Use a level to ensure that the line is level with the top of the pipe. The line should be at least 3 inches (76 millimeters) longer than the transducer spacing calculated by UltraScan or via Menu 25.

For example, if UltraScan calculates the spacing as 14 inches (356 millimeters), draw a line 17 inches (432 millimeters) long. (Figure 4.4-J)

11. Measure the spacing from the inside edge of the 3 o'clock transducer, and mark this on the pipe. (Figure 4.4-K)

12. Wrap the paper firmly back on the pipe.

Have the point where the ends of the

paper come together line up with the horizontal line on the 3 o'clock side of the

pipe. Ensure that the inside corner of the

straight edge of the paper is aligned with the mark made for the transducer

spacing. Tape the paper down, or have

someone hold the paper in place.

(Figure 4.4-L)



MARK ALONG

FIGURE 4.4-L: Z MOUNT, STEP 12

TRANSDUCER

SPACING

...4.4.3 Z Method continued

 Go to the other side of the pipe (9 o'clock position), and mark the pipe at the point where the marked fold and the inside edge of the paper length intersect. (Figure 4.4-M)





- 14. Remove the paper from the pipe and trace the shape of the 9 o'clock transducer in the same manner you did for the 3 o'clock transducer. Ensure that the inside edge of the transducer (opposite the cable connection) is even with the point just marked on the 9 o'clock side of the pipe. (Figure 4.4-N)
- 15. Mount the transducers by following steps in Section 6.7 (page 32). (Figure 4.4-O)





FIGURE 4.4-O: Z MOUNT, STEP 15

The figure below illustrates the final Z method installation.



4.4.4 WV and WW Methods

For applications with pipe diameters smaller than 2 inches (50 millimeters), the WV and WW methods are options to achieve higher accuracy and stability when reasonable signal strength can be obtained (10% or higher).

4.5 Small Pipe Applications

In this section, small pipe applications refer to the following pipe sizes:

- stainless steel or brass: 1.0 to 3.5 in (25.4 to 88.9 mm)
- PVC, carbon steel, or other: 1.0 to 2.5 in (25.4 to 63.5 mm).

If signal strength is greater than 10%, we recommend the W mounting method for pipe sizes 3.5 in (63.5 mm) or smaller and the WW mounting method for pipe sizes 2.0 in (50.8 mm) or smaller.

The pipe curve effect on small pipe applications can cause multipath signals and measurement uncertainty. Removing extra compound along the transducer sides can eliminate the side wave paths as seen in Figure 4.5-A (below). Follow these steps to eliminate these side wave paths:

- 1. Apply coupling compound as usual on to the coupling surfaces, and clamp the transducers onto the pipe.
- 2. Use a pen-sized, standard screwdriver to remove the extra grease between the transducers and the pipe (Figure 4.5-A, below).



For high temperature or outdoor small pipe applications, use the foam tape strips shipped with the flowmeter to block the side wave paths. **Other tape materials generally do not satisfy performance or safety specifications.** Please contact the Thermo Customer Service Department when more tape strips are needed.

1. Wipe grease off the coupling surfaces of both transducers. Clean the surfaces with detergent and let dry. (Figure 4.5-B)



FIGURE 4.5-B: APPLYING FOAM TAPE STRIPS, STEP 1

- 2. Draw 2 lines on each transducer surface with a pencil so that the band defined by the lines is in the middle of the surface. The spacing between the 2 lines should be as follows:
- 3.0 to 3.5 in pipes: 0.50 in (76.2 to 88.9 mm pipes: 12.7 mm);
- 2.5 to 3.0 in pipes: 0.44 in (63.5 to 76.2 mm pipes: 11.2 mm);
- 2.0 to 2.5 in pipes: 0.38 in (50.8 to 63.5 mm pipes: 9.7 mm);
- 1.5 to 2.0 in pipes: 0.32 in (38.1 to 50.8 mm pipes: 8.13 mm);
- 1.5 in and smaller pipes: 0.25 in (38.1 mm and smaller pipes: 6.35 mm). (Figure 4.5-C)
- Remove the adhesive protection paper to expose the tape strips. Place a strip on each side of the surface along the line. Press the strips down to ensure good adhesion. (Figure 4.5-D)





FIGURE 4.5-C: APPLYING FOAM TAPE STRIPS, STEP 2



FIGURE 4.5-D: APPLYING FOAM TAPE STRIPS, STEP 3



FIGURE 4.5-E: APPLYING FOAM TAPE STRIPS, STEP 4

5. Emergency Overrides & Master Erase

Since these 2 procedures allow critical data to be accessed and changed, this page may be removed from the instruction manual to prevent unauthorized use of these features.

5.1 Emergency Overrides

In the event that a user-entered password is forgotten, the following emergency override passwords may be used: **42** for the system password and **43** for the scale factor password. These override passwords may not be changed or disabled.

5.2 Performing a Master Erase

This function erases all user-entered data AND data in the datalogger. Note all configuration settings and download the datalog file if a record is desired prior to performing a Master Erase.

- 1. Turn the flowmeter off and back on again.
- 2. When the message **INITIALIZING...** is displayed, press **ERASE** within 3 seconds.
- 3. The **Master Erase** screen is displayed (Figure 5-A). To continue with the Master Erase, press the **5** key within 3 seconds, and Figure 5-B is displayed.
- 4. Press the . (decimal) key within 3 seconds to continue.
- 5. If the Master Erase function is completed, Figure 5-C is displayed. If the function is not completed, Figure 5-D is displayed.
- 6. Enter all configuration data.

Master Erase.

Are you sure?(5=yes)

FIGURE 5-A

Master Erase.Are you

really sure? (.=yes)

FIGURE 5-B

Master Erase

Completed

FIGURE 5-C

Master Erase Aborted

FIGURE 5-D

6. FLOWMETER MAINTENANCE & TROUBLESHOOTING

6.1 Replacing the Fuse



Prevent possible electrical shock and/or damage to the meter-disconnect power to the meter PRIOR to wiring.

6.1.1 Flowmeter Fuse

The fuse located on the front panel of the flowmeter (upper right corner) protects the instrument from overcurrent or short circuits from the internal battery. It is rated at 3 A, 250 V. The sheetmetal access cover does not need to be removed since it has a hole for accessing the fuse. To replace the fuse:

- 1. Disconnect power from the flowmeter, and determine the cause of the fuse failure; correct if known.
- 2. Open the door of the flowmeter, and use a small, flat-bladed screwdriver to remove the fuse and replace it with another fuse of the same rating.
- 3. Reconnect power to the flowmeter and verify that the unit operates properly, e.g. the newly-installed fuse does not blow.

6.1.2 Breakout Box Fuse

The fuse located in the breakout box protects the instrument from overcurrent from the battery charger/AC adapter output. To replace the fuse:

- 1. Disconnect power from the flowmeter and disconnect the breakout box from the flowmeter and battery charger/AC adapter.
- 2. Remove the 4 screws from the cover of the breakout box, and use a small, flat-bladed screwdriver, to remove the fuse and replace it with another fuse of the same rating.
- 3. Reconnect power to the flowmeter and the breakout box to the battery charger/AC adapter, and verify that the unit operates properly.

6.2 Charging the Printer Battery

Charging the printer battery is a simple procedure. Connect the printer to the printer power cable on the breakout box (if battery charger/AC adapter is connected). Note the following cautions PRIOR to charging the printer battery:



• If the battery is fully discharged, the battery charge time is 15 hours. DO NOT charge for more than 24 hours.



• Do not connect the battery charger/AC adapter directly to the printer. The voltage and polarity output of the charger do not match required input of the printer. If they are directly connected, the printer battery can explode or the printer can be seriously damaged.

6.3 Charging the Flowmeter

The DCT7088 is a DC-powered instrument that normally operates from the internal 12-V battery supplied with the unit. It may also be powered by one of the following sources which connect to the 12-15 Vdc input on the breakout box:

- battery charger/AC adapter, which converts a 90 to 64 Vac, 50/60 Hz, 15-W input to a 15 Vdc output;
- automobile cigarette lighter adapter, which provides a 12 Vdc output.

If the battery charger/AC adapter is connected, it simultaneously powers the flowmeter and recharges or maintains the charge on the internal battery. The battery charges at a slower rate when the charger/ adapter is used to power the unit and charge the battery.

6.4 Replacing Sonic Coupling Compound

Any voids or air gaps that exist in the coupling compound beneath the transducers can reduce the signal and render the flowmeter inoperative. Coupling compound should be protected from washout and replaced as required. Annual replacement is recommended for most applications to maintain optimal performance.

To replace the coupling compound:

- 1. Remove the transducers from the pipe.
- 2. Clean the old compound from the transducers and the pipe.
- 3. Apply a wide bead of compound lengthwise down the center of each transducer face.
- 4. Remount the transducers, verifying that the compound is squeezing out from underneath all sides of the transducers and forming a bead along the edges.

We recommend the following sonic coupling compounds:

- Sil-Glyde[®] (American Grease Stick Company): made from a silicon base and suited for most transducer installations; rated for pip skin temperatures from -40° to +212° F (-40° to +100° C);
- Dow Corning[®] 111 or similar high temperature couplant: can be used for applications with pipe skin temperatures up to 300° F (150° C);
- General Electric RTV-108 or similar silicon RTV: should be used for underground or submerged transducer sites or sites where a more permanent bond is required; RTV should be completely cured prior to covering up the transducer site or taking readings;
- Krautkramer[®] Hitempco (Thermo P/N 22861-0001): good high temperature couplant; should be used with optional high temperature transducers rated up to 392° F (200° C).



The transducers should not be bonded with epoxy.

Troubleshooting & Support 6.5

6.5.1 General

If the unit does not perform satisfactorily, complete the following steps until the problem is resolved:

- 1. Verify that the flowmeter is properly installed and that the installation site is suitable.
- 2. Verify that the flowmeter is properly configured.
- 3. Perform a Master Erase.
- 4. Contact the installation contractor or representative through whom the flowmeter was purchased.
- 5. Contact Thermo to attempt to resolve the problem over the phone.
- 6. If we determine the problem cannot be resolved over the phone, return the entire unit to the factory.

6.5.2 Local Representative Support

The local Thermo representative is the first contact for support and is well equipped to answer questions and provide application assistance. Your representative has access to product information and current software revisions.

6.5.3 Service & Returns

If it becomes necessary to contact the Thermo Service Center with software or hardware problems, please have the following information available:

- signal strength •
- pipe orientation

transducer type and mounting configuration pipe OD

•

- pipe ID
- fluid type
- liner thickness

- pipe material • liner material
- model and serial numbers.
- To return an instrument:
- 1. Contact the Thermo Service Center for an RMA number (issued by the service representative). The receiving dock does not accept shipments without the RMA number.

You can contact the us at any of the following:

- phone: (713) 272-0404 • fax: (713) 272-5388
- address: listed below web: www.thermo.com •
- 2. Ensure the instrument is well packed, in its original shipping box if available.
- 3. Include a letter fully explaining the symptoms of the failure as well as detail describing the application where the unit was being operated (type of fluid, pipe size, pipe material, fluid velocity, etc.).
- 4. Write the RMA number on the **outside** of the shipping box.
- 5. Send the unit freight-paid to:

Thermo Electron Corporation Process Instruments Division 9303 W. Sam Houston Parkway S. Houston, TX 77099 USA

6.5.4 Upgrades

Thermo provides the most current software for your meter at time of shipment. Find out about upgrades by contacting Thermo via mail, fax, phone, or web. Upgrades are available using the RS232 port and a remote terminal.

6.6 Warranty Statement

Thermo products are warranted to be free from defects in material and workmanship at the time of shipment and for one year thereafter. Any claimed defects in Thermo products must be reported within the warranty period. Thermo shall have the right to inspect such products at Buyer's plant or to require Buyer to return such products to Thermo plant.

In the event Thermo requests return of its products, Buyer shall ship with transportation charges paid by the Buyer to Thermo plant. Shipment of repaired or replacement goods from Thermo plant shall be F.O.B. Thermo plant. A shop charge may apply for alignment and calibration services. Thermo shall be liable only to replace or repair, at its option, free of charge, products which are found by Thermo to be defective in material or workmanship, and which are reported to Thermo within the warranty period as provided above. This right to replacement shall be Buyer's exclusive remedy against Thermo.

Thermo shall not be liable for labor charges or other losses or damages of any kind or description, including but not limited to, incidental, special or consequential damages caused by defective products. This warranty shall be void if recommendations provided by Thermo or its Sales Representatives are not followed concerning methods of operation, usage and storage or exposure to corrosive conditions.

Materials and/or products furnished to Thermo by other suppliers shall carry no warranty except such suppliers' warranties as to materials and workmanship. Thermo disclaims all warranties, expressed or implied, with respect to such products.

EXCEPT AS OTHERWISE AGREED TO IN WRITING BY Thermo, THE WARRANTIES GIVEN ABOVE ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, AND Thermo HEREBY DISCLAIMS ALL OTHER WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR PURPOSE.

APPENDIX A: PIPE SCHEDULES

This appendix provides pipe schedules as a convenient reference for the following pipe materials: steel, stainless steel, and PVC (Table A-1); cast iron (Table A-2); ductile iron (Table A-3).

The inside diameters (IDs) listed in the following tables are calculated from the outside diameter (OD) and minimum wall thicknesses as specified in applicable standards. The actual pipe ID may vary from the dimension listed in the tables by as much as 25% of the pipe minimum wall thickness. The accuracy of flow rate measurement is enhanced if the pipe ID is actually measured.

			Steel Insid	l, Stainl e Diame	ess Ste eter (ID)	Tal el and l and Ou	ble A-1 PVC Piț utside I	oe Stan Diamete	dard Sc ir (OD) i	chedule in Inche	Si			
Nominal Pipe Size()	Outside Diameter (OD)	Sched. 5	Sched. 10 (Light Wall)	Sched. 20	Sched. 30	Sched. 40	Sched. 60	Sched. 80	Sched. 100	Sched. 120	Sched. 140	Sched. 160	Std. Wall	X STG
1 1.25 1.5 2.5 2.5	1.315 1.660 1.900 2.375 2.875	1.185 1.530 1.770 2.245 2.709	1.097 1.442 1.682 2.157 2.635			1.049 1.380 1.610 2.067 2.469		0.957 1.278 1.500 1.939 2.323				0.815 1.160 1.338 1.687 2.125	1.049 1.380 1.610 2.067 2.469	0.957 1.278 1.500 1.939 2.323
ດ ທ 4 ກ ກ	3.500 4.000 4.500 5.563 6.625	3.334 3.834 4.334 5.345 6.407	3.260 3.760 4.260 5.295 6.357			3.068 3.548 4.026 5.047 6.065		2.900 3.364 3.826 4.813 5.761		3.624 4.563 5.501		2.624 3.438 4.313 5.187	3.068 3.548 4.026 5.047 6.065	2.900 3.364 3.826 4.813 5.761
8 112 16 16 16 12 12 12 12 12 12 12 12 12 12 12 12 12	8.625 10.750 12.750 14.000 16.000	8.407 10.482 12.438 15.670	8.329 10.420 12.390 13.500 15.500	8.125 10.250 12.250 13.376 15.376	8.071 10.136 12.090 13.250 15.250	7.981 10.020 11.938 13.124 15.000	7.813 9.750 11.626 12.812 14.688	7.625 9.562 11.374 12.500 14.312	7.437 9.312 11.062 12.124 13.938	7.187 9.062 10.750 11.876 13.562	7.001 8.750 10.500 11.500 13.124	6.813 8.500 10.126 11.188 12.812	7.981 10.020 12.000 13.250 15.250	7.625 9.750 11.750 13.000 15.000
18 20 33 30	18.000 20.000 24.000 36.000 36.000	17.670 19.634 23.564 29.500	17.500 19.500 23.500 29.376 35.376	17.376 19.250 23.250 29.000 35.000	17.124 19.000 22.876 28.750 34.750	16.876 18.812 22.624 28.500 34.500	16.500 18.376 22.062	16.124 17.938 21.562	15.688 17.438 20.938	15.255 17.000 20.376	14.876 16.500 19.876 31.876	14.438 16.062 19.312 31.312	17.250 19.250 23.250 29.250 35.250	17.000 19.000 23.000 29.000 35.000
42 48	42.000 48.000			41.000	40.750	40.500 47.250							41.250 47.250	41.000 47.000

	Чs	Q	6.00 8.00 10.00	12.00 14.00 16.00 20.00	24.00		
	Clas	do	7.38 9.60 11.84	14.08 16.32 18.54 20.78 23.02	27.76		è A-3.
	ss G	QI	6.08 8.10 10.12	12.14 14.18 16.18 18.22 20.24	24.26		isted in Table
	Clas	QD	7.38 9.60 11.84	14.08 16.32 18.54 20.78 23.02	27.76		nesses are li
Inches	ss F	Q	6.00 8.10 10.00	12.00 14.00 16.00 20.00 20.00	24.00 30.00 36.00		it lining thick
DD) in	Cla	QD	7.22 9.42 11.60	13.78 15.98 18.16 20.34 22.54	26.90 33.46 40.04		ouble cemer
lasses eter (C	ss E	QI	6.06 8.10 10.12	12.14 14.18 16.20 18.20 20.24	24.28 30.00 36.00		ndard and d
2 dard C e Diam	Cla	QO	7.22 9.42 11.60	13.78 15.98 18.16 20.34 22.54	26.90 33.10 39.60		kness. Sta
ible A- e Stanc Dutside	ss D	Q	3.00 3.96 6.00 8.10 10.04	12.00 14.01 16.02 18.00 20.00	24.00 30.00 36.00 42.02 48.00	53.94 60.06	he lining thic
Ta on Pipe and C	Cla	QD	3.96 5.00 7.10 9.30 11.40	13.50 15.65 17.80 19.92 22.06	26.32 32.74 39.16 45.58 51.98	58.40 64.82	y two times t
ast Irc er (ID)	ss C	Q	3.06 4.04 6.08 8.18 10.16	12.14 14.17 16.20 18.18 20.22	24.22 30.00 35.98 42.02 47.98	54.00 60.20 72.10	e diameter b
C Diamet	Cla	QO	3.96 5.00 7.10 9.30 11.40	13.50 15.65 17.80 19.92 22.06	26.32 32.40 38.70 45.10 51.40	57.80 64.20 76.88	ne pipe inside
Inside D	ss B	Q	3.12 4.10 6.14 8.03 9.96	11.96 13.98 16.00 18.00 20.00	24.02 29.94 36.00 41.94 47.96	54.00 60.06 72.10 84.10	gs, reduce th
	Cla	QO	3.96 5.00 7.10 9.05 11.10	13.20 15.30 17.40 19.50 21.60	25.80 32.00 38.30 44.50 50.80	57.10 63.40 76.00 88.54	cement linin
	ss A	Q	3.02 3.96 6.02 8.13 10.10	12.12 14.16 16.20 18.22 20.26	24.28 28.98 35.98 42.00 47.98	53.96 60.02 72.10 84.10	or pipes with
	Cla	QO	3.80 4.80 6.90 9.05 11.10	13.20 15.30 17.40 19.50 21.60	25.80 31.74 37.96 44.20 50.50	56.66 62.80 75.34 87.54	NOTE: Fc
		Nominal Pipe Size ()	4 4 8 10	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	24 30 42 48	54 60 72 84	

		Insi	Du ide Diamet	ictile Iron er (ID) and	Table A-3 Pipe Stanc d Outside I Inside Diameter	lard Class Diameter ((es OD) in Incl	hes	Cement Linin.	g (See Note)
Nominal Pipe Size	Outside Diameter (OD)	Class 50	Class 51	Class 52	Class 53	Class 54	Class 55	Class 56	Standard Thickness	Double Thickness
6 4 9 8 0 7 7 0 8 0 7	3.96 4.80 6.90 9.05 11.10 13.20	6.40 8.51 10.52 12.58	3.46 3.46 6.34 8.45 10.46 12.52	3.40 3.40 6.28 8.39 10.40 12.46	3.34 3.34 6.22 8.33 10.34 12.40	3.28 4.10 6.16 8.27 10.28 12.34	3.22 4.04 6.10 8.21 10.22 12.28	3.16 3.98 6.04 8.15 10.16 12.22	0.125	0.250
14 16 20 24	15.30 17.40 19.50 21.60 25.80	14.64 16.72 18.80 20.88 25.04	14.58 16.66 18.74 20.82 24.98	14.52 16.60 18.68 20.76 24.92	14.46 16.54 18.62 20.70 24.86	14.40 16.48 18.56 20.64 24.80	14.34 16.42 18.50 20.58 24.74	14.28 16.36 18.44 20.52 24.68	0.1875	0.375
30 36 42 54	32.00 38.30 44.50 50.80 57.10	31.22 37.44 43.56 49.78 55.96	31.14 37.34 43.44 49.64 55.80	31.06 37.06 43.32 49.50 55.64	30.98 37.14 43.20 49.36 55.48	30.90 37.04 43.08 49.22 55.32	30.82 36.94 42.96 49.08 55.16	30.74 36.84 42.84 48.94 55.00	0.250	0.500
Note: For pipes	s with cement lining	s, reduce the pipe i	inside diameter by	two times the linin	g thickness listed a	bove.				

APPENDIX B: FLUID PROPERTIES

B.1 Fluid Sound Velocities & Kinematic Viscosities

This section provides a table of fluid sound speeds and kinematic viscosities. The information is based on material from the *Cameron Hydraulic Data Book* (17th ed., Ingersoll-Rand, 1988) and *Table of Physical and Chemical Constants* (13th ed., Longmans, 1966).

Note that viscosity does not have as significant an effect on flow accuracy as sound speed since viscosity is only used to calculate flow profile. Even a comparatively large error in viscosity results in a change of only 2 to 5 percent.

LIQUID	ť°C	c(m/s)	t° F	c(ft/s)	cSt
Acetaldehyde CH ₃ CHO	16.1 20		61 68		0.305 0.295
Acetic acid	50	1584	122	5196	
10%	15		59		1.35
50%	15		59		2.27
80%	15		59		2.85
Concglacial	15		59		1.34
Acetic anhydride	24 15	1384 	75 59	4540 	 0.88
Acetone CH ₃ COCH ₃	20	1190	68	3903	0.41
Acetylene tetrabromide	28	1007	82	3303	
Acetylene tetrachloride	28	1155	82	3788	
Alcohol allyl	20 40		68 104		1.60 0.90
butyl-n	20 70		68 158		3.64 1.17
ethyl (grain) C ₂ H ₅ OH	20 37.8		68 100		1.52 1.2
methyl (wood) CH ₃ OH	15 0		59 32		0.74 1.04
propyl	20 50		68 122		2.8 1.4
Ammonia	-17.8		0		0.30

LIQUID	Т°С	c(m/s)	ťF	c(ft/s)	cSt
Amyl acetate	29.2	1173	85	3847	
n-Amyl alcohol	28.6	1224	83	4015	
iso-Amyl ether	26	1153	79	3782	
Aniline	20 10	1656 	68 50	5432 	4.37 6.4
Argon	-183.0	816.7	-297	2679	
Asphalt, blended RC-0, MC-0, SC-0	25 37.8		77 100		159 - 324 60 - 108
RC-1, MC-1, SC-1	37.8 50		100 122		518 - 1080 159 - 324
RC-2, MC-2, SC-2	50 60		122 140		518 - 1080 215 - 430
RC-3, MC-3, SC-3	50 60		122 140		1295 - 2805 540 - 1080
RC-4, MC-4, SC-4	60 82.8		140 180		1725 - 4315 270 - 540
RC-5, MC-5, SC-5	60 82.8		140 180		6040 - 18340 647 - 1295
RS-1, MS-1, SS-1	25 37.8		77 100		33 - 216 19 - 75
Asphalt emulsions Fed #1	25 37.8		77 100		215 - 1510 75 - 367
Fed #2, V, VI	25 37.8		77 100		33 - 216 19 - 75

LIQUID	t° C	c(m/s)	t° F	c(ft/s)	cSt
Automotive crankcase oils SAE-5W	-17.8		0		1295 max
SAE-10W	-17.8		0		1295 - 2590
SAE-20W	-17.8		0		2590 - 10350
SAE-20	98.9		210		5.7 - 9.6
SAE-30	98.9		210		9.6 - 12.9
SAE-40	98.9		210		12.9 - 16.8
SAE-50	98.9		210		16.8 - 22.7
Automotive gear oils SAE-75W	98.9		210		4.2 min
SAE-80W	98.9		210		7.0 min
SAE-85W	98.9		210		11.0 min
SAE-90	98.9		210		14 - 25
SAE-14Q	98.9		210		25 - 43
SAE 150	98.9		210		43 min
Beer	20		68		1.8
Benzene (Benzol) C ₆ H ₆	20 0	1321 	68 32	4333 	0.744 1.00
Benzophenone	100	1316	212	4316	
Bismuth	285	1663	545	5455	
Bone Oil	54.4 100		130 212		47.5 11.6
Bromine	20		68		0.34
Bromobenzene	50	1074	122	3523	
Bromoform	25	908	77	2978	
Butane-n	-1.1 		-50 30		0.52 0.35
Butyl acetate	30	1172	86	3844	
n-Butyl alcohol	20	1257.7	68	4125	
iso-Butyl bromide	-104	1450	-155	4756	
Butyric acid n	20 0		68 32		1.61 2.3cp
Cadmium	360	2150	680	7052	

LIQUID	t° C	c(m/s)	t° F	c(ft/s)	cSt
Caesium	130	967	266	3172	
Calcium chloride 5%	18.3		65		1.156
25%	15.6		60		4.0
Carbolic acid (phenol)	18.3		65		11.83
Carbon tetrachloride CCI₄	20 37.8		68 100		0.612 0.53
Carbon disulphide CS_2	25 0 20	1149 	77 32 68	3769 	 0.33 0.298
Carbon tetrachloride	20	938	68	3077	
Castor oil	18.6 37.8 54.4	1500 	65 100 130	4920 	 259-325 98-130
China wood oil	20.6 37.8		69 100		308.5 125.5
Chlorine	20	850	68	2788	
m-Chlornitrobenzene	40	1368	104	4487	
Chlorobenzene	25	1302	77	4271	
Chloroform	20 25 60	 995 	68 77 140	 3264 	0.38 0.35
Cocoanut oil	37.8 54.4		100 130		29.8 - 31.6 14.7 - 15.7
Cod oil	37.8 54.4		100 130		32.1 19.4
Corn oil	54.4 100		130 212		28.7 8.6
Corn starch solutions 22 Baume	21.1 37.8		70 100		32.1 27.5
24 Baume	21.1 37.8		70 100		129.8 95.2
25 Baume	21.1 37.8		70 100		303 173.2

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
Cotton seed oil	37.8 54.4		100 130		37.9 20.6
Crude Oil 48°API	15.6 54.4		60 130		3.8 1.6
40°API	15.6 54.4		60 130		9.7 3.5
35.6 API	15.6 54.4		60 130		17.8 4.9
32.6 API	15.6 54.4		60 130		23.2 7.1
Salt Creek	15.6 54.4		60 130		77 6.1
Cyclohexane	20	1278	68	4192	
Cyclohexanol	30	1622	86	5320	
Decane-n	-17.8 37.8		0 100		2.36 1.001
I-Decene	20	1250	68	4100	
Deuterium oxide	20	1381	68	4530	
Diesel fuel oils 2D	37.8 54.4		100 130		2 - 6 1 - 3.97
3D	37.8 54.4		100 130		6 - 11.75 3.97 - 6.78
4D	37.8 54.4		100 130		29.8 max 13.1 max
5D	50 71.1		122 160		86.6 max 35.2 max
Diethyl Ether	20		68		0.32
Diethylene glycol	21.1 30	 1533	70 86	 5028	32
Diethylene glycol monoethyl ether	30	1296	86	4251	
Dimethyl siloxane (Dow Corning [®] 200 fluid)	20	912.3	68	2992	

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
Diphenyl	100	1271	212	4169	
Diphenyl ether	30	1462	86	4795	
Ethanol	20	1156	68	3792	
Ethanol amide	25	1724	77	5655	
Ether (diethyl)	25	985	77	3231	
Ethyl acetate $CH_3COOC_2H_5$	15 20	 1133	59 68	 3716	0.4 0.49
Ethyl alcohol	20	1161.8	68	3811	
Ethyl bromide C_2H_5Br	10 20	932	50 68	3057 	 0.27
Ethyl glycol	30	1606	86	5268	
Ethyl iodide	20	876	68	2873	
Ethylene bromide	20		68		0.787
Ethylene chloride	20		68		0.668
Ethylene dibromide	24	1014	75	3326	
Ethylene dichloride	23	1240	73	4067	
Ethylene glycol	21.1 30	 1616	70 86	 5300	17.8
Ethylene glycol monoethyl ether	30	1279	86	4195	
Ethylene glycol monomethyl ether	30	1339	86	4392	
Formaldehyde	25	1587	77	5205	
Formamide	25	1610	77	5281	
Formic acid 10%	20 20	1299 	68 68	4261 	 1.04
50%	20		68		1.2
80%	20		68		1.4
Conc	20		68		1.48

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
Freon -11	21.1		70		0.21
-12	21.1		70		0.27
-21	21.1		70		1.45
Fuel Oils 1	21.1 37.8		70 100		2.39 - 4.28 2.69
2	21.1 37.8		70 100		3.0 - 7.4 2.11 - 4.28
3	21.1 37.8		70 100		2.69 - 5.84 2.06 - 3.97
5A	21.1 37.8		70 100		7.4 - 26.4 4.91 - 13.7
5B	21.1 37.8		70 100		26.4- 13.6 - 67.1
6	50 71.1		122 160		97.4 - 660 37.5 - 172
Gallium	50	2740	122	8987	
Gas oils	21.1 37.8		70 100		13.9 7.4
Gasolines a	15.6 37.8		60 100		0.88 0.71
b	15.6		60		0.64
C	15.6 37.8		60 100		0.46 0.40
Glycerine 100%	30 20.3 37.8	1923 	86 69 100	6307 	 648 176
50% Water	20 60		68 140		5.29 1.85cp
Glucose	37.8 65.6		100 150		7.7M - 22M 880 - 2420
Guaicol	100	1252	212	4107	
Helium	-268.8	179.8	-452	590	

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
n-Heptane	-17.8 22.4 37.8	 1150 	0 72 100	 3772 	0.928 0.511
Heptene	30	1082	86	3549	
Heptyne	30	1159	86	3802	
Hexane	20	1203	68	3946	
n-Hexane	-17.8 21.2 37.8	 1085 	0 70 100	 3559 	0.683 0.401
Honey	37.8		100		73.6
Hydrogen	-256	1187	-429	3893	
Industrial lubricants Turbine oils 685 SSU at 100 [°] F	15.6 93.3		60 200		647 14.5
420 SSU	15.6 93.3		60 200		367 11
315 SSU	15.6 93.3		60 200		259 8
215 SSU	15.6 93.3		60 200		151 7.3
150 SSU	15.6 93.3		60 200		99 6
Machine lubricants #8	37.8 54.4		100 130		23 - 34 13 - 18
#10	37.8 54.4		100 130		34 - 72 18 - 25
#20	37.8 54.4		100 130		72 - 83 25 - 39
#30	37.8 54.4		100 130		75 - 119 39 - 55

LIQUID	t [°] C	c(m/s)	t° C	c(ft/s)	cSt
Machine lubricants, cont					
Cutting oils					
#1	37.8		100		30 - 40
	54.4		130		17 - 23
#2	37.8 54.4		100 130		40 - 46 23 - 26
Indium	260	2215	500	7265	
Ink, printers	37.8		100		550 - 2200
	54.4		130		238 - 660
Insulating oil	21.1		70		24.1 max
	37.8		100		11.75 max
Kerosene	20		68		2.71
	25	1315	77	4313	
Jet Fuel (av)	-34.4		-30		7.9
Lard	37.8		100		62.1
	54.4		130		34.3
Lard oil	37.8		100		41 - 47.5
	54.4		130		23.4 - 27.1
Lead	340	1760	644	5773	
Linseed oil	37.8		100		30.5
	54.4		130		18.94
Menhadden oil	37.8		100		29.8
	54.4		130		18.2
Menthol	50	1271	122	4169	
Merck	20.2	1482.3	68	4862	
Mercury	20	1454	68	4769	
	21.1 37.8		70 100		0.118
Methanol	20	1118	68	3667	0.11
Mathylacotata			00		
wethyl acetate	20 30	 1131	68 86	 3710	0.44
Methyl alcohol	20	1121.2	68	3678	
Methyl bromide	2	905	36	2968	

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
Methylene chloride	23.5	1064	74	3490	
Methylene iodide	24	977.7	75	3207	
Milk	20		68		1.13
Molasses A, first	37.8 54.4		100 130		281 - 5070 151 - 1760
B, second	37.8 54.4		100 130		1410 - 13.2M 660 - 3.3M
C, blackstrap	37.8 54.4		100 130		2630 - 55M 1320 - 16.5M
Naphthalene	80		176		0.9
Naptha	25	1225	77	4018	
Neatsfoot oil	37.8 54.4		100 130		49.7 27.5
Nitrobenzene	20 23.8	 1462	68 75	 4795	1.67
Nitrogen	-188.9	744.7	-308	2443	
Nonane	20	1248	68	4093	
I-Nonene	20	1218	68	3995	
Nonene-n	-17.8 37.8		0 100		1.728 0.807
n-Octane	-17.8 20 37.8	 1192 	0 68 100	 3910 	1.266 0.645
Oil (lubricating)	10	1625	50	5330	
Oil of camphor	25	1390	77	4559	
Oleic acid	20	1442	68	4730	
Olive oil	21.7 37.8 54.4	1440 	71 100 130	4723 	 43.2 24.1
Oxygen	-182.9	912	-297	2991	
Palm oil	37.8 54.4		100 130		47.8 26.4

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
Paraldehyde	28	1197	82	3926	
Peanut oil	37.8 54.4		100 130		42 23.4
I-Pentadecene	20	1351	68	4431	
Pentane	20	1008	68	3306	
iso-Pentane	25	985	77	3231	
n-Pentane	-17.8 20 26.7	 1044 	0 68 80	 3424 	0.508 0.342
Petrolatum	54.4 71.1		130 160		20.5 15
Petroleum ether	15.6		60		31(est)
Phenol	100	1274	212	4179	
Potassium	150	1840	302	6035	
n-Propanol	20	1220	68	4002	
Propionic acid	20		68		1.13
n-Propyl acetate	26	1182	79	3877	
n-Propyl alcohol	20	1223.2	68	4012	
Propylene glycol	21.1		70		52
Pyridine	20	1445	68	4740	
Quenching oil (typical)					100 - 120
Rapeseed oil	37.8 54.4		100 130		54.1 31
Rosin oil	37.8 54.4		100 130		324.7 129.9
Rosin (wood)	37.8 93.3		100 200		216 - 11M 108 - 4400
Rubidium	160	1260	320	4133	
Sesame seed oil	37.8 54.4		100 130		39.6 23
Silicon tetrachloride	30	766.2	86	2513	

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
Sodium	150	2500	302	8200	
Sodium chloride (fused)	850	1991	1562	6530	
5%	20		68		1.097
25%	15.6		60		2.4
Sodium hydroxide (caustic soda) 20%	18.3		65		4.0
30%	18.3		65		10.0
Soya bean oil	37.8 54.4		100 130		35.4 19.64
Sperm oil	37.8 54.4		100 130		21 - 23 15.2
Sugar solutions Corn syrup 86.4 Brix	37.8 82.2		100 180		180Мср 1750ср
84.4 Brix	37.8 82.2		100 180		48Mcp 800cp
82.3 Brix	37.8 82.2		100 180		17Мср 380ср
80.3 Brix	37.8 82.2		100 180		6900ср 230ср
78.4 Brix	37.8 82.2		100 180		3200cp 160cp
Sugar solutions Sucrose 60 Brix	21.1 37.8		70 100		49.7 18.7
64 Brix	21.1 37.8		70 100		95.2 31.6
68 Brix	21.1 37.8		70 100		216.4 59.5
72 Brix	21.1 37.8		70 100		595 138.6
74 Brix	21.1 37.8		70 100		1210 238

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
Sugar solutions, cont Sucrose 76 Brix	21.1		70		2200
	37.8		100		440
Sulphur	130	1332	266	4369	
Sulphuric acid 100%	20		68		14.6
95%	20		68		14.5
60%	20		68		4.4
Tar, coke oven	21.1 37.8		70 100		600 - 1760 141 - 308
Tar, gas house	21.1 37.8		70 100		3300 - 66M 440 - 4400
Tar, pine	37.8 55.6		100 132		559 108.2
Tar, road - RT-2	50 100		122 212		43.2 - 64.9 8.88 - 10.2
RT-4	50 100		122 212		86.6 - 154 11.6 - 14.3
RT-6	50 100		122 212		216 - 440 16.8 - 26.2
RT-8	50 100		122 212		660 - 1760 31.8 - 48.3
RT-10	50 100		122 212		4.4M - 13.2M 53.7 - 86.6
RT-12	50 100		122 212		25M - 75M 108 - 173
Tetralin	20	1484	68	4868	
Tin (molten)	240	2470	464	8102	
Toluene	20 30	 1275	68 86	 4182	0.68
o-Toluidine	22.5	1669	73	5474	
I-Tridecene	20	1313	68	4307	

LIQUID	t [°] C	c(m/s)	t [°] F	c(ft/s)	cSt
Trielhylene glycol	21.1		70		40
Triethylamine	0	1189	32	3900	
Turpentine	25 37.8 54.4	1225 	77 100 130	4018 	 86.6 - 95.2 39.9 - 44.3
I-Undecene	20	1275	68	4182	
Varnish, spar	20 37.8		68 100		313 143
Water distilled	20	1482.9	68	4864	1.0038
fresh	15.6 54.4		60 130		1.13 0.55
sea					1.15
Water (sea) (surface, 3.5% salinity)	15	1507.4	59	4944	
Whale oil	37.8 54.4		100 130		35 - 39.6 19.9 - 23.4
Xylene hexafluoride	25	879	77	2883	
o-Xylene	20 22	 1352	68 72	 4435	0.93
Zinc	450	2700	842	8856	

B.2 Clean Water Sound Speed Versus Temperature

F٥	C⁰	ft/s	m/s	F٥	C°	ft/s	m/s
32	0	4599.8	1402.019	131	55	5075.4	1546.982
41	5	4677.8	1425.793	140	60	5087.2	1550.579
50	10	4747	1446.886	149	65	5095.3	1553.047
59	15	4808.3	1465.57	158	70	5099.7	1554.389
68	20	4862.1	1481.968	167	75	5100.8	1554.724
77	25	4909.1	1496.294	176	80	5098.7	1554.084
86	30	4949.9	1508.73	185	85	5093.6	1552.529
95	35	4985	1519.428	194	90	5085.6	1550.091
104	40	5014.7	1528.481	203	95	5074.8	1546.799
113	45	5039.4	1536.009	212	100	5068.4	1544.848
122	50	5059.6	1542.166	*see next page for graphical representation			



B.3 Relationship Between Specific Gravity, Viscosity, & Sound Velocity for Petroleum Products

This figure is a graph showing the approximate relationship between specific gravity, viscosity and sound velocities for aliphatic hydrocarbons (petroleum products).



*SEE TABLE FOR VISCOSITY OF VARIOUS TYPES OF CRUDE OIL ** MULTIPLY M/S BY 3.28 TO OBTAIN FT/S IF ENGLISH UNITS ARE REQUIRED

VISCOSITIES ARE APPROXIMATE. THIS NOMOGRAPH SHOULD BE APPLIED TO ALIPHATIC HYDROCARBONS AND MIXTURES THEREOF ONLY

APPENDIX C: MONITORING & DOWNLOADING DATALOGS USING D-LINK

D-Link is PC-based user interface software that can communicate with DCT6088 and DCT7088 flowmeters to monitor and download datalog information.

C.1 Installing D-Link

Start the PolyCD and select D-Link in Communication Software. Follow the instructions to install D-Link.

C.2 Establishing Communications with a Flowmeter

- 1. Go to the **Options Group** menu (42) and select *D-Link* in the communication options.
- 2. Connect a RS232 cable from the PC to the flowmeter.
- 3. Open the D-Link utility.

If a *Communication Failed* dialogue opens as shown in Figure C.2-A, click *OK*. Make necessary adjustments according to your PC setup (Figure C.2-B) and click *OK*.

DLink 🛛 🕅	🚾 CommPort Properties	×
DLink Communications Failed	CommPort Properties Properties Port: Com1 Maximum Speed 19200 Isseed Data Bits: 8 Parity: None Stop Bits: 1	OK Cancel

FIGURES C.2-A & C.2-B

If communications still do not establish check the following and correct any errors:

- D-Link is selected in communication Options Menu;
- RS232 cable is connected correctly between the meter and your PC;
- no other software program in your PC is using the COM port you selected.

C.3 Monitoring Datalogs

Once communications between the PC and the meter establish, the program opens as shown in Figure C.3-A (below). Click the arrow below *Get Log*, and select the log file you want to check. Click *Get Log*. The log information downloads and displays as seen in Figure C.3-B (page 77). Log information can be downloaded from the meter when the log is still running, so you can monitor the flow data without stop the log. Refer to Section 4.16 (page 28) for instructions on setting up the datalogger.

[™] D	Link1.1.6 - Datalog Retrieval DCT Series	_ 🗆 X
File	Log	
No D	atalog Loaded	GetLog 110802-1 110802-2 110802-3 110802-3 110802-4

FIGURE C.3-A: SELECTING A LOG TO DOWNLOAD



FIGURE C.3-B: DISPLAYED LOG

C.4 Saving & Loading Datalogs

To save the current displayed datalog to a file, go to *File* and select *Save Log.* The file can then be opened in data processing software such as Excel[®] for Windows[®].

To load a previously saved log file, go to File and select Load Log (refer to Figure C.4, page 78).

🚾 DLink1.1.6 - Datalog Retrieval DCT Series		. 🗆 X
File Log		
Load Log Save Log K About Quit		
4		•
No Datalog Loaded	Get I	Log T

FIGURE C.4