
Turbidimeters

(intensity)

()

()

가

Formazine

ASBC - America Society of Brewing Chemists.

EBC -

FAU - Formazine Attenuation units

(0 °)

: ISO 7027

FNU - Formazine Nephelometric Units

(90 °)

: ISO 7027

FTU - Formazine turbidity unit

NTU - Nephelometric turbidity unit

(90 °)

U.S. EPA(Environmental Protection Agency)

TE/F - "Trubungseinheit/Formazin"

, FNU

Formazine

:

1 EBC	1 FNU 1 NTU 1 FTU	1 ASBC	
1	0.25	0.014	EBC
4	1	0.057	FNU NTU FTU
70	17.5	1	ASBC

(SiO₂)

가

< >
,

Fromazine

(Angle)

가

Scatter angle	1 FTU	
25 °	2.25	ppm SiO₂
90 °	3.25	ppm SiO₂
135 °	7.5	ppm SiO₂

Reference: SIGRIST (Germany)