RS232 cable with 9 pin male/female connector – 2.5mm ear plug

Jack 2.5 mm

Connector
9 pin 25pin

9 pin	25pin
5	7
2	3
3	2
7	4
8	5
4	6
6	20

On the picture a scheme of connecting the meter with a PC is showed. On the right side of the picture way of connecting from the side of computer for 9 and 25 pin connector with the correct numbers of pins.