

Methods

The level of dissolved oxygen in natural waters is often a direct indication of quality, since aquatic plants produce oxygen, while microorganisms generally consume it as they feed on pollutants. At low temperatures the solubility of oxygen is increased; during summer, saturation levels can be as low as 4 ppm. Dissolved oxygen (D.O.) is essential for the support of fish and other aquatic life and aids in the natural decomposition of organic matter. Waste treatment plants that employ aerobic digestion must maintain a level of at least 2 ppm dissolved oxygen.

At elevated temperatures, oxygen is highly corrosive to metals, causing *pitting* in ferrous systems such as high-pressure boilers and deep well oil recovery equipment. To prevent costly corrosion damage, the liquids in contact with the metal surfaces must be treated, usually by a combination of physical and chemical means. Deaeration can reduce the dissolved oxygen concentration of boiler feedwater from several ppm to a few ppb. Chemical reducing agents such as hydrazine, DEHA, or sodium sulfite, may be used instead of or in conjunction with deaeration.

The Indigo Carmine Method

References: ASTM D 888-87, Colorimetric Indigo Carmine, Test Method A. Gilbert, T. W., Behymer, T. D., Castañeda, H. B., "Determination of Dissolved Oxygen in Natural and Wastewaters," *American Laboratory*, March 1982, pp. 119-134.

Test kits for environmental and drinking water applications (ppm range) employ the indigo carmine method. The reduced form of indigo carmine reacts with D.O. to form a blue product. The indigo carmine methodology is not subject to interferences from temperature, salinity, or dissolved gases such as sulfide, which plague users of D.O. meters. Results are expressed as ppm (mg/L) O₂.

The Rhodazine D™ Method

References: Developed by CHEMetrics, Inc. ASTM Power Plant Manual, 1st. ed. p. 169 (1984). ASTM D 5543-09, Low Level Dissolved Oxygen in Water. Department of the Navy, Final Report of NAVSECPHI-LADIV Project A-1598, Evaluation of CHEMetrics Feedwater Dissolved Oxygen Test Kit (1975).

Test kits for boiler waters and applications requiring trace levels of D.O. (ppb range) employ the Rhodazine D methodology. Developed by CHEMetrics, Inc., and approved by ASTM as the reference method for ppb D.O. determination, the Rhodazine D compound in reduced form reacts with dissolved oxygen to form a bright pink reaction product. The method is not subject to salinity or dissolved gas interferences. Oxidizing agents, including benzoquinone, can cause high results. Reducing agents such as hydrazine and sulfite do not interfere. Results are expressed as ppm (mg/L) or ppb (µg/L) O₂.

Low-range dissolved oxygen test kits include a special *sampling tube* (diagram) for use with boiler feedwater. This device allows the user to break the tip of the ampoule in a flowing sample stream in order to preclude error from contamination by atmospheric oxygen.





Range: 0-20 ppb MDL: 1 ppb / Method: Rhodazine D	
	Cat#
ULR CHEMets Kit	K-7511
ULR CHEMets Refill, 30 ampoules	R-7511
Comparator 0, 2, 4, 6, 8, 12, 16, 20 ppb	C-7511
Kit comes in a cardboard box and contains everything needed to perform 30 tests: Refill, Comparator, adhesive mounting clamp, permanent mounting clamp, sampling tube, instructions, and MSDS.	

Range: 5-180 ppb MDL: 5 ppb / Method: Rhodazine D	
	Cat#
CHEMets Kit	K-7518
CHEMets Refill, 30 ampoules, Shelf-life 12 months	R-7518
Comparator 5, 20, 40, 60, 80, 110, 140, 180 ppb	C-7518
Kit comes in a plastic case and contains everything needed to perform 30 tests: Refill, Comparator, adhesive mounting clamp, permanent mounting clamp, sampling tube, instructions, and MSDS.	

Range: 0-40 ppb MDL: 2.5 ppb / Method: Rhodazine D	
	Cat#
CHEMets Kit	K-7540
CHEMets Refill, 30 ampoules	R-7540
Comparator 0, 5, 10, 15, 20, 25, 30, 40 ppb	C-7540
Kit comes in a plastic case and contains everything needed to perform 30 tests: Refill, Comparator, adhesive mounting clamp, permanent mounting clamp, sampling tube, instructions, and MSDS.	

Range: 0-1 ppm MDL: 0.025 ppm / Method: Rhodazine D	
	Cat#
CHEMets Kit	K-7501
CHEMets Refill, 30 ampoules	R-7501
Comparator 0, 0.05, 0.1, 0.2, 0.3, 0.4, 0.6, 0.8, 1.0 ppm	C-7501
Kit comes in a plastic case and contains everything needed to perform 30 tests: Refill, Comparator, adhesive mounting clamp, permanent mounting clamp, sampling tube, 25 mL sample cup, instructions, and MSDS.	

Range: 0-100 ppb MDL: 5 ppb / Method: Rhodazine D	
	Cat#
CHEMets Kit	K-7599
CHEMets Refill, 30 ampoules	R-7540
Comparator 0, 10, 20, 30, 40, 60, 80, 100 ppb	C-7599
Kit comes in a plastic case and contains everything needed to perform 30 tests: Refill, Comparator, adhesive mounting clamp, permanent mounting clamp, sampling tube, instructions, and MSDS.	

Range: 1-12 ppm MDL: 1 ppm / Method: Indigo Carmine	
	Cat#
CHEMets Kit	K-7512
CHEMets Refill, 30 ampoules	R-7512
Comparator 1, 2, 3, 4, 5, 6, 8, 10, 12 ppm	C-7512
Kit comes in a plastic case and contains everything needed to perform 30 tests: Refill, Comparator, 25 mL sample cup, instructions, and MSDS.	

Instructions and MSDS(s) are posted on our website.

If no shelf-life is listed for a product, then the shelf-life is at least 2 years.





Instrumental Kits

V-2000 Multi-Analyte Photometer*(See page 14 for instrumental features)***Range: 0.100-1.000 ppm****Method: Rhodazine D****Vacu-vials Kit****Cat#****K-7553**

Kit comes in a cardboard box and contains everything needed to perform 30 tests: thirty ampoules, sampling tube, adhesive mounting clamp, permanent mounting clamp, ampoule blank, instructions, and MSDS.

Range: 0.20-2.00 ppm**Method: Indigo Carmine****Vacu-vials Kit****Cat#****K-7503**

Kit comes in a cardboard box and contains everything needed to perform 30 tests: thirty ampoules, 25 mL sample cup, sampling tube, adhesive mounting clamp, permanent mounting clamp, ampoule blank, instructions, and MSDS.

Range: 2.0-15.0 ppm**Method: Indigo Carmine****Vacu-vials Kit****Cat#****K-7513**

Kit comes in a cardboard box and contains everything needed to perform 30 tests: thirty ampoules, 25 mL sample cup, ampoule blank, instructions, and MSDS.

Vacu-vials Kits require the use of the V-2000 Photometer or a spectrophotometer capable of accepting a 13 mm diameter round cell. Instrument sold separately.

SAM Single-Analyte Photometers*(See page 17 for instrumental features)***Range: 2.0-15.0 ppm****Method: Indigo Carmine****SAM Kit****Cat#****I-2002**

Vacu-vials Kit, 30 ampoules, 25 mL sample cup, ampoule blank, instructions, and MSDS.

K-7513

SAM Kit comes in a plastic case and contains everything needed to perform 30 tests: Vacu-vials Kit, SAM Photometer, 4 AAA batteries, screwdriver, light shield, and instructions.

If no shelf-life is listed for a product, then the shelf-life is at least 2 years.

Kit Components common to Oxygen

Description	Cat#
Sample Cup Pack, 25 mL (6 ea)	A-0013
Sampling Tube Pack (3 ea)	A-0020
Mounting Clamp Pack, Adhesive (6 ea)	A-0022
Ampoule Blank Pack (5 ea)	A-0023
Mounting Clamp Pack, Permanent (6 ea)	A-0034

Instructions and MSDS(s) are posted on our website.

If no shelf-life is listed for a product, then the shelf-life is at least 2 years.

