PRODUCT PROFILE



MONITOR™ for QAC Sanitizers Product Code 5152

WHAT does this product do?

Serim® MONITORï for QAC test strips give a semi-quantitative indication that quaternary ammonium compound (QAC) sanitizers are at the appropriate concentration for use in sanitizing food processing equipment and facilities.

WHY should I use this product?

Serim MONITOR strips are used to indicate whether the QAC concentration is adequate for the surface being sanitized.

In food processing, the concentration of quaternary ammonium compounds can range from <200 ppm to 5,000 ppm. Recommended concentrations vary depending on the needs, equipment, plant design, and federal (FDA¹) or state regulations.

Using a QAC concentration that is too low may not thoroughly sanitize surfaces or equipment². Using a concentration that is higher than recommended (<200 ppm) for food contact items without a pre-use rinse may leave a toxic residue on these surfaces³.

The strips can be used to estimate QAC concentrations from 0 to 1,000 ppm, with color blocks at 0, 50, 100, 200, 400 and 1000 ppm.

WHERE do I use this product?

Use Serim MONITOR for QAC test strips wherever a QAC sanitizer solution is used. Follow the manufacturerop directions for dilution of the QAC concentrate for the specific surface being sanitized.

HOW to use this product

Serim MONITOR strips are supplied in ready-to-use form. When placed in contact with the sample* according to the directions for use (see below), the indicator pad changes color relative to the concentration of the QAC solution.

Ordering Information

Serim MONITOR for QAC "Product Code 5152 1 bottle of 100 strips



QAC Concentration (ppm)



Diagrams are for illustration purposes only. Always use the color blocks on the actual bottle label to interpret results.

Test Method	Immersion
Test Strip Technique	Immerse indicator pad in sample and remove immediately .
Results	Within 15 seconds after immersion, compare the color of the indicator pad to color chart on the bottle label.

PRODUCT PROFILE

SERIM MONITOR for QAC Sanitizers		
Features	Benefits	
Designed for use in the food processing industry	" Color blocks at levels significant to the food processing industry.	
May be used with acid QAC solutions	" Reliable results with acid QAC solutions	
Test results not affected by different formulations of various commercial brand QAC solutions	"Test strips can be used to estimate QAC concentration on first to fourth generation commercial brand QAC solutions with the exception of Hyamine 1622	
Ready-to-use strips, simple procedure	"No calculations or %drop counting+needed "No preparation or mixing of reagents	
Quick, semi-quantitative results in 15 seconds.	" Simple, quick and reliable method	
Simple to interpret color blocks	Accurate and consistent results minimize variation between readersColor of indicator pad is directly compared to color blocks on bottle label	
Consistent color reactions	" Results not affected by aging during the shelf life of the product	
Each bottle clearly labeled with: "Lot number "Expiration date	"Traceability of product from manufacturing to final user "Leaves no doubt as to the age or integrity of the product	

References:

- 1. Regulations of the Food & Drug Administration, Book 21 Code of Federal Regulations (21CFR 178.1010).
- 2. The Role of Sanitizers in Food Processing . www.teimongolia.org/areas/meat/refmat/SANITIZER.doc
- 3. Cleaning and Handling Fresh Produce and Fresh Produce Handling Equipment, Utensils and Sales Area. Maryland Cooperative Extension, Fact Sheet 715



Serim Research Corporation

P.O. Box 4002, Elkhart, IN 46514-0002

Phone: (800) 542-4670 (574)264-3440 FAX (574)266-6222 E-mail: customerservice@serim.com Website: www.serim.com

Certified to ISO 9001:2008 & ISO 13485:2003