


Operating Instructions



Ultrasonic Flowmeter KATflow 150

Katronic Technologies Ltd.

23 Cross Street
Leamington Spa
Warwickshire CV32 4PX
United Kingdom

Tel. +44 (0)1926 882954

Fax +44 (0)1926 338649

Internet www.katronic.co.uk

E-mail mail@katronic.co.uk

Operating Instructions KATflow 150

Version V13E1011

Copyright © 2011

All rights reserved.

KATflow 150 Operating Instructions

Table of Contents

	Page
1 Safety instructions, legal requirements, warranty, return policy.....	5
1.1 Symbols used in these operating instructions.....	5
1.2 Safety instructions.....	5
1.3 Warranty.....	6
1.4 Return policy.....	6
1.5 Legislative requirements.....	6
2 Introduction.....	7
3 Installation.....	8
3.1 Unpacking and storage.....	8
3.1.1 <i>Unpacking</i>	8
3.1.2 <i>Storage</i>	8
3.1.3 <i>Identification of components</i>	8
3.2 Clamp-on sensor installation.....	9
3.3 Installation location.....	9
3.4 Pipe preparation.....	12
3.5 Clamp-on sensor mounting configurations and sensor spacing.....	12
3.6 Flowmeter installation.....	13
3.6.1 <i>Wall mounting</i>	14
3.6.2 <i>Electrical connections</i>	15
3.7 Clamp-on sensor mounting.....	16
3.7.1 <i>Sensor pipe mounting configurations</i>	16
3.7.2 <i>Acoustic coupling gel</i>	16
3.7.3 <i>Correct positioning of the sensors</i>	17
3.7.4 <i>Sensor mounting with tension straps</i>	17
4 Operation.....	19
4.1 Switching On/Off.....	19
4.2 Keypad and display.....	19
4.2.1 <i>Keypad key functions</i>	19
4.2.2 <i>Display functions</i>	21
4.3 Quick setup wizard.....	22
4.4 Measurements.....	24
4.4.1 <i>Main process value (PV) display</i>	24
3-line display format.....	25
4.4.2 <i>Diagnostic displays</i>	25
4.4.3 <i>Totalisers</i>	25
4.4.4 <i>Datalogger</i>	25
5 Commissioning.....	26
5.1 Menu structure.....	26
5.2 Diagnostics.....	32
5.3 Display settings.....	32
5.4 Output configurations.....	32
5.4.1 <i>Serial interface RS 232</i>	32
5.4.2 <i>Serial interface RS 485</i>	32

5.4.3 HART output.....	32
5.4.4 Analogue current output 0/4 ... 20 mA.....	33
5.4.5 Analogue voltage output 0-10 v.....	33
5.4.6 Analogue frequency output 2...10k Hz.....	33
5.4.7 Digital Open-Collector output.....	34
5.4.85 Digital relay output.....	34
5.5 Input configurations.....	34
5.5.1 PT100 inputs.....	34
5.5.2 Analogue current input 0/4 ... 20 mA.....	35
5.6 Heat quantity measurement (HQM).....	35
5.7 Sound velocity measurement (SVM).....	35
5.8 Dual-channel flow calculations (maths functions).....	35
6 Maintenance.....	35
7 Troubleshooting.....	36
8 Technical data.....	38
9 Specification.....	44
10 Index.....	46
Appendix A.....	47
Appendix B.....	48

1 Safety instructions, legal requirements, warranty, return policy

1.1 Symbols used in these operating instructions



Danger

This symbol represents an immediate hazardous situation which could result in **serious injury, death or damage to the equipment**. Where this symbol is shown, do not use the equipment further unless you have fully understood the nature of the hazard and have taken the required precautions.



Attention

This symbol indicates important instructions which should be respected in order to avoid damaging or destroying the equipment. Follow the the precautions given in these instructions to avoid the hazard. Call our service team if necessary.



Call service

Where this symbol is shown call our service team for advice if necessary.



Note

This symbol indicates a note or detailed set-up tip.



Information point.



Operator keys are printed in bold typeface and placed in pointed brackets.

1.2 Safety instructions

- Do not install, operate or maintain this flowmeter without reading, understanding and following these operating instructions, otherwise injury or damage may result.
- Study these operating instructions carefully before the installation of the equipment and keep them for future reference.
- Observe all warnings, notes and instructions as marked on the packaging, on the equipment, and detailed in the operating instructions.
- Do not use the instrument under wet conditions with the battery cover removed or opened.
- Follow the unpacking, storage and preservation instructions to avoid damage to the equipment.
- Install the equipment and cabling securely and safely according to the relevant regulations.
- If the product does not operate normally, please refer to the service and troubleshooting instructions, or contact KATRONIC for help.

1.3 Warranty

- Any product purchased from KATRONIC is warranted in accordance with the relevant product documentation and as specified in the sales contract provided it has been used for the purpose for which it has been designed and operated as outlined in these operating instructions. Misuse of the equipment will immediately revoke any warranty given or implied.
- Responsibility for suitability and intended use of this ultrasonic flowmeter rests solely with the user. Improper installation and operation of the flowmeter may lead to a loss of warranty.
- Please note that there are no operator-serviceable parts inside the equipment. Any unauthorised interference with the product will invalidate the warranty.

1.4 Return policy

If the flowmeter has been diagnosed to be faulty, it can be returned to KATRONIC for repair using the Customer Returns Note (CRN) attached to the Appendix of this manual. KATRONIC regret that for Health & Safety reasons we cannot accept the return of the equipment unless accompanied by the completed CRN.

1.5 Legislative requirements

CE marking

The flowmeter is designed to meet the safety requirements in accordance with sound engineering practice. It has been tested and has left the factory in a condition in which it is safe to operate. The equipment is in conformity with the statutory requirements of the EC directive and complies with applicable regulations and standards for electrical safety EN 61010 and electro-magnetic compatibility EN 61326. A CE Declaration of Conformity has been issued in that respect, a copy of which can be found in the Appendix of these operating instructions.

WEEE Directive

The Waste Electrical and Electronic Equipment Directive (WEEE Directive) aims to minimise the impact of electrical and electronic goods on the environment by increasing re-use and recycling and by reducing the amount of WEEE going to landfill. It seeks to achieve this by making producers responsible for financing the collection, treatment, and recovery of waste electrical equipment, and by obliging distributors to allow consumers to return their waste equipment free of charge.



KATRONIC offers its customers the possibility of returning unused and obsolete equipment for correct disposal and recycling. The Dustbin Symbol indicates that when the last user wishes to discard this product, it must be sent to appropriate facilities for recovery and recycling. By not discarding this product along with other household-type waste, the volume of waste sent to incinerators or landfills will be reduced and natural resources will be conserved. Please use the Customer Return Note (CRN) in the Appendix for return to KATRONIC.

RoHS Directive

The European Union's RoHS ("Restriction of the use of certain Hazardous Substances") Directive (2002/95/EC) came into effect on July 1, 2006. All of the instrumentation manufactured by KATRONIC falls under Category 9, Measurement and Control Equipment. Currently this category is exempt from RoHS compliance until at least 2010, when it and other exemptions will be reviewed. Regardless of this, all products manufactured by KATRONIC are compliant with the RoHS Directive.

2 Introduction

Clamp-on transit-time flowmeter

The KATflow 150 is an ultrasonic flowmeter employing clamp-on sensors for the measurement of liquids in full, enclosed pipes. Flow measurements can be undertaken without interruption of the process or interference with the integrity of the pipeline. The clamp-on sensors are attached to the outside of the pipes. The KATflow 150 uses ultrasonic signals for measurement of the flow, employing the transit-time method.




Illustration 1: Clamp-on ultrasonic flowmeter configuration

Measuring principle

Ultrasonic signals are emitted by a transducer installed on a pipe and received by a second transducer. These signals are emitted alternately in the direction of flow and against it. Because the medium is flowing, the transit time of the sound signals propagating in the direction of flow is shorter than the transit time of the signal propagating against the direction of flow. The transit-time difference ΔT is measured and allows the determination of the average flow velocity along the path of acoustic propagation. A profile correction is then performed to obtain the average flow velocity over the cross-sectional area of the pipe, which is proportional to the volumetric flow rate.




Illustration 2: Transit-time measuring principle

3 Installation

3.1 Unpacking and storage

3.1.1 Unpacking

Care should be taken when opening the box containing the flowmeter, any markings or warnings shown on the packaging should be observed prior to opening. The following steps should then be taken:

- Unpack the flowmeter in a dry area.
- The flowmeter should be handled with care and not left in an area where it could be subject to physical shocks.
- If using a knife to remove packaging care should be taken not to damage the flowmeter or cables.
- The flowmeter package and contents should be checked against the delivery note supplied and any missing items reported immediately.
- The flowmeter package and contents should be checked for signs of damage during transport and any problems reported immediately.
- The vendor accepts no responsibility for damage or injury caused during the unpacking of the instrumentation supplied.
- Excess packing materials should be either recycled or disposed of in a suitable way.

3.1.2 Storage

If storage is necessary, the flowmeter and sensors should be stored:

- in a secure location,
- away from water and harsh environmental conditions,
- in such a way as to avoid damage,
- small items should be kept together in the bags provided to avoid loss.

3.1.3 Identification of components

The following items are typically supplied (please refer to your delivery note for a detailed description):

- KATflow 150 ultrasonic flowmeter
- Clamp-on sensors (one pair for single channel operation, two pairs for dual channel operation)
- Sensor connection cable(s) if not direct sensor connection
- Sensor mounting accessories
- Coupling component
- Operating instructions
- Project and/or hazardous area documentation (optional)
- Calibration certificate(s) (optional)
- Temperature measurement probes (optional)

3.2 Clamp-on sensor installation

The correct selection of the sensor location is crucial for achieving reliable measurements and high accuracy. Measurement must take place on a pipe in which sound can propagate (see Acoustic propagation) and in which a rotationally symmetrical flow profile is fully developed (see Straight pipe lengths).

The correct positioning of the transducers is an essential condition for error-free measurements. It ensures that the sound signal will be received under optimal conditions and evaluated correctly. Because of the variety of applications and the different factors influencing the measurement, there can be no standard solution for the positioning of the transducers.

The correct position of the transducers will be influenced by the following factors:

- diameter, material, lining, wall thickness and general condition of the pipe,
- the medium flowing in the pipe,
- the presence of gas bubbles and solid particles in the medium.

Check that the temperature at the selected location is within the operating temperature range of the transducers (see Specification).

After the sensor location has been selected, make sure that that supplied cable is long enough to reach the flow transmitter mounting location. Ensure that the temperature at the selected location is within the ambient operating temperature range of the flow transmitter (see Specification).

Acoustic propagation Acoustic propagation is achieved when the flowmeter is able to receive sufficient signal from the transmitted ultrasonic pulses. The signals are attenuated in the pipe material, the medium and at each of the interfaces and reflections. External and internal pipe corrosion, solid particles and gas content in the medium contribute heavily to signal attenuation.

Straight pipe lengths Sufficient straight lengths of pipe on the inlet and outlet of the measuring location ensure an axi-symmetrical flow profile in the pipe, which is required for good measurement accuracy. If insufficient straight lengths of pipe are available for your application measurements are still obtainable, but the certainty of the measurement can be reduced.

3.3 Installation location

Select an installation location following the recommendations in Table 1 and try to avoid measuring



- in the vicinity of deformations and defects of the pipe,
- near welding seams,
- where deposits could be building up in the pipe.


For a horizontal pipe:

Select a location where the transducers can be mounted on the side of the pipe, so that the sound waves emitted by the transducers propagate horizontally in the pipe. In this way, the solid particles deposited on the bottom of the pipe and the gas pockets developing at the top will not influence the propagation of the signal.



For a free inlet or outlet pipe section:

Select the measuring point at a location where the pipe cannot run empty.



For a vertical pipe:

Select the measuring point at a location where the liquid flows upward to ensure that the pipe is completely filled.




Table 1: Recommendations for sensor mounting location




Look for a sensor installation location with sufficient straight pipe to obtain accurate measurements. Please refer to Table 2 as a guideline for recommended distances from disturbance sources.

Disturbance source: 90°-elbow


Inlet

$L \geq 10 D$



Outlet


$L \geq 5 D$



Disturbance source: 2 x 90°-elbows in one plane


Inlet

$L \geq 25 D$



Outlet

$L \geq 5 D$






Table 2: Recommended distances from disturbance sources

3.4 Pipe preparation



- Clean dirt and dust from around the area of the pipework where the sensors are to be placed.
- Remove loose paint and rust with a wire brush or file.

Firmly bonded paint does not necessarily need to be removed provided the flow-meter diagnostics indicate sufficient signal strength.

3.5 Clamp-on sensor mounting configurations and separation distance

Reflection Mode

The most common clamp-on sensor mounting configuration is the Reflection Mode, sometimes known as V-Mode (see Illustration 3, sketch (1)). Here, the ultrasonic signal passes twice through the medium (2 signal passes). The Reflection Mode is the most convenient mounting method as the transducer separation distance can be measured easily and the sensors can be accurately aligned. This method should be used whenever possible.

Diagonal Mode

An alternative mounting configuration (Illustration 3, sketch (3)) is the Diagonal mode (Z-Mode). The signals travel only once through the pipe. This method is often used for larger pipes where greater signal attenuation might occur.

Further variation of the Reflection and the Diagonal Modes are possible by altering the number of passes through the pipe. Any even number of passes will require mounting the sensors on the same side of the pipe, while with an odd number of passes, the sensors must be mounted on opposite sides of the pipe. Commonly, for very small pipes, sensor mounting configurations such as 4 passes (W-mode) or 3 passes (N-mode) are used (Illustration 3, sketch (2)).




Illustration 3: Clamp-on sensor mounting configurations and sensor spacing

Transducer separation distance

The transducer separation distance A is measured from the inside edges of the sensor heads as shown in illustration 3. It is automatically calculated by the flow-meter based on the parameter entries for pipe outside diameter, wall thickness, lining material and thickness, medium, process temperature, the sensor type and the selected number of signal passes.

Sensor spacing




A negative separation distance $A < 0$ can occur for mounting configurations on small pipes where diagonal mode operation has been selected (see Illustration 3, sketch (3)). Negative separation distances may be suggested for reflection mode installations, but are not possible. In these cases, use diagonal mode or a larger number of passes.

3.6 Flowmeter installation


3.6.1 Wall mounting

The KATflow 150 is a wall mounted device and can be installed using suitable screws and wall plugs according to the following drawings.

Flowmeter outline dimensions



Drawing 1: Outline dimensions KATflow 150 ultrasonic flowmeter

Drilling aid for wall mounting

Make sure that the ambient temperature is within the -10 ... 60 °C operating temperature range specified for the flowmeter unit.


3.6.2 Electrical connections

Please note that in order to supply the unit with MAINS POWER, the equipment must be protected by suitably sized switches and circuit breakers.

Electrical wiring



100 ... 240 V AC, 50/60 Hz	10 W
9 ... 36 V DC	10 W



Drawing 3: Electrical connection diagram for the KATflow 150 flowmeter

3.7 Clamp-on sensor mounting

Sensor mounting

Before the sensors can be mounted

- the installation location should have been determined,
- a sensor mounting method should be chosen,
- the flowmeter must be mechanically and electrically installed,
- the sensors must be connected to the flowmeter.

Depending on which sensor mounting method is being used, the clamp on sensors are either mounted on the same side of the pipe (Reflection Mode) or on opposite sides of the pipe (Diagonal Mode). The sensor spacing is calculated by the flowmeter from the pipe parameters entered.

3.7.1 Sensor pipe mounting configurations




Illustration 4: Sensor pipe mounting configurations

3.7.2 Acoustic coupling gel



In order to obtain acoustical contact between the pipe and the sensors, apply a bead of acoustic coupling gel lengthwise down the centre of the contact area of the sensors.



3.7.3 Correct positioning of the sensors

Correct sensor position




Illustration 6: Correct positioning of the sensors

Always mount the transducer pair so that the free front edges of the sensors face each other.



There is a different engraving on the top of each transducer. The transducers are mounted correctly if the engravings on the two transducers form an arrow. The transducer cables should point in opposite directions.

Later, the arrow, in conjunction with the indicated measured value, will help to determine the direction of flow.

The sensor separation distance is automatically calculated by the flowmeter based on the parameter entries for pipe outside diameter, wall thickness, lining material and thickness, medium, process temperature, the sensor type and the selected number of signal passes.

3.7.4 Sensor mounting with tension straps



Illustration 7: Metallic mounting straps

- Cut the tension straps to the appropriate length.
- Pull at least 2 cm of the tension strap through the slot in the clamp and bend the strap back to secure the clamp to the tension strap.
- Guide the other end of the tension strap through the groove on top of the sensor.
- Place the sensor onto the prepared pipe section.
- Hold the clamp on the transducer with one hand and guide the tension strap around the pipe.

- Pull the tension strap and guide the free end through the clamp so that the clamp hooks engage. Slightly tighten the screw on the clamp.
- Mount the second sensor in the same way.
- Press the sensors firmly to the pipe. There should be no air pockets between the transducer surface and the pipe wall.
- Using a measuring tape, adjust the sensor separation distance as suggested by the flowmeter. When the sensor positioning screen (Section 3.3) is displayed, the middle bar allows fine adjustment of the sensor location.




Illustration 8: Sensor mounting with tension straps and clamps

4 Operation

4.1 Switching On/Off

Switching On/Off

The flowmeter is switched on by connecting the power supply to the instrument. Disconnecting the external supply switches off the flowmeter.

4.2 Keypad and display




Illustration 9: Keypad and display overview

4.2.1 Keypad key functions

Keypad

Key	Main function	Secondary function
	Character entry: 1 (1 short key stroke) , (2 short key strokes) . (3 short key strokes) _ (4 short key strokes)	Show NEXT available item
	Character entry: A B C 2 /	Q_{ON} = Start and reset totaliser
	Character entry: D E F 3 ?	Show next DISP lay

	Character entry: G H I 4 <	Q = Reset negative total value
	Character entry: J K L 5 >	
	Character entry: M N O 6 \$	Q+ = Reset positive total value
	Character entry: P Q R S 7	Toggle MULTipleXer (where multi-channel functions are provided)
	Character entry: T U V 8 *	Q_{OFF} = Stop totaliser function
	Character entry: W X Y Z 9	
	Move menu/list selection item UP	Character backspace clear
	Character entry: . (decimal point)	Switch LCD backlight on/off
	Character entry: 0 Space character + = #	
	Move menu/list selection item DOWN	Character entry : - (minus sign)
	ESC ape menu item	Abort entry without saving

Table 3: Menu structure

	<p>ENTER menu item</p>	<p>Confirm entry with saving</p>
---	-------------------------------	----------------------------------

4.2.2 Display functions

Main measurement display




Illustration 10: Main display functions

Display icons

Display icon	Function
	<p>On Not used Off</p>
	<p>On Datalogger recording Off Datalogger switched off</p>
	<p>On Not used Off</p>
	<p>On Backlight switched on Off Backlight switched off</p>
	<p>On I/O processor error Off I/O processor functioning correctly</p>
	<p>On Without strike-through: Speaker on Off With strike-through: Speaker off</p>
	<p>On Poor sensor coupling, low SNR Off Sensor coupling OK</p>
	<p>On Not used Off</p>


	On Not used Off
	On Time/date set Off Clock error
	On Error recorded in error log Off No error detected
	On Serial communication on (RS232 and/or RS485) Off Serial communication off

Table 4: Display icons

4.3 Quick setup wizard

The quick setup wizard allows for a speedy setup of the most important parameters in order to achieve successful measurements in the shortest possible time:

Quick start wizard



Display screen	Operation
<p>MAIN MENU</p> <p>Quick start Installation Display In/Output</p>	<p>The main menu is displayed after first power on and the boot-up sequence.</p> <p>Use <UP> and <DOWN> cursor keys to select Quick start. Confirm by pressing <ENTER>.</p>
<p>QUICK START</p> <p>Setup Wizard CH1 Setup Wizard CH2 Start Measurement</p>	<p>Use cursor keys to select Setup Wizard. Confirm by pressing <ENTER>.</p> <p>If sensors are recognised, the serial number will be shown. If not recognised or not connected, they may be selected from a list.</p>
<p>MIDDLE UNITS</p> <p>m3/h m3/m m3/s</p>	<p>Select units of measurement using cursor keys and pressing <ENTER>.</p>
<p>PIPE MATERIAL</p> <p>Stainless Steel Carbon Steel Ductile cast iron</p>	<p>Choose pipe material using cursor keys and pressing <ENTER>.</p>



<p>OUTSIDE DIAMETER</p> <p style="text-align: center;">76.1 mm</p>	<p>Enter outside pipe diameter using alphanumeric keys and confirm by pressing <ENTER>.</p> <p>Use key <UP> as character backspace clear to correct for data entry errors.</p> <p>If 0 is entered, an additional screen appears that allows entering the pipe circumference.</p>
<p>WALL THICKNESS</p> <p style="text-align: center;">3.4 mm</p>	<p>Enter pipe wall thickness using alphanumeric keys and confirm by pressing <ENTER>.</p> <p>Use key <UP> as character backspace clear to correct for data entry errors.</p>
<p>FLUID</p> <div style="border: 1px solid black; padding: 5px;"> <p style="background-color: black; color: white; padding: 2px;">Water</p> <p>Saltwater</p> <p>Acetone</p> </div>	<p>Select fluid using cursor keys.</p> <p>Confirm by pressing <ENTER>.</p>
<p>TEMPERATURE</p> <p style="text-align: center;">20.0 C</p>	<p>Enter process temperature using alphanumeric keys and confirm by pressing <ENTER>.</p> <p>Use key <UP> as character backspace clear to correct for data entry errors.</p>
<p>LINER MATERIAL</p> <div style="border: 1px solid black; padding: 5px;"> <p style="background-color: black; color: white; padding: 2px;">None</p> <p>Epoxy</p> <p>Rubber</p> </div>	<p>Select pipe lining material using cursor keys.</p> <p>Confirm by pressing <ENTER>.</p>
<p>PASSES</p> <div style="border: 1px solid black; padding: 5px;"> <p style="background-color: black; color: white; padding: 2px;">Auto</p> <p>1</p> <p>2</p> </div>	<p>Select transducer configuration (number of passes) using cursor keys.</p> <p>Auto Automatically</p> <p>1 1 pass, diagonal mode</p> <p>2 2 passes, reflection mode</p> <p>3 3 passes, diagonal mode</p> <p>4 4 passes, reflection mode</p> <p>5 5 passes, diagonal mode</p> <p>6 6 passes, reflection mode</p> <p>..etc.</p> <p>Confirm by pressing <ENTER>.</p>

<p style="text-align: center;">QUICK START</p> <p>Setup Wizard CH1 Setup Wizard CH2 Start Measurement</p>	<p>Use cursor keys to select Start Measurement. Confirm by pressing <ENTER>.</p>
<p style="text-align: center;">CHNL1 SENSOR</p> <p>Spacing 35.0 mm Using 2 passes Signal 26 dB</p> 	<p>Sensor placement screen: Mount transducers with suggested spacing and use middle bar for fine adjustment of position (central position is desired). Observe signal-to-noise (upper bar) and quality (lower bar). These should be of identical length.</p> <p>Confirm by pressing <ENTER> to obtain measurements.</p>
<p style="text-align: center;">CHNL-1</p> <p style="text-align: center;">25.678 m3/h</p> <p>11/11/07 10:56:00</p>	<p>Success!</p>

Table 5: Quick setup wizard

4.4 Measurements

4.4.1 Main process value (PV) display

Measurement is started using the Quick Setup Wizard. Once all the parameters are programmed, any subsequent power-on sequences will bring up the main PV display immediately.

Measurement screens



Display screen	Operation
<p style="text-align: center;">CHNL-1</p> <p style="text-align: center;">25.678 m3/h</p> <p>11/11/07 10:56:00</p>	<p>The main process value can be changed using the menu structure.</p> <p>Press <ESC> at any time to access the main menu.</p> <p>Change to the 3-line display by pressing <DISP> or <NEXT>.</p>

3-line display format



Display screen	Operation
CHNL-1 - 0.0 m3 25.678 m3/h 1.370 m/s 11/11/07 10:56:00	The three-line display screen is configurable to show flow, totalizers and diagnostic functions. Change to diagnostic displays by pressing <DISP> and to totalizer screens by pressing <NEXT>. Cycle through screens using <NEXT>. Cycle through available flow channels using <MUX>.

4.4.2 Diagnostic displays

Diagnostic screens



Display screen	Operation
DIAGNOSTIC 1 55.2 Gain 20.5 Signal -10.0 Noise 11/11/07 10:56:00	Line 1 shows the amplifier gain. Line 2 displays the signal strength. Line 3 indicates the noise. Change to more diagnostic displays by pressing <NEXT>.

4.4.3 Totalisers

The totaliser displays will only be shown when the totalisers are activated.

Totalisers



Display screen	Operation
CHNL-1 - 1.3 m3 25.678 m3/h 37.3 m3 11/11/07 10:56:00	The flow totalizer may be assigned to lines in the three line display, the datalogger or process outputs. They can be started or reset by pressing <QON>. Pressing <Q+> resets the total accumulated flow in positive flow direction. Pressing <Q-> resets the total accumulated flow in negative flow direction. The totalizers can be stopped by activating <QOFF>. Pressing <QON> again will reset to zero. Change to other displays or revert to the three line display screen without resetting by pressing <DISP> or <NEXT>.

4.4.4 Datalogger



The datalogger is enabled from the Main Menu, and operates when a non-zero value is entered for the interval. Items to be logged are selected from the "Selection" screen. "ENTER" selects items, "0" deselects. Up to ten items may be selected. Send logger by serial port to a terminal program by selecting "Log download". Clear the logger by selecting "Log Erase".

5 Commissioning

5.1 Menu structure

Menu structure

Main menu	Menu level 1	Menu level 2	Description/settings
Quick Start			
	Setup Wizard CH1		
		Sensor type	<i>Indication of sensor type and serial number if automatically detected, otherwise select from list</i> ↑↓ K1N, K1L, K1E K4N, K4L, K4E M Q Special
		Middle Units	<i>Select from list</i> ↑↓ m/s, f/s, in/s, m ³ /h, m ³ /min, m ³ /s, l/h, l/min, l/s, USgall/h, USgall/min, USgall/s, bbl/d, bbl/h, bbl/min, g/s, t/h, kg/h, kg/min, m ³ , l, Usgall, bbl, g, t, kg, W, kW, MW, J, kJ, MJ, Sig dB (signal), noise dB, SNR, C m/s (sound speed), CU (housing temperature) Tin, Tout (inlet and outlet temperature) TEMP (specified or measured fluid temperature), SOS, DEN. KIN (derived sound speed, density, kinematic viscosity) Math (Calculated value – see below)
		Pipe material	<i>Select from list</i> ↑↓ Stainless steel, Carbon steel Ductile cast iron, Grey cast iron Copper, Lead PVC, PP, PE, ABS Glass, Cement User (pipe c-speed)
		Pipe c-speed	<i>Only if user pipe material selected</i> 600 ... 6553.5 m/s
		Outside diameter	6 ... 6500 mm
		Wall thickness	0.5 ... 75 mm
		Fluid	<i>Select from list</i> ↑↓ Water, Salt water Acetone, Alcohol, Ammonia Carbon Tet (carbon tetrachloride) Ethanol, Ethyl alcohol, Ethyl ether Ethylene glycol, Glycol/water 50% Kerosene, Methanol, Methyl alcohol Milk, Naphtha, Car oil Freon R134a, Freon R22 Hydrochloric acid, Sour cream, Sulphuric acid Toluene, Vinyl chloride User (enter kinematic viscosity, density, medium c-speed)
		Kinematic viscosity	<i>Only if user fluid selected</i> 0.001 ... 30000 mm ² /s
		Density	<i>Only if user fluid selected</i> 100 ... 2000 kg/m ³
		Medium c-speed	<i>Only if user fluid selected</i> 800 ... 3500 m/s
		Temperature	-30 ... 300 °C

		Liner Material	Select from list ↑↓ None, Epoxy, Rubber, PVDF, PP, Glass, Cement, User (liner c-speed)
		Liner c-speed	Only if lining material selected 600 ... 6553.0 m/s
		Liner thickness	Only if lining material selected 1.0 ... 99.0 mm
		Passes	Select from list ↑↓ Auto 1...16
	Setup Wizard CH2		
			As setup wizard single for channel 1
	Start Measurement		
		Sensor type	Indication of sensor type and serial number if automatically detected, otherwise select from list ↑↓ K1N, K1L, K1E K4N, K4L, K4E M Q Special
		Sensor frequency	SP1, only for special, unrecognised sensors
		Wedge angle	SP2, only for special, unrecognised sensors
		Wedge c-speed 1	SP3, only for special, unrecognised sensors
		Wedge c-speed 2	SP4, only for special, unrecognised sensors
		Crystal offset	SP5, only for special, unrecognised sensors
		Spacing offset	SP6, only for special, unrecognised sensors
		Zero flow offset	SP7, only for special, unrecognised sensors
		Upstream offset	SP8, only for special, unrecognised sensors
		Sensor placement	Adjust sensor position
Installation			
		Select channel	Channel 1, Channel 2
	Pipe		
		Material	Select from pipe material list ↑↓
		Outside diameter	6 ... 6500 mm
		Wall thickness	0.5 ... 75 mm
		C-speed	600 ... 6554 m/s (transverse sound speed)
		Circumference	18.8 ... 20420.4 mm
		Roughness	0.0 ... 10 mm
	Medium		
		Fluid	Select from fluid list ↑↓
		Kinematic (viscosity)	0.001 ... 30000 mm ² /s
		Density	100 ... 2000 kg/m ³
		C-speed	100 ... 3500 m/s
		Temperature	-30 ... 300 °C

	Lining		
		Material	Select from material list ↑↓
		Thickness	1 ... 99 mm
		C-speed	600 ... 6553.0 m/s
	Passes		
		Passes	Select from list ↑↓
Display			
		Select channel	Channel 1, Channel 2
		Select line of display (Top, Middle, Bottom)	Select from unit list ↑↓
		Damping	Reduces fluctuations in the display output 1 ... 255 s
		Metric/Imp.	Select metric or Imperial units.
In/Output			
	Type		Select from list ↑↓
	I Out		Analogue current output
		Source	Select from list ↑↓ Off Channel 1, Channel 2 Math 1, Math 2 System, Test
		Units	Select from unit list ↑↓
		Min Value	Min. process variable (PV) value that corresponds to 0/4 mA
		Max Value	Max. process variable (PV) value that corresponds to 20 mA
		Damping	Additional smoothing of the current output, the higher the damping factor, 1 ... 255 s
		Span	0-20mA or 4-20mA
		Error	Defines output behaviour in the event of error Select from list ↑↓ Hold (hold last value, select hold time), 3.8mA, 21.0mA
	Voltage out		
		Source	Select from list ↑↓
		Units	Select from list ↑↓
		Min Value	Min. process variable (PV) value that corresponds to 0v
		Max Value	Max. process variable (PV) value that corresponds to 10v
		Damping	Additional smoothing of the current output, the higher the damping factor, 1 ... 255 s
		Error	Defines output behaviour in the event of error Select from list ↑↓
	Frequency out		
		Source	Select from list ↑↓
		Units	Select from list ↑↓
		Min Value	Min. process variable (PV) value that corresponds to minimum frequency
		Max Value	Max. process variable (PV) value that corresponds to maximum frequency

		Damping	<i>Additional smoothing of the current output, the higher the damping factor, 1 ... 255 s</i>
		Error	<i>Defines output behaviour in the event of error Select from list ↑↓</i>
	Pulse Out		
		Source	<i>Select from list ↑↓ Off Channel 1, Channel 2 Math 1, Math 2 System, Test</i>
		Units	<i>Select from unit list ↑↓</i>
		Mode	<i>Select from list ↑↓ Alarm (select on point, off point) Pulse (select value, width) Linear (select min value, max value, damping)</i>
	Relay Out		
		Source	<i>Select from list ↑↓ Off Channel 1, Channel 2 Math 1, Math 2 System, Test</i>
		Units	<i>Select from unit list ↑↓</i>
		Mode	<i>Select from list ↑↓ Alarm (select on point, off point) Pulse (select value, width) Linear (select min value, max value, damping)</i>
	PT100 4 WIRE		
		Source	<i>Select from list ↑↓ Off Channel 1, Channel 2 Math 1, Math 2 System, Test</i>
		Type	<i>Select from list ↑↓ User (Fixed value - enter) PT100 (Measured - select whether inlet, outlet, compensation and enter offset if required)</i>
	Current In		
		Current IP Log	<i>Yes – If serial output is turned on, mode printer, then the current input value may be output via serial communication No</i>
	RS 485		[where specified]
	Modbus RTU		[where specified]
	HART®		[where specified]
	Other In/Out types		Refer to Technical Support
System			
	Instrument info		
		Model Code	KF150
		Serial No.	<i>Example: 15002013</i>
		HW Revision	<i>Example: 2.0, 1.5</i>
		SW Revision	<i>Example: 3.1, 2.4</i>
	Calculation		
		Select channel	Channel 1, Channel 2
		Low F Cut	<i>± Low flow velocity cut off 0 ... 0.025 m/s</i>

		Max F Cut	\pm Maximum flow velocity cut off 0 ... 30 m/s
		Corrected	Apply flow velocity profile correction Yes No
		PV Offset	Calibration process variable zero offset -30 ... 30 m/s
		PV Scaling	Calibration process variable gradient scaling 0.001... 10 units (based on flow velocity)
		Zero Cal	Zero calibration settings
		Zero	Perform auto zero calibration Yes No
		Track	Track zero offset Yes No
		Delta	Zero flow delta time offset in ns, read from sensor PROM or entered directly for special sensors
		Timeup	Upstream transit-time offset in μ s, allows for fixed delays in special sensors, buffer rods and extension leads
		Math Function	Select from list $\uparrow\downarrow$ None, Sum, Difference, Average (mean), Max
		Heat Capacity	Specific heat capacity of medium
	User		
		Identifier	Example: Pump P3A 9 character string
		Tag No.	Example: 1FT-3011 9 character string
		Password	Enter a password (Default 1111) See also "Key Lock" below
	Test		
		Installation	Control system simulation: 60 second ramping up of flow velocity in m/s from 0 to programmed Max F Cut and subsequent 60 second ramping down, i.e. the process variable would change over com- plete possible range. All configured outputs will exhibit their programmed behaviour. Yes No
		Display	Display screen test routine
		Keypad	Keypad test routine
		Memory	Memory test routine, Memory erase yes/no
		Peripherals	Unit temperature, time, date, clock, battery meter, charger test routine
		Ultrasonics	Tests ultrasonic board and sensors
		Calibrate PT100s	Tests measured temperature and resistance
		Reset PT100s	Resets temperature inputs
	Settings		
		Date	Example: 03/10/07
		Time	Example: 09:27:00
		Date Format	Select from list $\uparrow\downarrow$ dd/mm/yy mm/dd/yy yy/mm/dd

		Language	Select from list ↑↓ As installed
		Keypad	Enable keypad sound Yes No
	Defaults		Reload factory default settings, except for date and time Yes No
	Key Lock		Locks the keypad until password is entered (four number keys followed by "ENTER"). See also "Password" above.
Diagnostics			
		Temperature	Shows control unit temperature
		Log Memory	Percentage of unused datalogger memory, estimated time remaining
Datalogger			
		Interval	A value of zero turns the datalogger off, a non-zero value turns the datalogger on and defines the logging interval. 0 ... 999 s
	Channel 1, Channel 2	Selection	Select up to 10 items from list ↑↓ ENTER to select, 0 to remove m/s, f/s, in/s, m3/h, m3/min, m3/s, l/h, l/min, l/s, USgall/h, USgall/min, USgall/s, bbl/d, bbl/h, bbl/min, g/s, t/h, kg/h, kg/min, m3, l, Usgall, bbl, g, t, kg, W, kW, MW, J, kJ, MJ, Sig dB (signal), noise dB, SNR, C m/s (sound speed), CU (housing temperature) Tin, Tout (inlet and outlet temperature) TEMP (specified or measured fluid temperature), SOS, DEN. KIN (derived sound speed, density, kinematic viscosity) Math (Calculated value – see below)
		Low Memory	Warning output: The amount of memory remaining at which the flowmeter begins to give an audible warning. 0 ... 100 %
		Log Download	Sends logger content to selected serial communication port.
		Log Erase	Erase datalogger Yes/no
Serial Comms			
		Mode	Select from list ↑↓ None Printer, Diagnostic, Log download, Calibration Test (not normally used by user)
		Baud	Select from list ↑↓ 9600, 19200, 57600, 115200
		Parity	Select from list ↑↓ None Even (Default) Odd
		Type	Select from list where fitted

Table 6: Firmware menu structure

5.2 Diagnostics

Diagnostic screens can be viewed directly during measurement using the **3/DISP** and **1/NEXT** keys, or through the menu structure.

5.3 Display settings

Customer specific settings for data to be displayed can be achieved using the appropriate menu items to select units for the top, middle and bottom lines.

5.3.1 Main PV



The main Process Value (PV) is the primary measurement data, and is usually displayed as the Middle Units.

5.4 Output configuration

Serial interfaces



5.4.1 Serial interface RS 232

The RS 232 serial interface can be used to transmit data on-line or to communicate with peripheral equipment and computers.

5.4.2 Serial interface RS 485 / Modbus RTU

The RS 485 interface is used for networking up to 32 flowmeters to a centralised computer system. Each flowmeter is given an unique address to be able to communicate effectively. The communication protocol used conforms to the conventions of the Modbus RTU protocol, a description of which is given in a separate document. Please refer to customer support for further information.

In addition, the ASCII printer output can also directed through the RS 485 interface.

Wiring	
Setup	Please refer to customer support.
Operation	Please refer to customer support.



5.4.3 HART output

The KF100 can also be configured with an optional HART module which responds to output commands conforming to the HART protocol. Please refer to customer support for further information.

HART® is a registered trademark of the HART Communication Foundation.

Wiring	
Setup	Please refer to customer support.
Operation	Please refer to customer support.

Analogue outputs



5.4.4 Analogue current output 0/4 ... 20 mA

The analogue current outputs operate in a 4 ... 20 mA or 0 ... 20 mA span.

Current outputs may be assigned to process values in the “mode” section of the output menu. The outputs can be programmed and scaled within the menu structure.

Wiring	<p>Active I out (optional)</p> <p>Passive I out (optional)</p>
Electrical characteristics	<p>0/4...20 mA active and 4...20 mA passive options. Galvanically isolated from main electronics and from other I/O's. Passive: U=9...30 V, RLoad=50 ohm typical. Resolution: 16 bit, accuracy: 0.1 % of MV. Active: RLoad<500 ohm, U=30 V. Resolution: 16 bit, accuracy: 0.1 % of MV.</p>

5.4.5 Analogue voltage output 0 – 10 v



Voltage outputs may be assigned to process values in the “mode” section of the output menu. The outputs can be programmed and scaled within the menu structure.

Wiring	<p>Volts out (optional)</p>
Electrical characteristics	<p>Galvanically isolated from main electronics and from other I/O's. Range 0...10 V. RLoad=1000 ohm. Resolution: 16 bit, accuracy: 0.1% of MV.</p>

5.4.6 Analogue frequency output



Frequency outputs may be assigned to process values in the “mode” section of the output menu. The outputs can be programmed and scaled within the menu structure.

Wiring	<p>Frequency (analogue output) (optional)</p>
Electrical characteristics	<p>Galvanically isolated from main electronics and from other I/O's. Open-collector: 2...10000 Hz. U=24 V, I_{max}=4 mA.</p>

Digital outputs

5.4.7 Digital open collector output

Open-Collector outputs may be assigned to process values in the “mode” section of the output menu. The outputs are configured using the menu structure.

The totaliser function is enabled and controlled using the menu structure



Wiring	Optically switched relay "Open-Collector" (optional)
Electrical characteristics	Galvanically isolated from main electronics and from other I/O's. Totaliser pulse, value 0.01...1000/unit. Active high and active low available. Width 1...990 ms. U=24 V, I _{max} =4 mA.

5.4.8 Digital relay output

Relay outputs may be assigned to process values in the “mode” section of the output menu. The relay outputs are configured using the menu structure.



Wiring	
Electrical characteristics	Form A (SPDT-NO and NC) contacts Width 3...990 ms. U=48 V, I _{max} =250 mA. Galvanically isolated from main electronics and from other I/O's. Mode: Alarm, fault, totaliser (programmable). 1 Form A (SPST-NO) contacts. 1 Form A (SPST-NC) contacts. Width 3...990 ms. U=48 V, I _{max} =250 mA.

5.5 Input configuration

5.5.1 PT100 inputs

Inputs



Wiring	Temperature input PT100, 4 wire (optional)
Wiring	Temperature input PT100, 3 wire (optional)
Electrical characteristics	3 and 4 wire options. Galvanically isolated from main electronics and from other I/O's. Temperature: Range -50 ... 400 °C. Resolution: 0.01 K. Accuracy: ±0.1 K.

5.5.2 Analogue current input 0/4 ... 20 mA



Wiring	<p>Analogue input (optional)</p> <p>Analogue input (optional)</p>
Electrical characteristics	<p>Active or passive wiring Measuring range active = 0 ... 20 mA at 30 V Measuring range passive = 4 ... 20 mA Accuracy = 0.1 % of measured value</p>

5.6 Heat quantity measurement (HQM) – [where installed]

If a heat quantity unit is specified for the Process Value, the KF100 will prompt the user for the Specific Heat Capacity of the medium in J/g/K (for example 4.186 J/g/K for water).

This may also be entered in the System\Calculation sub-menu.



The In/Output menu will then allow the user to select the temperature input source; either PT100 temperature sensors or a fixed value for measurement against a known inlet or outlet temperature. Where PT100 sensors are selected, the flowmeter will prompt the user for a temperature offset, which may be useful where the temperature of the medium differs from the temperature of the pipe wall (for example with unlagged pipes). If a fixed value is selected, the meter will ask the user to specify this value.

When heat quantity units are selected, these behave as any other Process Value and may be totalized, or applied to a Process Output.

5.7 Sound velocity measurement (SVM)



The measured sound velocity (SOS) is available as a Process Value and a diagnostic function (where specified) during measurement and may be applied to a Process Output by selecting “C m/s” from the appropriate menu.

5.8 Dual-channel flow calculations (maths functions)

Where suitably equipped, dual channel calculations are available from the System/Calculation/Math menu.

These allow the user to select the sum, difference, average (mean) or maximum of the two flow channels.

This value may be displayed or applied to a Process Output by selecting MATH from the appropriate output menu.

6 Maintenance

No general maintenance is required for this equipment.

7 Troubleshooting

Should there be the need to call customer service, please let us know the following details:



- Model code
- Serial number
- SW, HW revision
- Error log list

Possible error messages may include the following:

Error list

Error message	Group	Description	Error handling
USB INIT FAIL	Hardware	Internal board communication error	Power on/off, otherwise call customer support
NO SERIAL NO.	Hardware	Failed to read from FRAM	Call customer support
NO VERSION NO.	Hardware	Failed to read from FRAM	Call customer support
PARA READ FAIL	Hardware	Failed to read from FRAM	Load defaults, otherwise call customer support
PARA WRITE FAIL	Hardware	Failed to write to FRAM	Load defaults, otherwise call customer support
VAR READ FAIL	Hardware	Failed to read from FRAM	Call customer support
VAR WRITE FAIL	Hardware	Failed to write to FRAM	Call customer support
SYSTEM ERROR	Hardware		Call customer support
VISIBILITY ERR	Hardware	Failed to read from FRAM	Call customer support
FRAM LONG WRITE ERR	Hardware	Failed to write to FRAM	Call customer support
FRAM READ ERR	Hardware	Failed to read from FRAM	Call customer support
RTC ERR	Hardware	Real Time Clock failure	Power on/off, otherwise call customer support
EXTMEM ERR	Hardware	Logger memory failure	Power on/off, otherwise call customer support
SPI ERR	Hardware	SPI bus failure	Power on/off, otherwise call customer support
I2C ERR	Hardware	I2C bus failure	Power on/off, otherwise call customer support
MATH ERR	Software	Internal calculation error	Call customer support
STACK ERR	Software	Internal calculation error	Call customer support
ADDR ERR	Software	Internal calculation error	Call customer support
OSC ERR	Software	Internal calculation error	Call customer support
ADC ERR	Software	Internal calculation error	Call customer support
IO ERR	Software	Internal calculation error	Call customer support
TIMING ERR	Software	Internal calculation error	Call customer support
COMM INIT ERR	Hardware	Internal communication error	Power on/off, otherwise call customer support
COMM START ERR	Hardware	Internal communication error	Power on/off, otherwise call customer support
COMM HS0 ERR	Hardware	Internal communication error	Power on/off, otherwise call customer support

COMM HS1 ERR	Hardware	Internal communication error	Power on/off, otherwise call customer support
COMM READ AVE ERR	Hardware	Internal communication error	Power on/off, otherwise call customer support
COMM READ RAW ERR	Hardware	Internal communication error	Power on/off, otherwise call customer support
COMM READ HISTORY ERR	Hardware	Internal communication error	Power on/off, otherwise call customer support
COMM CRC ERR	Hardware	Internal communication error	Power on/off, otherwise call customer support
SENSOR COUPLING ERR	Application	Weak sensor coupling, low SNR	Recouple sensors, check installation, reduce number of passes, look for other location, then have a cup of tea and call customer support!

Table 7: Error messages

7.1 Data download difficulties

If difficulties are encountered downloading the logger data :-

- Check that the flowmeter is switched on and not in measurement mode.
- Check that the same number COM port is allocated in the “Device Manager” (or equivalent) as is set in the KatData+ software.
- Check that the settings (baud, parity, word length, stop bits) are identical.
- Use the supplied connectors – whether connecting to a 9-pin COM port or converting from serial communication to a Universal Serial Bus (USB).

8 Technical data

Material	Sound Speed* Shear Wave (at 25 °C)	
	m/s	ft/s
Steel, 1% Carbon, hardened	3,150	10,335
Carbon Steel	3,230	10,598
Mild Steel	3,235	10,614
Steel, 1% Carbon	3,220	10,565
302 Stainless Steel	3,120	10,236
303 Stainless Steel	3,120	10,236
304 Stainless Steel	3,141	10,306
304L Stainless Steel	3,070	10,073
316 Stainless Steel	3,272	10,735
347 Stainless Steel	3,095	10,512
Aluminium	3,100	10,171
Aluminium (rolled)	3,040	9,974
Copper	2,260	7,415
Copper (annealed)	2,325	7,628
Copper (rolled)	2,270	7,448
CuNi (70%Cu 30%Ni)	2,540	8,334
CuNi (90%Cu 10%Ni)	2,060	6,759
Brass (Naval)	2,120	6,923
Gold (hard-drawn)	1,200	3,937
Inconel	3,020	9,909
Iron (electrolytic)	3,240	10,630
Iron (Armco)	3,240	10,630
Ductile Iron	3,000	9,843
Cast Iron	2,500	8,203
Monel	2,720	8,924
Nickel	2,960	9,712
Tin (rolled)	1,670	5,479
Titanium	3,125	10,253
Tungsten (annealed)	2,890	9,482
Tungsten (drawn)	2,640	8,661
Tungsten (carbide)	3,980	13,058
Zinc (rolled)	2,440	8,005
Glass (pyrex)	3,280	10,761
Glass (heavy silicante first)	2,380	7,808
Glass (light brate crown)	2,840	9,318
Nylon	1,150	3,772
Nylon, 6-6	1,070	3,510
Polyethylene (LD)	540	1,772
PVC, CPVC	1,060	3,477
Acrylic	1,430	4,690

* Please note these values are to be considered nominal. Solids may be inhomogeneous and anisotropic. Actual values depend on exact composition, temperature, and to a lesser extent, on pressure and stress.

All data given at 25 °C (77 °F) unless otherwise stated

Substance	Chemical Formula	Specific Gravity	Sound Speed		Change v/°C	Kinematic x10 ⁻⁶	Viscosity ft ² /s
			m/s	ft/s			
Acetic anhydride	(CH ₃ CO) ₂ O	1.082 (20 °C)	1,180	3,871.4	2.5	0.769	8.274
Acetic acid, anhydride	(CH ₃ CO) ₂ O	1.082 (20 °C)	1,180	3,871.4	2.5	0.769	8.274
Acetic acid, nitrile	C ₂ H ₃ N	0.783	1,290	4,232.3	4.1	0.441	4.745
Acetic acid, ethyl ester	C ₄ H ₈ O ₂	0.901	1,085	3,559.7	4.4	0.467	5.025
Acetic acid, methyl ester	C ₃ H ₆ O ₂	0.934	1,211	3,973.1		0.407	4.379
Acetone	C ₃ H ₆ O	0.791	1,174	3,851.7	4.5	0.399	4.293
Acetylene dichloride	C ₂ H ₂ Cl ₂	1.26	1,015	3,330.1	3.8	0.400	4.304
Alcohol	C ₂ H ₆ O	0.789	1,207	3,960	4.0	1.396	15.02
Ammonia	NH ₃	0.771	1,729 (-33 °C)	5,672.6 (-27 °C)	6.68	0.292 (-33 °C)	3.141 (-27 °F)
Benzene	C ₆ H ₆	0.879	1,306	4,284.8	4.65	0.711	7.65
Benzol	C ₆ H ₆	0.879	1,306	4,284.8	4.65	0.711	7.65
Bromine	Br ₂	2.928	889	2,916.7	3.0	0.323	3.475
n-Butane(2)	C ₄ H ₁₀	0.601 (0°C)	1,085 (-5° C)	3,559.7 (23 °C)	5.8		
2-Butanol	C ₄ H ₁₀ O	0.81	1,240	4,068.2	3.3	3.239	34.851
sec-Butylalcohol	C ₄ H ₁₀ O	0.81	1,240	4,068.2	3.3	3.239	34.851
n-Butyl bromide (46)	C ₄ H ₉ Br	1.276 (20°C)	1,019 (20°C)	3,343.2 (68°F)		0.49 (15°C)	5.272 (59°C)
n-Butyl chloride (22,46)	C ₄ H ₉ Cl	0.887	1,140	3,740.2	4.57	0.529 (15°C)	5.692 (59°F)
Carbon tetrachloride	CCl ₄	1.595 (20°C)	926	3,038.1	2.48	0.607	6.531
Carbon tetrafluoride (Freon 14)	CF ₄	1.75 (-150 °C)	875.2 (-150 °C)	2,871.5 (-238 °F)	6.61		
Chloroform	CHCl ₃	1.489	979	3,211.9	3.4	0.55	5.918
Dichlorodifluoromethane (Freon 12)	CCl ₂ F ₂	1.516 (40 °C)	774.1	2,539.7	4.24		
Ethanol	C ₂ H ₆ O	0.789	1,207	3,960	4.0	1.39	14.956
Ethyl acetate	C ₄ H ₈ O ₂	0.901	1,085	3,559.7	4.4	0.489	5.263
Ethyl alcohol	C ₂ H ₆ O	0.789	1,207	3,960	4.0	1.396	15.020
Ethyl benzene	C ₈ H ₁₀	0.867 (20 °C)	1,338 (20 °C)	4,89.8 (68 °F)		0.797 (17 °C)	8.575 (63 °F)
Ether	C ₄ H ₁₀ O	0.713	985	3,231.6	4.87	0.311	3.346
Ethyl ether	C ₄ H ₁₀ O	0.713	985	3,231.6	4.87	0.311	3.346
Ethylene bromide	C ₂ H ₄ Br ₂	2.18	995	3,264.4		0.79	8.5
Ethylene chloride	C ₂ H ₄ Cl ₂	1.253	1,193	3,914		0.61	6.563
Ethylene glycol	C ₂ H ₆ O ₂	1.113	1,658	5,439.6	2.1	17,208 (20°C)	185.158 (68°F)
Fluorine	F	0.545 (-143 °C)	403 (-143 °C)	1,322.2 (-225 °F)	11.31		
Formaldehyde, methyl ester	C ₂ H ₄ O ₂	0.974	1,127	3,697.5	4.02		
Freon R12			774.2	2,540			
Glycol	C ₂ H ₆ O ₂	1.113	1,658	5,439.6	2.1		
50% Glycol/50% H ₂ O			1,578	5,177			
Isopropanol	C ₃ H ₈ O	0.785 (20 °C)	1,170 (20 °C)	3,838.6 (68 °F)		2.718	29.245
Isopropyl alcohol (46)	C ₃ H ₈ O	0.785 (20 °C)	1,170 (20 °C)	3,838.6 (68 °F)		2.718	29.245
Kerosene		0.81	1,324	4,343.8	3.6		

Methane	CH ₄	0.162 (-89 °C)	405 (-89 °C)	1,328.7 (-128 °F)	17.5		
Methanol	CH ₄ O	0.791 (20 °C)	1,076	3,530.2	292	0.695	7.478
Methyl acetate	C ₃ H ₆ O ₂	0.934	1,211	3,973.1		0.407	4.379
Methyl alcohol	CH ₄ O	0.791	1,076	3,530.2	292	0.695	7.478
Methyl benzene	C ₇ H ₈	0.867	1,328 (20 °C)	4,357 (68 °F)	4.27	0.644	7.144
Milk, homogenized			1,548	5,080			
Naphtha		0.76	1,225	4,019			
Natural Gas		0.316 (-103 °C)	753 (-103 °C)	2,470.5 (-153 °F)			
Nitrogen	N ₂	0.808 (-199 °C)	962 (-199 °C)	3,156.2 (-326 °F)		0.217 (-199 °C)	2.334 (-326 °F)
Oil, Car (SAE 20a.30)		1.74	870	2,854.3		190	2,045.093
Oil, Castor	C ₁₁ H ₁₀ O ₀	0.969	1,477	4,845.8	3.6	0.670	7.209
Oil, Diesel		0.80	1,250	4,101			
Oil, Fuel AA gravity		0.99	1,485	4,872	3.7		
Oil (Lubricating X200)			1,530	5,019.9			
Oil (Olive)		0.912	1,431	4,694.9	2.75	100	1,076.365
Oil (Peanut)		0.936	1,458	4,738.5			
Propane (-45 to -130 °C)	C ₃ H ₈	0.585 (-45 °C)	1,003 (-45 °C)	3,290.6 (-49 °F)	5.7		
1-Propanol	C ₃ H ₈ O	0.78 (20 °C)	1,222 (20 °C)	4,009.2 (68 °F)			
2-Propanol	C ₃ H ₈ O	0.785 (20 °C)	1,170 (20 °C)	3,838.6 (68 °F)		2.718	29.245
Propene	C ₃ H ₆	0.563 (-13 °C)	963 (-13 °C)	3,159.4 (9 °F)	6.32		
n-Propyl-alcohol	C ₃ H ₈ O	0.78 (20 °C)	1,222 (20 °C)	4,009.2 (68 °F)		2.549	27.427
Propylene	C ₃ H ₆	0.563 (-13 °C)	963 (-13 °C)	3,159.4 (9 °F)	6.32		
Refrigerant 11	CCl ₃ F	1.49	828.3 (0 °C)	2,717.5 (32 °F)	3.56		
Refrigerant 12	CCl ₂ F ₂	1.516 (-40 °C)	774.1 (-40 °C)	2,539.7 (-40 °C)	4.24		
Refrigerant 14	CF ₄	1.75 (-150 °C)	875.24 (-150 °C)	2,871.6 (-268 °F)	6.61		
Refrigerant 21	CHCl ₂ F	1.426 (0 °C)	891 (0 °C)	2,923.2 (32 °F)	3.97		
Refrigerant 22	CHClF ₂	1.491 (-69 °C)	893.9 (50 °C)	2,932.7 (122 °F)	4.79		
Refrigerant 113	CCl ₂ F-CClF ₂	1.563	783.7 (0 °C)	2,571.2 (32 °F)	3.44		
Refrigerant 114	CClF ₂ -CClF ₂	1.455	665.3 (-10 °C)	2,182.7 (14 °F)	3.73		
Refrigerant 115	C ₂ ClF ₅		656.4 (-50 °C)	2,153.5 (-58 °F)	4.42		
Refrigerant C318	C ₄ F ₈	1.62 (-20 °C)	574 (-10 °C)	1,883.2 (14 °F)	3.88		
Sodium nitrate	NoNO ₃	1.884 (336 °C)	1,763.3 (336 °C)	5,785.1 (637 °F)	0.74	1.37 (336 °C)	14.74 (637 °F)
Sodium nitrite	NoNO ₂	1.805 (292 °C)	1876.8 (292 °C)	6157.5 (558 °F)			
Sulphur	S		1177 (250 °C)	3861.5 (482 °F)	-1.13		
Sulphuric Acid	H ₂ SO ₄	1.841	1,257.6	4,126	1.43	11.16	120.081

Tetrachloroethane	C ₂ H ₂ Cl ₄	1553 (20 °C)	1,170 (20 °C)	3,838.6 (68 °F)		1.19	12.804
Tetrachloro-ethene	C ₂ Cl ₄	1.632	1,036	3,399			
Tetrachloro-Methane	CCl ₄	1.595 (20 °C)	926	3,038.1		0.607	6.531
Tetrafluoro-methane (Freon 14)	CF ₄	1.75 (-150 °C)	875.24 (-150 °C)	2,871.5 (-283 °F)	6.61		
Toluene	C ₇ H ₈	0.867 (20 °C)	1,328 (20 °C)	4,357 (68 °F)	4.27	0.644	6.929
Toluol	C ₇ H ₈	0.866	1,308	4,291.3	4.2	0.58	6.24
Trichloro-fluoromethane (Freon 11)	CCl ₃ F	1.49	828.3 (0 °C)	2,717.5 (32 °F)	3.56		
Turpentine		0.88	1,255	4,117.5		1.4	15.064
Water, distilled	H ₂ O	0.996	1,498	4,914.7	-2.4	1.00	10.76
Water, heavy	D ₂ O		1,400	4,593			
Water, sea		1.025	1531	5023	-2.4	1.00	10.76

Temperature Sound Speed in Water

° C	° F	m/s	ft/s
0	32.0	1402	4600
1	33.8	1407	4616
2	35.6	1412	4633
3	37.4	1417	4649
4	39.2	1421	4662
5	41.0	1426	4679
6	42.8	1430	4692
7	44.6	1434	4705
8	46.4	1439	4721
9	48.2	1443	4734
10	50.0	1447	4748
11	51.8	1451	4761
12	53.6	1455	4774
13	55.4	1458	4784
14	57.2	1462	4797
15	59.0	1465	4807
16	60.8	1469	4820
17	62.6	1475	4830
18	64.4	1476	4843
19	66.2	1479	4853
20	68.0	1482	4862
21	69.8	1485	4872
22	71.6	1488	4882
23	73.4	1491	4892
24	75.2	1493	4899
25	77.0	1496	4908
26	78.8	1499	4918
27	80.6	1501	4925
28	82.4	1504	4935
29	84.2	1506	4941
30	86.0	1509	4951
31	87.8	1511	4958
32	89.6	1513	4964
33	91.4	1515	4971
34	93.2	1517	4977

35	95.0	1519	4984
36	96.8	1521	4984
37	98.6	1523	4990
38	100.4	1525	4997
39	102.2	1527	5010
40	104.0	1528	5013
41	105.8	1530	5020
42	107.6	1532	5026
43	109.4	1534	5033
44	111.2	1535	5036
45	113.0	1536	5040
46	114.8	1538	5046
47	116.6	1538	5049
48	118.4	1540	5053
49	120.2	1541	5056
50	122.0	1543	5063
51	123.8	1543	5063
52	125.6	1544	5066
53	127.4	1545	5069
54	129.2	1546	5072
55	131.0	1547	5076
56	132.8	1548	5079
57	134.6	1548	5079
58	136.4	1548	5079
59	138.2	1550	5086
60	140.0	1550	5086
61	141.8	1551	5089
62	143.6	1552	5092
63	145.4	1552	5092
64	147.2	1553	5092
65	149.0	1553	5095
66	150.8	1553	5095
67	152.6	1554	5099
68	154.4	1554	5099
69	156.2	1554	5099
70	158.0	1554	5099
71	159.8	1554	5099
72	161.6	1555	5102
73	163.4	1555	5102
74	165.2	1555	5102
75	167.0	1555	5102
76	167.0	1555	5102
77	170.6	1554	5099
78	172.4	1554	5099
79	174.2	1554	5099
80	176.0	1554	5099
81	177.8	1554	5099
82	179.6	1553	5095
83	181.4	1553	5095
84	183.2	1553	5095
85	185.0	1552	5092
86	186.8	1552	5092
87	188.6	1552	5092
88	190.4	1551	5089

89	192.2	1551	5089
90	194.0	1550	5086
91	195.8	1549	5082
92	197.6	1549	5082
93	199.4	1548	5079
94	201.2	1547	5076
95	203.0	1547	5076
96	204.8	1546	5072
97	206.6	1545	5069
98	208.4	1544	5066
99	210.2	1543	5063
100	212.0	1543	5063
104	220.0	1538	5046
110	230.0	1532	5026
116	240.0	1524	5000
121	250.0	1526	5007
127	260.0	1507	4944
132	270.0	1497	4912
138	280.0	1487	4879
143	290.0	1476	4843
149	300.0	1465	4807
154	310.0	1453	4767
160	320.0	1440	4725
166	330.0	1426	4679
171	340.0	1412	4633
177	350.0	1398	4587
182	360.0	1383	4538
188	370.0	1368	4488
193	380.0	1353	4439
199	390.0	1337	4387
204	400.0	1320	4331
210	410.0	1302	4272
216	420.0	1283	4210
221	430.0	1264	4147
227	440.0	1244	4082
232	450.0	1220	4003
238	460.0	1200	3937
243	470.0	1180	3872
249	480.0	1160	3806
254	490.0	1140	3740
260	500.0	1110	3642

Specific Heat Capacity

Medium	SHC (KJ/Kg.K)
Ethanol @ 0 deg C	2.30
Ethylene Glycol	2.36
Freon R12 @ 5 deg C	0.88
Light oil @ 15 deg C	1.80
Mineral Oil	1.67
Paraffin	2.13
Propane @ 0 deg C	2.40
Water	4.18
Water (salt)	3.93

9 Specification

General

Measuring principle : Ultrasonic time difference correlation principle

Flow velocity range : 0.01 ... 25 m/s

Resolution : 0.25 mm/s

Repeatability : 0.15 % of measured value ± 0.015 m/s

Accuracy :

Volume flow

$\pm 1 \dots 3$ % of measured value depending on application,

± 0.5 % of measured value with process calibration

Flow velocity

± 0.5 % of measured value

Turn down ratio : 1/100

Gaseous and solid content of liquid media : < 10 % of volume

Flowmeter

Enclosure : Wall mounted housing

Degree of protection : IP 66 according EN 60529

Operating temperature : -10 ... 60 °C (14 ... 140 °F)

Housing material : Polycarbonate

Flow channels : 1 or 2

Power supply : 100 ... 240 V AC 50/60 Hz,

9 ... 36 V DC, special versions on request

Display : LCD graphic display, 128 x 64 dots, backlit

Dimensions : H 237 x W 258 x D 146 mm without cable glands

Weight : Approx. 2.3 kg

Power consumption : < 10 W

Signal damping : 0 ... 99 s

Measurement rate : 1Hz standard, higher rates on application

Operating languages : English, 2 other (as requested and subject to availability)

Response time : 1 s, faster rates upon request

Calculation functions : Average/difference/sum

Quantity and units of measurement

Volumetric flow rate : m³/h, m³/min, m³/s, l/h, l/min, l/s, USgal/h (US gallons per hour), USgal/min, USgal/s, bbl/d (barrels per day), bbl/h, bbl/min, bbl/s.

Flow velocity : m/s, ft/s, inch/s

Mass flow rate : g/s, t/h, kg/h, kg/min

Volume : m³, l, gal (US gallons), bbl

Mass : g, kg, t

Heat flow : W, kW, MW (only with heat quantity measurement option)

Heat quantity : J, kJ, MJ (only with heat quantity measurement option)

Sig dB (signal), noise dB, SNR,

C m/s (sound speed), CU (housing temperature)

T_{in}, T_{out} (inlet and outlet temperature)

Internal data logger

Storage capacity : In excess of 1 million data points (16MB)

Logging data : Up to ten selected variables

Communication

Serial interface : RS 232, RS 485 (optional)

Data : Instantaneous measured value, parameter set and configuration, logged data

Software KATdata+

Functionality : Downloading of measured values/parameter sets, graphical presentation, list format, export to third party software, on-line transfer of measured data

Operating systems : Windows 2000, NT, XP, Linux, Mac (optional)

Process inputs / Process Outputs (maximum of ten per instrument)

Inputs

Temperature : PT 100, three or four-wire circuit, measuring range - 50 ... 400 °C, resolution 0.1K, accuracy ± 0.2 K
Current : 0 ... 20 mA active or 4 ... 20 mA passive, U = 30 V, R_i = 50 Ohm, accuracy 0.1 % of MV

Outputs

Current : 0/4 ... 20 mA, active (R_{Load} < 500 Ohm), 16 bit resolution, U = 30 V, accuracy = 0.1 %
Voltage : On request, 0 ... 10 V, R_i = 500 Ohm
Frequency : On request
Digital (Optical - Open Collector) : U = 24 V, I_{max} = 4 mA
Digital (relay) : Form C (SPDT-CO) contacts, U = 48 V, I_{max} = 250 mA

Clamp-on sensors

Type K1L, K1N, K1E

Diameter range : 50 ... 3000 mm
Dimensions : 60 x 30 x 34 mm
Material : Stainless steel
Temperature range :
Type K1N: -30 ... 130 °C (-22 ... 266 °F)
Type K1E: -30 ... 200 °C (-22 ... 392 °F), for short periods up to 300 °C (572 °F)
Degree of protection : IP 66 acc. EN 60529, IP 67 and IP 68 optional

Type K4L, K4N, K4E

Diameter range : 10 ... 250 mm
Dimensions : 43 x 18 x 22 mm
Material : Stainless steel
Temperature range :
Type K4N: -30 ... 130 °C (-22 ... 266 °F)
Type K4E: -30 ... 200 °C (-22 ... 392 °F), for short periods up to 300 °C (572 °F)
Degree of protection : IP 66 acc. EN 60529, IP 67 and IP 68 optional

Type K1Ex, K4Ex

(for use in hazardous areas Zone 1 or 2)

Diameter range :
Type K4Ex: 10 ... 250 mm
Type K1Ex: 50 ... 3000 mm
Dimensions : 60 x 30 x 34 mm
Material : Stainless steel
Temperature range : -20 ... 120 °C
Degree of protection : IP 66 acc. EN 60529
Protection concept : Encapsulation
Certification code : Ex mb IIC T4 - T6

The sensors are suitable for use in hazardous areas classified as Zone 1 and 2. The transmitter unit must be placed in the safe area or suitable enclosure.

10 Index

Acoustic coupling gel	16	Negative separation distance	12
Analogue current input	35	Outer Diameter	23
Analogue current output	33	Output Configuration	32
Analogue frequency output	33	Output settings	32
Analogue voltage output	33	Packaging	8
Certificate of Conformity	47	Passes	23
Commissioning	26	Pipe material selection	22
Customer Return Note (CRN)	48	Pipe parameters	22
Datalogger	25	Pipe preparation	12
Diagnostic displays	25	Process value	24
Diagnostics	32	PT100 inputs	34
Diagonal mode	12	Quick Start	22
Digital open collector output	34	Reflection mode	12
Digital relay output	32	Retaining clip (sensor mounting)	17
Dimensions	13	Return Policy	6
Display	21	RS 232	32
Display icons	21	Safety	5
Display settings	32	Sensor configuration	12
Disturbance sources	10	Sensor Location	9
Dual channel calculations	35	Sensor mounting	16
Electrical connections	15	Sensor mounting fixtures	17
Error messages	36	Sensor placement screen	24
Fluid selection	23	Sensor Separation	12
Fluid temperature	23	Serial interface	32
HART output	32	Setup Wizard	22
Heat quantity measurement	35	SOS (Speed of Sound)	35
Identification of components	8	Sound passes	23
Input configuration	34	Sound velocity measurement	35
Installation	8	Specification	44
Keypad	19	Storage	8
Keypad function	19	Switching on / off	19
Legislative requirements	6	Totalizer	25
Liner material	23	Transit-time method	7
Maintenance	35	Troubleshooting	36
Maths functions	35	Units of measurement	22
Measurements	24	Wall thickness	23
Measuring principle	7	Warranty	6
Menu structure	26	Wizard (quick setup)	22
MODBUS	32		

Appendix A

Certificate of Conformity



Katronic Technologies Ltd.
 23 Cross Street
 Leamington Spa
 CV32 4PX
 GREAT BRITAIN

Phone +44 (0)870 3000 110
 Fax +44 (0)870 3000 111

E-mail mail@katronic.co.uk
 Web www.katronic.co.uk

Declaration of Conformity

We, **Katronic Technologies Ltd.**, declare under our sole responsibility that the products listed below to which this declaration relates are in conformity with the EEC directives:

EMC Directive 2004/108/EC for Electromagnetic Compatibility
Low Voltage Directive 2006/95/EC for Electrical Safety

Description of products:

Ultrasonic flowmeters KATflow 100, 150, 200 and 230 with associated KATRONIC transducers

The mentioned products are in conformity with the following European Standards:

Class	Standard	Description
EMC Directive	BS EN 61326-1:2006	Electrical equipment for measurement, control and laboratory use - EMC requirements
Immunity	BS EN 61326-1:2006	Electrical equipment for continuous unattended use
	BS EN 61000-4-2:1995	Electrostatic discharge
	BS EN 61000-4-3:2006	RF field
	BS EN 61000-4-4:2004	Electric fast transient/burst
	BS EN 61000-4-5:2006	Surge
Emission	BS EN 61000-4-6:2009	RF conducted
	BS EN 61000-4-11:2004	AC mains voltage dips and interruption
Low Voltage Directive	BS EN 61326-1:2006	Electrical equipment Class B
	BS EN 55022:2006	Disturbance voltage Class B
	BS EN 61010-1:2010	Safety requirements for electrical equipment for measurement, control and laboratory use

Leamington Spa, 03 December 2010

For and on behalf of **Katronic Technologies Ltd.**

Andrew Sutton
 Managing Director



Registered in England No. 3298020 • Registered Office as above

Appendix B

Customer Return Note (CRN)



Company	<input type="text"/>	Address	<input type="text"/>
Name	<input type="text"/>	<input type="text"/>	<input type="text"/>
Tel. No.	<input type="text"/>	<input type="text"/>	<input type="text"/>
E-mail	<input type="text"/>	<input type="text"/>	<input type="text"/>

Instrument model	<input type="text"/>	Katronic contract no.	<input type="text"/>
Serial number	<input type="text"/>	(if known)	
Sensor type(s)	<input type="text"/>		
Sensor serial number(s)	<input type="text"/>		

The enclosed instrument has been used in the following environment (please \surd):

Nuclear radiation	<input type="checkbox"/>
Water-endangering	<input type="checkbox"/>
Toxic	<input type="checkbox"/>
Caustic	<input type="checkbox"/>
Biological	<input type="checkbox"/>
Other (please specify)	<input type="text"/>

We confirm (* delete if not applicable)

- that we have checked the instrument and sensors are free of any contamination*,
- neutralised, flushed and decontaminated all parts which have been in contact with hazardous substances and/or environments*,
- that there is no risk to man or environment through any residual material.

Date	<input type="text"/>
Signature	<input type="text"/>
Company stamp	<input type="text"/>