

Coulometric Thickness Tester

電解式膜厚計

COULO-TECHNOSTER





株式会社 電 測
DENSOKU INSTRUMENTS CO.,LTD.

Display screen



Mesurement Screen




Statistics Indication Screen



Statistics Indication Screen

統計選択 1 統計項目設定 3 統計モード設定 2 臨時統計 4 リミット設定 番号を設定して下さい。

Statistics Selection Screen




Transferring Excel data to PC

Standard Accessories



Measurement Table: Easy to set up for round stick (Available for continuous measurement of the same form)
Standard Accessories: 1)Test Solution(100ml) 1bottle
2)Cleansing bottle 1pc 3)Wasting liquid bottle 1pc
4)Measurement Stand 5)Cell A/B 6)Gasket A/B/C
7)Thickness Standard(Ni/Fe) 1pc 8)Cleaning liquid 1 bottle
9)Beaker,Spoite 10)Stirring Tube 1set Fuse
Operation Manual

Option



W T=Wire Material and test sample under width 1.7mm : necessary for using Wire Tester.

Option: 11)Anode & Cathod Jig 12)Plastic Vise 13)Wire Tester



Purpose

You can use accurate thickness measurement for single, multi, alloy material plating.

Especially it is efficient for : thin plating, thickness under 1um thick plating, thickness over 20um and multi-layers more than triple layers.

Principle

When using suitable test solution for each plating, dissolving fixed area by fixed electric current, and plating thickness can be measured by required time for its disolution.

Standard

Our thickness tester is authorized and adopted by JIS; ASTM; MIL; ISO; DIN and other industrial standards.

Managing various platings by high performance.

Special Feature

- Screen: bigger, more clearly Dialogue method is employed
- 2) Electric current accuracy has been improved.
- 3) Surface process method at m'ment point can be confirmed easily.
- 5 layers measurement conditions can be set up for multi plating layers, at maximum.
- 5) Measurement channels can be saved 50 channels at maximum.
- 6) The tin plating measurement can be measured each pure tin layer or tin alloy layer.
- 7) Depending on combination of plating and base, available test solution can be indicated automatically.
- 8) Excel data can be transferred directly to PC.
- 9) As statistics process function is employed, data can be indicated on the screen.
- 5 kinds of data transactions are adopted.
- 11) Printer is used for thermal paper
- 12) Weight calculation for unit per area can be done
- By using electrode and recorder both, electric potential difference on W-Ni and Tri-Ni can be easily measured. (By option)

Coat/Base Combination and Test Solution Application

Plating	Solution	Substrate		
Cu	K-44	Steel, Aluminium, Nickel,		
		Molybdenum, Stainless Steel, Non-Metallics		
	K-52	Brass, Berylium-copper, Lead, Zinc-Die-Cast, Cadmium, Tin, Nickel-silver		
Ni	K-54	Steel, Aluminium, Brass, Copper, Inconel,		
		Molybdenum, Tungsten, Stainless Steel, Non-metallics, Chrom		
	K-53	Kovar		
Cr	K-47	Brass, Copper, Cobalt, Nickel-silver, Cadmium,		
		Nickel, Stainless Steel		
	K-51	Steel, Aluminium, Nickel, Stainless, Non-metallics, Inconel		
Electro- K-57		Steel, Aluminium, Kovar, Non-Metallics		
less		Magnetic-Stainless		
Nickel				
Au	K-56	Brass, copper, Nickel, Electroless Nickel, Nickel-silver, Cobalt		
Ag	K-44	Steel, Aluminium, Non-metallics		
	K-48	Brass, Copper, Tin, Non-metallics		
	K-48G	Nickel,Nickel-silver		
Sn	K-47	Steel, Nickel, Nickel-silver, Cadmium, Non-metallics,Permalloy		
	K-51	Aluminium		
	K-50	Copper, Brass		
Zn	K-46	Steel, Aluminium, Brass, Copper, Nickel, Non-metallics, Tin, tungsten		
Solder	K-44	Steel, Aluminium, Brass, copper, Non-metallilcs		
(Tin:Lead=60:40)				
Cobalt	K-54	Steel, Brass, Copper, Non-metallics		
Brass	K-44	Steel, Aluminium, Non-metallics		
Cadmium	K-45	Steel, Aluminium, Brass, Copper, Nickel, Non-metallics		
		Tungsten		
Surface Treatment	N-64	Removing deposit after nickel measurement		
Solution	C.S.	Cleaning Suspension-removing stain of test sample and polishing resins		

Type of Thickness Standards

Chromium/Brass	5~7μm
Chromium/Copper	5~7μm
Chromium/Steel	3~6µm
Chromium/Nickel	0.3~0.5µm
Copper/Steel	10~14µm
Copper/Zinc	5~7μm
Nickel/Steel	10~14µm
Nickel/Brass	10~14μm
Nickel/Copper	10~14µm
Silver/Steel	10~14μm
Silver/Brass	10~14μm
Silver/Copper	10~14μm

Tin/Steel	= 10~14μm
Tin/Copper	10~14µm
Tin/Brass	10~14µm
Zinc/Steel	10∼14µm
Zinc/Brass	10∼14µm
Zinc/Copper	10~14µm
Gold/Nickel	0.5∼0.7µm
Gold/Brass	0.5~0.7μm
Gold/Copper	0.5∼0.7µm

Specification

Measuring Dissolution Speed	0.125u/second or 0.0125u/second, 0.00125/second	
Accuracy of Main Unit	$\pm 1\%$	
Measurement Unit	um, nm, mg(g/m2)	
Dimension	H181x W287x D302mm	
Weight	5.8kgs(for Main unit)	
Power Supply	AC100V(115V,200V,230V), 50/60Hz	
Measurement Area	A Gasket: 3.4ϕ	
	B Gasket: 2.4ϕ	
	C Gasket: 1.7ϕ	