

Method

References: ASTM D 1385-01, Hydrazine in Water. L. C. Thomas and G. J. Chamberlin, *Colorimetric Chemical Analytical Methods*, 8th ed., pp. 194-195, Method I (1974).

Hydrazine is a powerful reducing agent that is used in various chemical processes and in boiler water as an oxygen scavenger. To control corrosion, residual hydrazine typically is maintained in the 0.05 to 0.1 mg/L range. Higher levels may be used to guard against corrosion when the boiler is out of service for an extended period.

CHEMetrics' hydrazine test kits employ the PDMAB, paradimethylaminobenzaldehyde chemistry. PDMAB in acid solution reacts with hydrazine to form a yellow product. Results are expressed as ppb ($\mu\text{g/L}$) or ppm (mg/L) N_2H_4 .

Visual Kits

Range: 0-50 ppb
MDL: 2 ppb / Method: PDMAB

	Cat#
ULR CHEMets Kit	K-5011
ULR CHEMets Refill, 30 ampoules	R-5011
Comparator 0, 2, 5, 10, 20, 30, 40, 50 ppb	C-5011

Kit comes in a plastic case and contains everything needed to perform 30 tests: Refill, Comparator, 25 mL sample cup, instructions, and MSDS.

Range: 0-0.5 ppm
MDL: 0.005 ppm / Method: PDMAB

	Cat#
CHEMets Kit	K-5005
CHEMets Refill, 30 ampoules	R-5005
Comparator 0, 0.01, 0.03, 0.05, 0.07, 0.1, 0.3, 0.5 ppm	C-5005

Kit comes in a plastic case and contains everything needed to perform 30 tests: Refill, Comparator, 25 mL sample cup, instructions, and MSDS.

Range: 0-12.5 ppm
MDL: 0.25 ppm / Method: PDMAB

	Cat#
VACUettes Kit	K-5005D
VACUettes Refill, 30 ampoules	R-5005D
Comparator 0, 0.25, 0.75, 1.25, 1.75, 2.5, 7.5, 12.5 ppm	C-5005D

Kit comes in a plastic case and contains everything needed to perform 30 tests (except distilled water): Refill, Comparator, dilutor snapper cup, micro test tube, instructions, and MSDS.

Range: 0-25 ppm
MDL: 0.5 ppm / Method: PDMAB

	Cat#
VACUettes Kit	K-5005A
VACUettes Refill, 30 ampoules	R-5005A
Comparator 0, 0.5, 1.5, 2.5, 3.5, 5, 15, 25 ppm	C-5005A

Kit comes in a plastic case and contains everything needed to perform 30 tests (except distilled water): Refill, Comparator, dilutor snapper cup, micro test tube, instructions, and MSDS.





Instrumental Kits

V-2000 Multi-Analyte Photometer

(See page 12 for instrumental features)

Range: V-2000: 0.10-1.20 ppm / Spec: 0.070-0.700 ppm
Method: PDMAB

Vacu-vials Kit **Cat#**
K-5003

Kit comes in a cardboard box and contains everything needed to perform up to 30 tests: thirty ampoules, 25 mL sample cup, ampoule blank, instructions, calibration table, and MSDS.

Vacu-vials Kits require the use of the V-2000 Photometer or a spectrophotometer capable of accepting a 13 mm diameter round cell. Instrument sold separately.

Kit Components common to Hydrazine

Description	Cat#
Sample Cup Pack, 25 mL (6 ea)	A-0013
Micro Test Tube Pack (10 ea)	A-0015
Dilutor Snapper Cup Pack (6 ea)	A-0018
Ampoule Blank Pack (5 ea)	A-0023

Instructions are posted on our website.

If no shelf-life is listed for a product, then the shelf-life is at least 2 years.

Range: 0-50 ppm MDL: 1 ppm / Method: PDMAB	
VACUettes Kit	Cat# K-5005B
VACUettes Refill, 30 ampoules	R-5005B
Comparator 0, 1, 3, 5, 7, 10, 30, 50 ppm	C-5005B
Kit comes in a plastic case and contains everything needed to perform 30 tests (except distilled water): Refill, Comparator, dilutor snapper cup, micro test tube, instructions, and MSDS.	

Range: 0-500 ppm MDL: 10 ppm / Method: PDMAB	
VACUettes Kit	Cat# K-5005C
VACUettes Refill, 30 ampoules	R-5005C
Comparator 0, 10, 30, 50, 70, 100, 300, 500 ppm	C-5005C
Kit comes in a plastic case and contains everything needed to perform 30 tests (except distilled water): Refill, Comparator, dilutor snapper cup, micro test tube, instructions, and MSDS.	

